

AD Parts Master 2020

No.	Description	MSRP
001-7013	Worm Shaft	3.78
001-9010	Worm Shaft Gear	0.50
002-0010	Worm Shaft Pin	0.50
002-5020	Osc Pawl Washer	0.50
002-8070	SCREW(C)	0.50
003-1805	Drag Knob	4.66
003-2001	Bail	5.39
003-5010	SCREW(H)	0.50
003-5020	SCREW(J)	0.50
003-5050	SCREW(E)	0.50
004-5020	Drive Gear Washer B	0.50
004-7010	Worm Shaft Retainer	0.50
007-1020	Adj Cap O-Ring	0.50
008-6030	Sleeve Washer	0.50
008-8010	Drag Spring Washer	0.50
012-0010	Spool Bearing Pin	0.50
013-5010	Drive Shaft Plt Screw	0.50
014-1010	Spool Cover Screw	0.50
014-1020	Front Cover Screw A	0.50
014-4050	WASHER(C)	0.50
015-2010	SCREW(B)	0.50
018-0010	HANDLE SCREW	0.50
018-0020	Handle Screw	0.50
018-8010	CLICK LEAF SPRING HOLDER	0.51
018-8040	Click Plate	0.69
019-6010	Bushing A	0.50
020-2020	Side Cover Screw B	0.50
020-2030	Side Cover Screw A	0.50
028-8021	Osc Pawl Nut	0.50
029-3010	Clutch Lever Screw	0.50
030-6611	Click Pawl	0.50
030-6612	Click Pawl	1.01
040-3201	Handle Nut Plate	0.72
040-3206	Handle Nut Plate	5.76
040-3207	Handle Nut Plate	5.10
040-3208	Handle Nut Plate	5.76
040-3211	Handle Nut Plate	4.35
040-3217	Plate	5.51
040-3218	Handle Nut Plate	2.30
040-3222	Handle Nut Plate	6.36
040-4801	Clutch Stoper Plate	0.60
041-5601	Rod Brace	2.17
041-8011	Gear Shaft Collar	2.27

041-8102	Bail Kick Lever Cover	0.50
041-8802	Bail Spring Cover	0.50
041-9202	Bail Kick Lever Cover	0.60
041-9901	Rod Clamp	1.95
046-4011	Osc Pawl	1.20
052-6020	Slide Cam Screw	0.50
053-9020	Worm Shaft Washer	0.50
054-8010	Drive Gear Washer A	0.50
055-8032	Drive Shaft	2.61
063-3905	BODY COVER	2.60
063-4005	Body Cover	3.36
064-6010	WASHER(A)	0.50
064-6020	WASHER(B)	0.50
069-0010	Adj Cap Washer	0.50
071-0512	Drive Gear Shaft	3.21
071-0513	Drive Gear Shaft	2.30
080-0070	Yoke	0.99
080-0080	Yoke	0.99
081-8010	A/R Ratchet	0.54
083-4010	Tension Washer	0.50
090-0260	Clutch Lever	1.76
090-0261	Clutch Lever	1.35
090-0280	Clutch Lever	0.88
090-0290	Clutch Lever	0.88
090-0340	Clutch lever	0.74
093-3010	Star Drag Washer	0.50
102-2081	Star drag	19.22
110-1030	Frame	27.29
110-1031	Frame	19.66
110-1035	Frame	19.66
110-1038	Frame	27.29
110-1040	Frame	27.29
110-1041	Frame	27.14
110-1045	Frame	19.66
110-1048	Frame	27.14
110-1070	Frame	24.29
110-1074	FRAME	24.29
110-1080	Frame	24.29
110-1084	Frame	24.29
110-1100	Frame	26.59
110-1110	Frame	18.96
110-1180	Frame	30.07
110-1181	Frame	27.29
110-1184	Frame	27.14
110-1185	FRAME	30.07
110-2020	Frame	27.29
110-2021	Frame	27.29

110-2024	Frame	27.29
110-2025	Frame	30.75
110-2082	Frame Assembly	10.07
110-2092	Frame	10.07
111-7011	A/R Pawl	0.50
111-8301	A/R Claw	0.57
117-3030	Drive Shaft	2.61
117-7050	SCREW(D)	0.50
120-2020	Handle Nut Ret Screw	0.50
121-4212	Line Guide Pawl	2.17
121-6801	Set Plt Screw	0.50
122-0601	Line Guide Pawl	2.87
122-0602	Line Guide Pawl	4.19
130-6801	Anti Reverse Lever Cover	0.82
136-7010	Key Washer	0.60
140-0570	Ball Bearing D	4.44
140-0610	Ball Bearing D	1.42
140-0970	Ball Bearing	4.50
140-1280	Ball Bearing C	1.42
140-1370	Roller Clutch	8.00
140-1400	Ball Bearing A	2.68
140-1500	Ball Bearing A	9.04
140-1550	Ball Bearing	11.12
140-1650	Ball Bearing A	5.32
140-1770	Ball Bearing (D)	13.20
140-1790	Ball Bearing	18.84
140-1810	Roller Clutch	6.05
140-1820	Ball Bearing B	1.42
140-1850	Ball Bearing C	1.42
140-1880	Ball Bearing	5.01
140-1890	Roller Clutch	9.07
140-2000	Roller Clutch	8.95
140-2060	Ball Bearing	4.16
140-2130	Ball Bearing	14.58
140-2180	Ball Bearing	11.12
140-2340	Ball Bearing	7.88
140-2630	Ball bearing	20.95
140-3220	Ball Bearing D	13.23
140-3310	Ball bearing	19.48
140-6010	Level Wind Guard	0.50
140-7010	A/R Ratchet	0.54
142-5111	Pick Up Pin Spring	0.50
144-0321	A/R Cam Spring	0.50
144-1211	Click Lever Spring	0.50
144-5111	A/R Claw Spring	0.50
145-0001	Bail Spring	0.50
145-0501	A/R Pawl Spring	0.50

145-0701	Bail Kick Cam Spring	0.50
145-0902	A/R Pawl Spring	0.50
145-2101	Click Spring	0.50
145-2701	Anti Reverse Cam Spring	0.50
145-2901	A/R Claw Spring	0.50
145-3001	Bail Kick Cam Spring	0.50
150-0270	Bearing	2.49
150-1050	Bushing	0.72
150-1350	BUSHING	1.39
150-1760	Drive Shaft Bushing	1.67
150-1790	Worm Shaft Holder	1.48
150-1820	Bushing	0.50
150-2060	Bushing	0.72
150-2190	Gear Shaft Collar	2.74
150-2200	Gear Shaft Collar	2.74
150-2250	Gear Shaft Collar	2.61
150-2260	Worm Shaft Washer	0.50
150-2270	Gear Shaft Collar	2.74
150-2280	Gear Shaft Collar	2.58
150-3020	Bush	0.72
150-3060	Bushing	0.66
150-3240	Bushing	0.51
150-7030	Screw A	0.50
150-8901	Spring Washer	0.50
150-8902	DRAG SPRING WASHER	0.75
150-9001	Handle Washer	0.50
151-7211	Spool Metal Leaf Spring	0.50
151-8901	Drag Adj Plt	0.82
151-9101	Drag Adj Plt	1.10
153-1010	Drag Washer	0.57
156-8030	Ball bearing (C)	14.18
158-8011	Ball Bearing Retainer	0.50
160-7922	Click Spring	3.15
160-8001	Lock Washer	0.50
160-8101	Washer	0.50
160-8401	Lock Washer	0.50
170-1261	Clutch Cam	0.66
170-1271	Clutch Cam	0.66
170-1280	Clutch Cam	0.88
170-1330	Clutch Cam	0.60
170-1340	Clutch Cam	0.57
170-1370	Clutch Cam	0.66
170-1380	Clutch Cam	0.66
170-1390	Clutch Cam	0.57
170-1510	Clutch cam	0.51
170-1520	Clutch cam	0.51
170-4101	Drag Washer Ret	0.50

170-4601	Drag Washer Ret	0.50
170-7701	Ball Bearing Ret	0.50
171-1001	O Ring	0.50
171-5201	O Ring	0.72
171-5202	IDLE GEAR"O"RING (B)	1.02
171-7701	Drag Washer Ret	0.50
175-5033	Washer (D)	0.63
180-1990	Handle Nut Plate	0.50
180-2470	Handle Nut Plate	1.42
180-2471	Handle Nut Plate	1.89
180-2600	Counter Cover	11.12
185-0010	Spool Spacer	0.50
190-1140	Click Pawl	1.04
190-1270	Click Pawl	1.45
190-1271	Click Pawl	1.26
193-8020	Drive Gear B	0.50
200-0530	Ret	0.50
200-0570	E-Clip	2.74
200-0580	Ret	0.50
200-0590	Ret	0.50
200-0870	Ret	0.50
200-1160	Retainer	0.50
200-1440	Retainer	0.50
200-2010	Click Leaf Spring	0.50
201-4020	Click pawl retainer	0.50
202-1617	Rotor	6.83
202-1802	Rotor	5.37
202-1903	Rotor	9.49
207-3010	Pinion Yoke	0.50
207-6010	Clutch cam retainer	0.50
208-0020	Retainer (B)	0.50
208-3010	Yoke	0.50
210-0750	Spacing Sleeve	1.01
210-0981	Brake Collar	0.54
210-0990	Spacing Sleeve	1.83
210-2410	Kick Lever Spring Bushing	1.39
210-2580	Collar	1.04
210-2610	Collar	1.04
210-2620	Collar	1.10
210-2630	Collar	1.07
210-2670	Brake Collar	2.93
218-2011	Handle nut screw	1.07
220-3000	Left Set Plate	1.95
220-3001	Set Plate	1.95
220-3010	Set Plate	2.49
220-3011	Set Plate	3.56
220-3021	Set Plate	3.15

220-3030	Set Plate	2.49
220-3031	Set Plate	3.56
220-3050	Counter Cover	9.23
220-3062	Handle nut	3.62
220-3070	Counter Cover	9.23
220-3091	Counter Cover	2.30
220-3100	Counter Cover	1.73
220-3110	Set Plate	9.89
220-3120	Set Plate	9.89
220-3130	Set Plate	9.89
220-3140	Set Plate	9.89
220-3150	Set Plate	2.30
220-3160	Set Plate	6.30
220-3170	Set Plate	6.30
220-3210	Set plate	9.41
230-072B	Right Side Plate	3.44
230-2270	Left Side Plate	2.54
230-2275	Left Side Plate	9.98
230-2280	L/S Plate	21.98
230-2281	Left Side Plate	21.98
230-2330	Right Side Plt	21.98
230-2340	Right Side Plate	21.98
230-2341	Right Side Plt	22.20
230-2342	Right Side Plt	22.20
230-2343	Right Side Plt	22.20
230-2345	R/S Plt	17.12
230-2346	R/S Plt	17.12
230-2347	Right Side Plate	17.12
230-2350	Left Side Plate	3.46
230-2355	L/S Plt	8.79
230-235B	Left Side Plate	8.79
230-2360	Set Plate	2.93
230-2370	Right Side Plt	3.46
230-2372	Left Side Plate	7.91
230-2375	L/S Plt	16.73
230-2380	Left Side Plt	22.20
230-2385	R/S Plt	8.59
230-238B	Right Side Plate	6.56
230-2390	Set Plate	2.30
230-2420	Right Side Plt	21.98
230-2430	Left Side Plate	2.54
230-2470	Right Side Plate	6.48
230-2475	Right Side Plate	6.48
230-2490	Right Side Plate	21.98
230-2491	Right Side Plate	21.98
230-2492	Right Side Plate	19.66
230-2510	Left Side Plate	3.61

230-2530	Right Side Plate	13.88
230-2531	Right Side Plate	13.88
230-2540	Left Side Plate	8.10
230-2550	Right Side Plate	18.82
230-2551	Right Side Plate	22.20
230-2552	Right Side Plate	22.20
230-2553	Right Side Plate	15.15
230-2555	R/S Plt	18.49
230-2556	R/S Plt	18.49
230-2557	Right Side Plate	18.49
230-2558	Right Side Plate	18.49
230-2560	Left Side Plate	3.46
230-2565	L/S Plt	9.72
230-256B	Left Side Plate	9.72
230-2570	Set Plate	2.30
230-2580	Left Side Plate	15.15
230-2581	Left Side Plate	22.20
230-2582	Left Side Plate	22.20
230-2585	L/S Plt	18.49
230-2590	Right Side Plate	22.20
230-2595	R/S Plt	9.72
230-259B	Right Side Plate	9.72
230-2600	Set Plate	2.30
230-2610	Right Side Plate	13.88
230-2611	Right Side Plate	13.88
230-2620	Left Side Plate	8.10
230-2640	L/S Plate	8.79
230-2641	L/S Plate	8.79
230-2650	R/S Plt	4.86
230-2660	L/S Plate	5.25
230-2661	L/S Plate	5.25
230-2670	R/S Plate	3.61
230-2680	L/S Plate	9.78
230-2681	L/S Plate	9.78
230-2690	R/S Plate	3.61
230-2700	R/S Plate	7.77
230-2701	R/S Plate	7.95
230-2702	R/S Plate	7.95
230-2703	R/S Plate	7.95
230-2704	R/S Plate	8.10
230-2705	R/S Plate	8.10
230-2710	L/S Plate	8.10
230-2711	L/S Plate	7.91
230-2712	L/S Plate	7.95
230-2713	L/S Plate	6.85
230-2714	L/S Plate	8.10
230-2715	L/S Plate	8.10

230-2720	R/S Plate	6.79
230-2721	R/S Plate	6.85
230-2722	R/S Plate	6.93
230-2730	L/S Plate	7.95
230-2731	L/S Plate	6.85
230-2732	L/S Plate	6.93
230-273B	Left Side Plate	3.44
230-2740	Left Side Plate	3.61
230-2760	Right Side Plate	21.48
230-2770	Left Side Plate	7.91
230-2820	Left Side Plate	21.48
230-2830	Right Side Plate	7.91
230-2840	Left Side Plate	7.91
230-2850	Right Side Plate	18.08
230-2874	Left Side Plate	11.07
230-2894	Right Side Plate	18.08
230-2900	Set Plate	9.89
230-2924	Left Side Plate	10.15
230-2964	Right Side Plate	7.91
230-3010	Set Plate	2.49
230-8011	Kick Lever	0.50
231-3501	Arm Lever	2.33
236-6010	Ball Bearing	3.53
23A-2560	Left side plate	15.44
23A-2590	Right side plate	15.44
240-1952	Magnet Holder	4.25
240-2030	A/R Ratchet	2.05
240-2180	Worm Shaft Gear	0.50
240-2190	Drive Gear A	0.50
240-2200	Drive Shaft Gear	0.54
240-2210	Worm Shaft Gear	0.50
240-2230	Spool Gear	1.73
240-2260	Drive Gear "B"	0.76
240-2290	Magnet Holder	4.25
240-2300	Worm Shaft Gear	2.55
240-2310	Worm Shaft Gear	2.43
240-2330	Cog Wheel	0.88
240-2340	Cog Wheel	0.88
240-2460	Worm Shaft Gear (B)	0.50
240-2480	Shaft	1.39
240-2490	Worm Shaft Gear (C)	0.72
240-2530	Anti-Reverse Ratchet	0.72
240-2540	Anti-Reverse Ratchet	2.93
240-2550	Anti-Reverse Ratchet	2.36
240-2560	A/R Ratchet	3.59
240-2820	Counter Gear	0.66
240-2830	Counter Gear	1.35

240-2850	Click Gear	1.64
240-2860	Idle Gear	0.50
240-2880	Counter Gear	0.50
240-2890	Idle Gear	0.76
240-2900	Idle Gear	3.31
240-2910	Gear	0.50
240-2930	Worm Shaft Gear (B)	0.60
240-2950	Worm Shaft Gear B	0.98
240-3030	A/R Ratchet	4.44
240-3040	A/R Ratchet	2.71
240-3090	Spool Gear	7.37
240-3200	Worm Shaft Gear	7.65
240-3210	Worm Shaft Gear (A)	0.98
240-3220	Worm Shaft Gear (C)	0.72
240-3230	Shaft	1.39
240-3240	Worm Shaft Gear (B)	7.65
240-3250	Cog Wheel	0.54
240-3260	Worm Shaft Gear	0.54
240-3270	Worm Shaft Gear	0.54
240-3290	Worm Shaft Gear	0.54
240-4040	Anti-reverse ratchet	3.57
243-8010	Worm Shaft Bushing	0.50
246-5010	Yoke Spring	0.50
250-1321	Drive Gear	6.50
250-1322	Drive Gear	6.64
250-1323	Drive Gear	6.64
250-1324	Drive Gear	6.64
250-1340	Drive Gear	10.64
250-1341	Drive gear	8.92
250-1350	Drive Gear	10.64
250-1360	Drive Gear	10.64
250-1370	Drive Gear	10.64
250-1371	Drive Gear	10.64
250-1380	Drive Gear	9.80
250-1400	Drive Gear	9.25
250-1410	Drive Gear	9.84
250-1420	Drive Gear	9.25
250-1430	Drive Gear	6.11
250-1440	Drive Gear	9.25
250-1450	Drive Gear	9.25
250-1460	Drive Gear	9.25
250-1470	Drive Gear	9.25
250-1500	Drive Gear	10.64
250-1510	Drive Gear	10.64
250-1520	Drive Gear	22.10
250-1540	Drive Gear	10.78
250-1550	Drive Gear	10.78

250-1560	Drive Gear	10.78
250-1570	Drive Gear	10.52
250-1580	Drive Gear	10.54
250-1590	Drive Gear	9.80
250-1640	Drive Gear	12.26
250-1650	Drive Gear	12.26
250-1660	Drive Gear	12.26
250-1700	Drive Gear	6.79
250-1710	Drive Gear	12.71
250-1720	Drive Gear	12.71
250-1780	Drive Gear	12.26
250-1790	Drive Gear	12.71
250-1800	Drive Gear	12.71
250-1820	Drive Gear	10.39
250-1850	Drive Gear	10.39
250-1860	Drive Gear	17.40
250-1870	Drive Gear	7.91
250-2180	Drive gear	22.06
250-2190	Drive gear	22.06
250-2200	DRIVE GEAR	12.30
250-3921	Line Roller	1.01
250-4221	Line Roller	1.80
250-4501	Line Roller	1.07
25A-2190	DRIVE GEAR	12.30
260-1670	Pinion Gear	3.77
260-1671	Pinion Gear	6.25
260-1673	Pinion Gear	6.25
260-1680	Pinion Gear	3.77
260-1681	Pinion Gear	6.25
260-1683	Pinion Gear	9.72
260-1690	Pinion Gear	3.77
260-1691	Pinion Gear	6.25
260-1693	Pinion Gear	6.25
260-1701	Pinion Gear	6.25
260-1703	Pinion Gear	3.77
260-1721	Pinion Gear	6.25
260-1730	Pinion Gear	5.31
260-1733	Pinion Gear	6.44
260-1740	Pinion Gear	5.31
260-1743	Pinion Gear	6.44
260-1750	Pinion Gear	5.31
260-1753	Pinion Gear	6.44
260-1760	Pinion Gear	5.31
260-1761	Pinion Gear	5.31
260-1763	Pinion Gear	6.44
260-1830	Pinion Gear	6.25
260-1901	Pinion Gear	6.25

260-1910	Pinion Gear	6.25
260-1940	Pinion Gear	5.31
260-1950	Pinion Gear	5.31
260-1960	Pinion Gear	4.49
260-2000	Pinion Gear	4.63
260-2001	Pinion Gear	11.99
260-2010	Pinion Gear	4.63
260-2011	Pinion Gear	6.56
260-2020	Pinion Gear	4.63
260-2021	Pinion Gear	8.10
260-2030	Pinion Gear	4.63
260-2031	Pinion Gear	8.26
260-2040	Pinion Gear	5.23
260-2041	Pinion Gear	6.56
260-2050	Pinion Gear	4.16
260-2060	Pinion Gear	4.16
260-2070	Pinion Gear	3.96
260-2080	Pinion Gear	3.96
260-2152	Pinion Gear	8.10
260-2154	PINION GEAR	5.31
260-2160	Pinion Gear	8.10
260-2201	Pinion Gear	7.91
260-2202	Pinion Gear	8.10
260-2211	Pinion Gear	8.10
260-2221	Pinion Gear	8.10
260-2232	PINION GEAR	11.65
260-2290	Pinion Gear	8.10
260-2300	Pinion Gear	8.10
260-2310	Pinion Gear	8.10
260-2330	Pinion Gear	6.66
260-2360	Pinion Gear	6.66
260-2400	Gear	0.72
260-2410	Pinion Gear	11.99
260-2420	Pinion Gear	11.99
260-2430	Gear	0.82
260-2700	Pinion gear	11.40
260-2710	Pinion gear	11.40
260-2720	Pinion gear	11.40
260-2750	Pinion gear	11.40
260-2760	Pinion gear	12.87
260-5010	Bushing	0.50
266-5010	Slide Cam Spring	0.50
268-8010	Clutch Cam Plt Spring	0.50
269-0010	Clutch Cam Plt Spring	0.50
270-0720	Level Wind Guard	0.72
270-0810	Level Wind Guard	0.72
270-0820	Level Wind Guard	2.77

270-0840	Level Wind Guard	8.63
270-0850	Level Wind Guard	4.00
270-0860	Line Guide	7.88
270-0870	Level Wind Guard	0.72
270-0890	Level Wind Guard	4.95
270-0920	Level Wind Guard	2.93
270-0930	Level Wind Guard	0.72
271-1010	Stabilizer Bar	0.50
280-6702	Ratchet	2.55
280-8901	Ratchet	1.80
280-9001	Ratchet	1.10
280-9301	Ratchet	0.50
280-9501	Ratchet	0.82
286-7010	Drive Gear	9.94
286-8010	Drive Gear	9.94
289-3010	CLUTCH CAM PLATE(A)	0.50
289-4010	Clutch Cam Plt Retainer	0.57
289-5010	CAM PLATE_R	0.50
292-8010	PINION GEAR (6.8:1)	5.86
292-9010	PINION GEAR (7.5:1)	5.86
293-0010	PINION GEAR (8.3:1)	5.86
293-9010	CLUTCH CAM PLATE(A)	0.50
294-0010	CAM PLATE_L	0.50
295-0010	Ball Bearing A	2.71
295-2010	Drive Shaft Bearing	2.71
295-4010	Ball Bearing	2.71
295-7010	PINION GEAR (6.8:1)	5.86
295-8010	PINION GEAR (7.5:1)	5.86
295-9010	PINION GEAR (8.3:1)	5.86
296-1010	Drive Gear	9.94
296-2010	Drive Gear	9.94
297-6010	Bearing Retainer	0.50
301-3020	SCREW(G)	0.50
301-4010	Clutch Cam Plt Ret Screw	0.50
310-1350	Cast Control Cap	3.31
320-1170	Star Drag	14.21
320-1180	Star Drag	10.84
320-1201	Star Drag	14.88
320-1220	Star Drag	11.28
320-1230	Star Drag	11.94
320-1231	Star Drag	11.94
320-1233	Star Drag	2.74
320-1234	Star Drag	4.13
320-1235	Star Drag	4.13
320-1260	Star Drag	11.31
320-1270	Star Drag	3.06
320-1402	Ret	0.50

320-1611	Retainer	0.50
320-5901	Ret	0.50
320-7601	Ret	0.50
320-7602	Drive Shaft Ret	0.50
320-8002	Retainer	0.50
320-8202	Retainer	0.50
320-9501	Ball Bearing Ret Washer	0.50
320-9702	Mechanical Brake Knob Ret	0.50
321-0101	Anti Reverse Lever Retain	0.50
321-0801	Ball Bearing Ret Washer	0.50
321-1001	Spool Retainer	0.72
32A-1330	Star drag	22.01
330-2750	Clutch Lever	0.57
330-2820	Clutch Trip Plate	0.50
330-2830	Clutch Trip Plate	0.50
330-2840	Kick Lever	1.23
330-2850	Kick Lever	1.23
330-2860	Click Button	5.26
330-2940	Kick Lever	1.42
330-2941	Kick lever	1.47
330-2950	Kick Lever	1.42
330-2951	Kick lever	1.47
330-3000	Click Button	2.27
330-3050	Click Button	2.27
330-3060	Click Button	2.17
330-3180	Kick lever	9.37
330-3190	Kick lever	9.37
340-6602	Rotor Nut	0.50
341-5801	Handle Nut	1.07
341-5805	Handle Nut	4.66
341-5901	Line Guide Nut	1.07
341-9201	Rotor Nut	0.50
341-9203	Rotor Nut	0.50
342-3102	Handle Arm Ret Nut	0.82
342-4004	Power Lever Nut B	2.02
342-4911	Rotor Nut	1.54
342-5301	Clamp Nut	1.80
35001	One Pound Blue Grease	38.00
35002	One Pound Super Lube	20.55
350-0310	Handle Nut Plate	1.76
350-8912	Screw	0.50
351-0311	Osc Slider Screw	0.50
351-0901	Screw	0.50
351-0905	Screw	0.50
351-0906	Set Plt Screw	0.50
351-1010	Screw (K)	1.92
351-1106	Side Cover Screw	0.72

351-1801	Screw	0.50
351-1803	Screw	0.50
351-1804	Screw	0.50
351-4701	Screw	0.50
351-5311	Screw	0.50
351-5901	Body Cover Screw	0.50
351-6101	Screw	0.50
351-6108	Side Cover Screw	0.50
351-6401	Screw	0.50
351-6413	A/R Claw Screw	0.50
351-6417	Screw (J)	0.95
351-6601	Screw	0.50
351-7701	Screw	0.50
351-7704	Rear Cover Screw	0.50
351-7705	Idle Gear Screw	0.50
351-7706	Idle Gear A Screw	0.50
351-7709	Brake Adjusting Screw	0.50
351-7801	Body Cover Screw	0.50
351-8801	Body Cover Screw	0.50
351-8901	Screw	0.50
351-8903	Osc Slider Cover Screw	0.50
351-9001	Osc Slider Screw	0.63
352-0401	Screw	0.50
352-0601	Screw	0.50
352-0901	Screw	0.50
352-1102	Screw	0.50
352-2010	Level Wind Assembly	2.36
352-2201	Screw	0.50
352-2501	A/R Lever Screw	0.50
352-2506	Screw	0.50
352-2509	Screw	1.80
352-2510	Screw	0.50
352-7020	Brake collar (B)	0.50
353-0001	Body Cover Screw	0.50
353-1812	Line Roller Screw	0.57
353-4401	Screw	0.50
353-4402	Screw	0.50
353-4911	Body Cover Screw	0.50
353-8201	Screw	0.50
353-8207	Line Roller Screw	0.91
353-8209	Screw	0.50
353-8212	Set Plate Gear Screw	0.79
353-8301	Handle Nut Plate Screw	0.50
353-8302	Handle Nut Plate Screw	0.50
353-8705	R/S Plt Screw A	0.50
353-9101	Handle Arm Ret Nut Screw	0.50
353-9801	Rod Clamp Screw	1.07

358-2010	Clutch Cam Plate	0.50
358-3010	Slide Cam	0.50
358-4010	Dial Cam	0.50
358-5010	Clutch Cam Plate	0.50
358-6010	Drive Shaft Plate	0.50
35A-0310	Handle nut plate	1.84
360-2321	Main shaft	7.72
361-5010	Pinion Gear	5.68
361-6010	Pinion Gear	5.68
361-7011	Arm Lever Screw	1.80
361-9010	Pinion Gear	5.68
361-9011	Osc Gear Screw	0.72
362-0010	Pinion Gear	5.68
363-2911	Cam Kick Plt Screw	0.57
363-3111	Bail Screw	0.72
363-4702	Handle Screw Cap	0.66
363-5201	Arm Lever Screw	1.07
363-5302	Handle Screw	1.07
363-8511	Handle Screw	0.50
363-8611	Handle Lock Screw	0.72
363-8801	A/R Claw Screw	0.50
363-9301	A/R Claw Screw	0.57
364-0431	Drag Adj Screw	0.79
364-0531	Drag Adj Screw	0.79
364-1101	Clamp Bolt	0.98
364-3011	Spring	0.50
371-2822	Washer	0.50
371-2829	Washer	0.50
371-2836	Washer F	0.50
371-6905	Clutch Trip Plt Washer	0.50
371-6906	Clutch Trip Plt Washer	0.50
371-6907	Clutch Trip Plt Washer	0.50
372-3832	Eared Washer	0.72
372-3833	Drag Washer C	0.50
372-3837	Drag Lip Washer	3.21
372-6504	Disc Washer	1.07
372-7602	Handle Ret	0.50
372-7603	Washer	0.50
372-7608	Washer C	0.91
372-7610	RATCHET WASHER	0.50
372-9601	Spool Washer	0.50
372-9911	A/R Lever Washer	0.50
373-1303	Osc Pawl Washer	0.50
373-1306	Worm Shaft Washer	0.50
373-1601	Click Claw Washer	0.50
373-1602	Click Claw Washer	0.50
373-1603	Worm Shaft Washer	0.50

373-1604	Washer	0.50
373-2701	Washer	0.50
373-3606	Eared Washer	0.50
373-3701	Disc Washer	0.72
373-3711	Drag Washer	0.50
373-4501	Line Roller Washer	0.50
373-7611	Gear Shaft Washer	0.50
373-7806	Spacer	0.50
373-7807	Washer	0.50
373-7808	Drive Gear Washer	0.66
373-7810	Washer	0.50
373-7813	Handle Bearing Washer	0.50
373-7816	Washer	0.50
374-4802	Key Washer	0.50
374-6604	Drive Shaft Washer B	0.50
374-6605	Drive Shaft Washer B	0.50
374-9102	Shim Plate	0.50
374-9103	Shim Plate	0.50
374-9302	Gear Shaft Washer B	0.50
375-0502	Drive Gear Washer	0.50
375-1001	Washer	0.50
375-1101	Washer	0.50
375-1505	Clamp Screw Washer	2.02
375-3002	Washer	0.50
375-3003	Washer	0.57
375-3005	Washer	0.50
375-4101	Worm Shaft Pawl Washer	0.50
375-4102	SPOOL GEAR (B)WASHER	0.50
375-4104	Brake Dial Washer	0.50
375-5200	PINION BEARING(B) WASHER	0.50
375-5202	Washer	0.50
375-5401	Eared Washer	0.50
375-5701	Spool Washer	0.50
375-5801	Drive Shaft Washer	0.50
375-5805	Drive Shaft Washer A	0.50
375-5903	Disc Washer	1.39
375-6001	Key Washer	0.60
375-7403	Ball Bearing Metal Washer	0.50
375-7404	Bearing Metal Washer	0.50
375-7405	Spacer	0.50
375-7406	Bearing Washer	0.50
375-7411	Spacer B	0.50
375-7501	Spool Adj Cap Metal	0.50
375-7802	Disc Washer	0.72
375-8002	Eared Washer	0.50
375-8500	PINION BEARING(A) WASHER	0.68
375-8501	Washer	0.50

375-8502	Drive Gear Washer	0.50
375-8503	Ball Bearing Washer	0.50
375-9301	Click Button Washer	0.50
375-9801	Washer	0.50
375-9803	Washer	0.50
376-0101	Drag D Washer	0.50
376-1801	Worm Shaft Holder Washer	0.50
376-1901	Spool Washer	0.66
376-2001	Drag Washer B	0.50
376-2101	Drag Washer	0.72
376-3901	Spool Washer	0.50
376-4001	Drag D Washer	0.50
377-2010	Drive Gear Washer A	0.50
380-0770	Handle Nut	1.17
380-0780	Line Guide Nut	0.50
380-0880	Handle Nut	1.45
380-1441	Handle Nut	5.39
380-1740	Pawl Cap	4.54
380-1770	Cast Control Cap	2.84
380-1780	Cast Control Cap	2.84
380-1790	Cast Control Cap	2.49
380-1791	Cast Control Cap	4.54
380-1792	Cast Control Cap	4.54
380-1810	Handle Nut	3.47
380-1830	Cast Control Cap	3.34
380-1831	Cast Control Cap	5.45
380-1890	Cast Control Cap	4.63
380-1891	Cast Control Cap	4.63
380-1930	Handle Nut	5.39
380-1990	Cast Control Cap	5.32
380-1991	Cast Control Cap	5.32
380-2000	Handle Nut	3.56
380-2010	Handle Nut	3.56
380-2020	Cast Control Cap	2.43
380-2023	Cast Control Cap	2.65
380-3210	Nut	3.16
380-3220	NUT	3.16
380-3320	Cast Control Cap	3.50
380-3470	Cast control cap	8.09
382-1721	Shaft Metal	2.33
382-1821	Shaft Metal	3.24
38A-1990	Cast control cap	5.62
394-1301	Main Shaft	1.01
400-2250	Spool Pin	0.50
400-2531	Screw	0.72
400-2540	Line Guide Pawl	1.64
400-2550	Pin	1.42

400-2560	Pin	1.42
400-2570	Pin	0.50
400-2580	Line Guide Pawl	4.16
400-2610	Stabilizer Bar	3.56
400-2620	Stabilizer Bar	3.91
400-2630	Stabilizer Bar	3.56
400-2640	Stabilizer Bar	3.91
400-2650	Stabilizer Bar	4.25
400-2660	Pillar	0.50
400-2670	Stabilizer Bar	2.55
400-2680	Stabilizer Bar	2.71
400-2710	Stabilizer Bar	2.93
400-2720	SPOOL PIN	0.50
400-2730	Stabilizer Bar	2.93
400-2740	Stabilizer Bar	2.71
400-3310	Kick Lever Pin	1.07
400-3311	Kick Lever Pin	1.35
400-3320	A/R Pawl Pin	1.54
400-3380	Pillar	0.50
402-6401	Pinion Gear	2.34
402-6701	Pinion Gear	0.66
403-0701	Pinion Gear	1.68
403-2201	Pinion Gear	2.99
403-2801	Pinion Gear	2.58
403-2901	Spool Gear	1.01
403-3301	Pinion Gear	3.03
40A-3380	Pillar	4.56
410-1911	Brake Dial Ret B	0.50
410-1920	Pinion Yoke	0.54
410-1960	Spacer C	0.50
410-1970	Spacer B	0.50
410-2020	Click Spring Holder	0.76
410-2140	Clutch Lever Plt C	0.50
410-2150	Clutch Lever Plt B	0.50
410-2210	Drive Gear Shaft Plate	0.88
410-2211	Drive Shaft Plate	1.35
410-2220	Click Leaf Spring Holder	0.85
410-2500	Handle Nut Plate	2.68
410-250G	Handle Nut Plate	2.68
410-2540	Drive Shaft Plate	0.88
410-2550	Plate	0.88
410-2610	Plate	0.60
410-2611	Plate	2.17
410-2620	Plate	3.09
410-2621	Plate	2.17
410-2650	Plate (R)	5.76
410-2660	Plate (L)	6.39

410-2670	Spacer C	0.50
410-2680	Spacer B	0.50
410-2690	Clutch Cam Plate	5.51
410-2700	Drive Shaft Plate	2.71
410-2710	Yoke	0.66
410-2711	Yoke	0.66
410-2720	Brake Dial Ret B	0.50
410-2730	Clutch Cam Plate	5.54
410-2740	Drive Shaft Plate	0.88
410-2750	Yoke	0.66
410-2751	Yoke	0.66
410-2880	Yoke	0.50
410-2890	Yoke	0.50
410-3030	Yoke	5.92
410-3040	Click Spring Ret	0.50
410-3050	Yoke Plate	2.39
410-3060	Yoke Plate	2.39
410-3070	Yoke Plate	2.21
410-3350	Plate	0.50
410-3360	Plate	0.54
410-3370	Plate	0.60
410-3380	Plate	0.98
410-4450	Spacer (A)	0.50
410-4460	Spacer (B)	0.50
410-4470	Plate	0.51
410-4480	Plate	3.05
410-4490	Plate	1.40
410-4500	Plate	0.51
410-4510	Plate	3.05
410-4520	Plate	0.88
413-5821	Drive Gear	2.09
413-7010	Kick Lever Spring	0.50
414-0012	Drive Gear	0.62
414-1312	Drive Gear	4.45
414-1801	Drive Gear	0.94
414-1901	Drive Gear	0.94
414-2302	Drive Gear	2.11
414-2901	Drive Gear	2.34
414-6010	Kick Lever Spring	0.50
41A-2500	Handle nut plate	3.68
420-0010	Frame	5.35
420-0020	Frame	2.50
420-0030	Frame	2.09
420-1020	Frame Plate	0.91
420-2010	Clutch Bar Plate R	0.50
420-2020	SPACER(A)	0.50
420-3010	Clutch Bar Plate L	0.50

420-3020	SPACER(B)	0.50
420-4010	Clutch Lever	0.91
420-5010	Front Cover	0.91
420-5020	Front Cover	0.54
420-5030	Front Cover	0.54
420-5040	FRONT PLATE	0.55
420-7010	Gear Side Cover	6.21
420-7020	Gear Side Cover	3.12
420-7030	Gear Side Cover	3.12
420-7060	RIGHT SIDE PLATE(A)	4.52
420-9010	Star Drag	1.42
420-9020	Star Drag	1.42
420-9030	Star Drag	1.42
420-9040	Star Drag	1.42
420-9050	STAR DRAG (8.3:1)	1.47
420-9070	STAR DRAG (8.3:1)	1.47
421-1010	Handle Assembly	7.81
421-1011	HANDLE ASSEMBLY(A)	5.11
421-3010	Handle Knob	1.01
421-4010	Cap	0.72
421-4020	CAP	0.74
421-5010	Handle Nut Retainer	0.50
421-5020	Handle Nut Retainer	0.50
421-5030	Handle Nut Retainer	0.50
421-5040	HANDLE LOCK PLATE	0.50
422-0010	Palm Side Cover	4.19
422-0020	Palm Side Cover	1.89
422-0030	Palm Side Cover	1.89
422-0040	LEFT SIDE PLATE(A)	2.65
422-1010	Palm Side Cover Trim	0.50
422-1020	Palm Side Cover Trim	0.63
422-2010	Spool Cover	0.91
422-3010	Lock Lever	0.50
422-4010	Control Dial	0.50
422-4020	Control Dial	0.76
422-9010	Handle Assembly	11.25
422-9020	Handle Assembly	7.81
422-9030	Handle Assembly	4.35
423-0010	Frame	5.35
423-0020	Frame	4.16
423-0030	Frame	2.07
423-1010	Front Cover	0.91
423-1020	Front Cover	0.54
423-1030	Front Cover	0.54
423-3010	Gear Side Cover	6.21
423-3020	Gear Side Cover	3.12
423-3030	Gear Side Cover	3.12

423-3060	RIGHT SIDE PLATE(A)	4.52
423-7010	Palm Side Cover	4.19
423-7020	Palm Side Cover	1.89
423-7030	Palm Side Cover	1.89
423-7040	LEFT SIDE PLATE(A)	2.65
423-8010	Lock Lever	0.50
424-0010	Spool Assembly	11.30
424-0020	Spool Assembly	11.30
424-0030	Spool Assembly	10.21
425-3010	Spool Assembly	11.30
425-3020	Spool Assembly	11.30
425-3030	Spool Assembly	10.17
427-7011	Ball bearing (A)	10.08
429-6011	HANDLE NUT	0.66
429-7011	HANDLE NUT	0.66
429-8010	Cast Control Cap	1.20
429-8020	Cast Control Cap	1.42
429-8030	Cast Control Cap	1.42
429-8040	CAST CONTROL CAP	1.47
429-9010	Magnet Holder Assembly	1.70
430-0440	Bearing Ret	0.50
430-0970	Magnet holder ret, ring	0.50
430-1000	O Ring	0.63
430-1060	Ret	0.50
430-1061	Bearing Retainer	0.50
430-1070	Magnet Holder Ret	0.50
430-1080	O Ring	0.50
430-1110	O-ring	0.50
430-1131	Ring Holder	2.96
430-1150	Left Side Outer Ring	7.12
430-1160	Left Side Outer Ring	7.47
430-1170	Right Side Outer Ring	8.16
430-1180	Left Side Outer Ring	7.47
430-1330	Left Side Outer Ring	16.03
430-1340	Right Side Outer Ring	15.21
430-1350	Right Side Outer Ring	16.73
430-1360	Right Side Outer Ring	16.73
430-1370	Left Side Outer Ring	17.99
430-1430	L/S Outer Ring	14.11
430-1440	R/S Outer Ring	14.93
437-4010	DRIVE SHAFT	2.68
437-6010	DRIVE SHAFT	2.68
440-9010	PLATE	0.50
444-7010	ROLLER CLUTCH	5.37
453-7010	GEAR SHAFT COLLAR	2.35
457-5010	FRAME	22.11
457-6010	COVER(B)	0.96

457-7010	FRAME	22.11
457-8010	Click Pin	0.50
457-9010	Click Pin Spring	0.50
460-0440	Screw	0.50
460-0450	Handle Nut Plate Screw	0.50
460-1010	DRIVE GEAR (8.3:1)	10.29
460-1131	Side Plate Screw	0.50
460-1290	Screw	0.50
460-1480	Click Spring Screw	0.50
460-1570	Plt Screw	0.50
460-1830	Screw	0.50
460-1860	Screw	0.50
460-1980	Screw	0.50
460-2010	DRIVE GEAR (8.3:1)	10.29
460-2130	Counter Gear Screw	0.50
460-2150	Screw	0.50
460-2260	Click Spring Screw	0.50
460-2580	Screw	0.50
460-2930	Screw	0.50
460-3220	Set Plt Screw	0.50
460-3850	Screw	0.50
460-4160	Counter Screw	0.50
460-4161	Screw	0.50
460-4260	Handle Lock Screw	0.50
460-4300	Screw	0.50
460-4330	Clutch Lever Screw	0.50
460-4350	Side Plt Screw	0.50
460-4380	Handle Nut Plate Screw	0.50
460-4640	Screw	0.50
460-4850	Side Plate Screw	0.50
460-4861	Long Screw	1.07
460-4870	Screw	0.50
460-4900	Screw	0.50
460-4980	Long Screw	1.76
460-5170	Long Screw	1.07
460-5180	Counter Gear Screw	0.50
460-5240	Counter Screw	0.76
460-5241	Screw	0.76
460-5270	Side Plate Screw	0.50
460-5290	Screw	0.50
460-5320	Long Screw	0.50
460-5370	Screw	0.50
460-5380	Handle Nut Plate Screw	0.50
460-5390	Handle Nut Plate Screw	0.50
460-5440	Clutch Cam Screw	0.50
460-5450	Side Plt Screw	0.50
460-5460	Drive Shaft Ret Screw	0.50

460-5470	Right Side Plt Screw	0.50
460-5480	Left Side Plt Screw	0.50
460-5490	Click Spring Screw	0.50
460-5500	Left Side Plate Screw	0.50
460-5510	Drive Shaft Ret Screw	0.50
460-5570	Set Plt Screw	2.33
460-5571	Set Plate Screw	3.72
460-5600	Screw	0.50
460-5620	Set Plate Screw	2.33
460-5630	Screw	0.50
460-5660	Counter Gear Screw	0.50
460-5670	Counter Gear Screw	0.50
460-5780	Set Plate Screw	4.85
460-5790	Screw	0.50
460-6010	Side Cover Screw	0.50
460-6020	R/S Plt Screw B	0.50
460-6030	Screw	0.50
460-6040	Side Plate Screw	0.50
460-6050	R/S Plt Screw B	0.50
460-6070	Left Side Plate Screw	0.50
460-6080	Right Side Plate Screw	0.50
460-6090	Left Side Plate Screw	0.50
460-7010	Screw	0.50
460-7030	Side Plate Screw	0.50
460-7040	Screw	0.50
460-7050	Screw	0.50
460-7070	R/S Plt Screw	0.50
460-7080	Screw	0.50
460-7340	LONG SCREW (W/thumb screw head)	4.69
460-7400	Screw	0.50
460-7420	Long Screw	1.45
460-7430	Screw	0.50
460-7440	Set Plate Screw	4.63
460-7460	Screw	0.50
460-7470	Set Plate Screw	0.50
460-7480	Long Screw	3.43
460-7510	Screw	0.50
460-7940	Screw	0.50
460-8010	SPOOL ASSEMBLY	9.69
460-8180	Screw	0.50
461-4501	A/R Cam	0.50
461-5103	A/R Cam	1.54
461-7107	A/R Cam	1.45
461-7302	A/R Cam	1.01
470-1920	Worm Shaft	3.37
470-1930	Drive Shaft	4.16
470-1931	Drive Shaft	4.16

470-1940	Drive Shaft	4.16
470-1941	Drive Shaft	4.16
470-1950	Drive Shaft	5.17
470-1951	Drive Shaft	9.23
470-1960	Worm Shaft	7.72
470-1970	Drive Shaft	5.17
470-1971	Drive Shaft	9.23
470-2030	Worm Shaft	11.59
470-2070	Worm Shaft Assembly	10.43
470-2080	Worm Shaft Assembly	10.71
470-2100	Worm Shaft	5.04
470-2110	Worm Shaft	5.54
470-2140	Worm Shaft	2.43
470-2422	Drive Shaft	24.66
470-2423	Drive Shaft	24.66
470-2430	Worm Shaft	8.51
470-2440	Drive Shaft	24.73
470-2441	Drive Shaft	25.23
470-2442	Drive Shaft	25.23
470-2470	Drive Shaft	6.49
470-2480	Drive Shaft	6.49
470-2490	Drive shaft	26.10
470-2500	Drive shaft	26.10
470-2510	Drive shaft	17.09
470-2520	Drive shaft	17.09
470-3081	Drive Shaft	4.16
470-3091	Drive Shaft	6.30
470-3150	Drive Shaft	10.62
470-3160	Worm Shaft Assembly	1.83
470-3170	Drive Shaft	14.36
470-3180	Drive Shaft	11.62
470-3190	Worm Shaft Assembly	18.25
470-3200	Drive Shaft	10.36
470-3210	Drive Shaft	10.36
470-3230	Drive Shaft	10.36
470-3360	Worm Shaft	8.69
470-3390	Worm Shaft	8.69
470-3790	Drive Shaft	4.16
470-3880	Drive Shaft	4.16
470-4500	Worm Shaft	8.69
470-4540	Worm Shaft	16.60
470-4550	Worm Shaft	8.69
470-4570	Worm Shaft	7.72
470-4580	Worm Shaft	7.50
470-4590	Worm Shaft	7.50
471-8720	Shaft	1.61
480-7601	Osc Slider	1.20

481-1802	Osc Slider	0.50
481-2101	Osc Slider	0.50
481-2401	Osc Slider	0.72
481-2701	Osc Slider	0.72
481-3011	Osc Slider	0.50
481-3111	Osc Slider	0.50
490-1080	Line Guide	6.21
490-1100	Line Guide	6.21
490-1102	Line guide	7.06
501-1401	Roller Collar	0.50
501-1601	Roller Collar	0.50
501-1602	Line Roller Collar	0.57
501-2001	Roller Collar	0.50
501-9901	Spring Holder	0.50
502-1301	Spring Holder	1.07
502-1401	Roller Bushing	0.72
510-2440	Spool Tension Spring	0.72
510-3260	Leaf Spring	0.50
510-4210	A/R Pawl Spring	0.50
510-4430	Yoke Spring	0.50
510-4450	Set Plate Spring	0.50
510-4540	Click Leaf Spring	0.50
510-4560	Yoke Spring	0.50
510-4590	Drag Spring Washer	0.76
510-4760	Leaf Spring	3.56
510-4770	Yoke Spring	0.50
510-5040	Clutch Cam Spring	0.88
510-5050	Clutch Trip Plt Spring	0.50
510-5051	Kick Lever Spring	0.50
510-5070	Clutch Cam Spring A	0.50
510-5080	Clutch Cam Spring B	0.50
510-5081	Kick Lever Spring	0.50
510-5100	Yoke Spring	0.50
510-5120	Click Spring	3.31
510-5130	Kick Lever Spring	0.50
510-5140	Kick Lever Spring	0.50
510-5160	Spring	0.50
510-5162	Spring	0.50
510-5170	Spring	0.50
510-5172	Spring	0.50
510-5180	Brake Click Spring	0.50
510-5190	Yoke Spring	0.50
510-5290	Kick Lever Spring	0.50
510-5300	Spring	0.50
510-5310	Spring	0.50
510-5320	Kick Lever Spring	0.50
510-5330	Spring	0.50

510-5340	Brake Click Spring	0.50
510-5341	Brake click spring	0.59
510-5350	Clutch Cam Spring	0.50
510-5370	Click Leaf Spring Holder	1.92
510-5380	Clutch Spring	0.50
510-5390	Clutch Cam Spring (A)	0.50
510-5400	Clutch Cam Spring (A)	0.50
510-6040	Yoke Spring	0.50
510-6130	Spring	0.77
510-6220	Spring	0.50
510-6230	Click Spring	3.47
510-6240	Click Spring	3.47
510-6290	Click Spring	3.47
510-6300	Spring	0.50
510-6310	Click Spring	3.09
510-6320	Spring	0.50
510-6330	Click Spring	2.84
510-6340	Click Spring	2.84
510-6370	Clutch Trip Plate Spring	0.50
510-6610	Kick lever spring	0.50
510-6620	Yoke spring	0.50
510-6630	Kick lever spring	0.50
523-4030	Ball bearing (E)	13.23
530-0790	A/R Pawl	3.43
530-0840	Anti-Reverse Pawl	2.08
530-0850	Anti-Reverse Pawl	2.14
530-0860	Anti-Reverse Pawl	4.50
530-0900	A/R Pawl	1.32
530-0920	A/R Pawl	2.05
540-1490	Spacing Washer	0.50
540-1570	Spacing Washer	0.50
540-2830	Washer B	0.50
540-3200	Apacer (A)	0.50
540-3930	Washer	0.50
540-3950	Washer	0.50
540-3980	Washer	0.50
540-4140	Washer	0.50
540-4170	Washer (A)	0.50
540-4180	Drive Shaft Washer (B)	21.33
540-4340	Spacer	0.50
540-5170	Washer G	0.50
540-5380	Washer	1.61
540-5440	Clutch Lever Washer	0.50
540-5460	Worm Shaft Holder Washer	0.50
540-5480	Yoke Washer	0.57
540-5550	Washer F	0.57
540-5570	Click Spring Washer	0.57

540-5580	Washer	0.50
540-5801	A/R Lever	1.07
540-5980	Spacer (D)	0.50
540-5990	Spacer A	0.50
540-6020	Washer B	0.50
540-6060	Worm Shaft Washer	0.50
540-6180	Key Washer	2.61
540-6190	Eared Washer	2.21
540-6210	Washer	0.50
540-6250	Washer	0.50
540-6340	Spacing Washer	0.50
540-6390	Drag Spring Washer	0.50
540-6391	Washer	0.88
540-6460	Washer	0.50
540-6570	Drag Washer	0.50
540-6580	Washer	5.10
540-6600	Washer	0.50
540-6670	Washer	0.50
540-6840	Drive Shaft Washer B	0.50
540-6850	Spacer D	0.50
540-6870	Drag Washer	0.72
540-6880	Drag Washer	3.91
540-6890	Drag Washer	5.67
540-6910	Key Washer	1.48
540-6930	Drag Washer	0.50
540-6950	Drag Washer	3.21
540-6980	Drive Shaft Washer	0.63
540-6990	Drive Shaft Washer	0.50
540-7000	Drag Washer	0.50
540-7010	Drive Shaft Washer A	1.07
540-7080	Drag Washer	0.66
540-7100	Washer	15.97
540-7110	Drive Shaft Washer	0.50
540-7160	Worm Shaft Holder Washer	0.50
540-7170	Spacer (A)	0.50
540-7190	Washer	0.50
540-7210	Washer (E)	0.79
540-7220	Washer	0.50
540-7250	Washer	0.50
540-7300	Drag Washer	3.21
540-7990	Eared Washer	1.73
540-8000	Washer (E)	1.61
540-8010	Key Washer	1.86
540-8020	Key Washer B	4.63
540-8030	Eared Washer	1.48
540-8050	Drag Washer	4.16
540-8060	Key Washer	1.86

540-8070	Key Washer	1.86
540-8080	Washer	11.88
540-8090	Drag Washer	12.00
540-8100	Key Washer	1.86
540-8110	Spacer A	0.50
540-8120	Spacer	0.50
540-8140	Washer	0.50
540-9020	Washer D	0.50
540-9021	Washer	2.93
540-9030	Key Washer	1.86
540-9031	Key Washer	2.17
540-9050	Washer	1.86
540-9271	Washer	3.01
540-9301	Washer	3.01
540-9370	Worm Shaft Holder Washer	0.50
540-9720	Worm Shaft Washer	0.50
540-9740	Washer	0.54
540-9750	Washer	0.50
540-9760	Washer	1.04
540-9770	Washer	0.54
540-9830	Washer	1.07
540-9890	Washer	15.97
541-3132	A/R Lever	0.72
541-5406	A/R Lever	1.61
541-6801	A/R Lever	0.50
541-7301	A/R Lever	0.50
550-1371	Counter	12.16
550-1601	Front Plate	1.42
550-1610	Brake Adjusting Knob	3.34
550-1611	Brake Adjusting Knob	1.32
550-1630	Frame Plate	1.42
550-1631	Front Plate	4.98
550-1635	Front Plt	4.98
550-1640	Frame Plate	1.42
550-1641	Front Plt	4.98
550-1650	Front Plate	1.76
550-1651	Front Plate	2.14
550-1660	Front Plate	3.97
550-1661	Front Plate	3.97
550-1700	Brake Adj Knob	1.32
550-1710	Front Plate	2.99
550-1711	Front Plate	5.67
550-1715	Front Plt	5.67
550-1720	Front Plate	1.42
550-1721	Front Plate	5.67
550-1724	Front Plate	2.99
550-1725	Front Plt	5.67

550-1760	Front Plate	2.30
550-1762	Front Plate	2.27
550-1767	Front Plate	2.30
550-1770	Front Plate	2.30
550-1772	Front Plt	2.96
550-1777	Front Plate	2.30
550-1850	Front Plate	3.31
550-1890	Front Plate	3.31
550-1900	Front Plate	3.31
550-1910	Front Plate	3.31
550-1960	Frame plate	1.18
550-1970	Frame plate	1.18
550-1980	Brake adjusting knob	3.79
550-4004	Front Plate	1.76
550-4104	Front Plate	1.76
550-6100	Counter Assembly	17.86
55A-1710	Frame plate	5.88
55A-1720	Frame plate	5.88
571-0901	Bail Kick Cam	0.57
571-1001	Bail Kick Lever	0.66
571-1101	Bail Kick Cam	0.72
571-1201	Bail Kick Lever	0.91
571-1301	Bail Kick Cam	0.79
575-3010	bearing	1.51
600-8011	Clamp nut	3.15
610-7011	Gear shaft collar	5.13
610-7021	Gear shaft collar	5.13
617-4010	Click button washer (A)	0.50
617-4030	Click button washer (A)	0.50
624-4020	Rod clamp	3.15
630-4020	Drag washer (C)	9.07
633-1312	Bail Spring Cover	0.60
633-3010	Roller clutch	8.00
635-4801	Ball Bearing	8.66
635-5001	Ball Bearing	8.63
635-9901	Ball Bearing Ret Washer	0.50
636-6403	Ball Bearing	7.06
636-6711	Click Gear	0.72
636-7602	Oscillating Support	0.60
637-0102	Osc Support	1.07
637-2102	Ball Bearing	5.70
637-3001	Osc Support	1.29
637-4111	Osc Support	1.73
637-4801	Drive Gear Bushing	0.50
637-5601	Bearing Metal	0.76
637-5702	Ball Bearing	7.94
679-3010	Click pawl	1.17

683-5011	Anti-reverse pawl	5.04
688-8010	"O"ring (C)	0.50
694-2010	Washer (J)	2.58
699-2041	Frame plate	10.05
699-2051	Frame plate	10.05
699-2061	Frame plate	10.05
6E6401020	COLLAR	7.25
6E6471041	SCREW	6.30
6E6766031	HANDLE KNOB	22.05
6E7502010	HANDLE ARM	17.33
6E7543010	HANDLE ARM	18.90
6E7570010	HANDLE KNOB	23.63
6E7741012	CLAMP NUT B	2.27
6F7210010	NUT	7.34
6F7212010	NUT	8.38
6J0021010	HANDLE ASSY	23.82
6J0218010	HANDLE ASSY	24.54
6J0229010	HANDLE ASSY	23.64
700-0490	Frame	10.41
700-0500	Frame	11.56
700-0510	Frame	11.56
700-0520	Frame	12.71
700-0530	Frame	13.88
700-0590	Left Side Plate	6.93
700-0600	Left Side Plate	8.10
700-0610	Right Side Plate	11.56
700-0620	Right Side Plate	11.56
700-0630	Right Side Plate	13.88
700-0640	Right Side Plate	13.88
700-0650	Right Side Plt	13.88
700-0750	Frame Assembly	36.67
700-0810	Frame Assembly	13.88
700-0930	Frame Assembly	29.17
700-0931	Frame Assembly	21.28
700-0940	Frame Assembly	18.31
700-0970	Frame Assembly	33.54
700-0971	Frame	23.41
700-0980	Frame Assembly	20.44
700-0990	Frame	11.17
700-1000	Frame	10.84
700-1010	Frame	11.32
700-1011	Clutch cam plate	0.66
700-1020	Frame	11.21
700-1050	Frame Assembly	24.66
700-1060	Frame Assembly	21.65
700-1300	Worm Shaft Assembly	5.20
700-1310	Worm Shaft Assembly	5.54

700-6010	Drive shaft retainer	0.85
700-7010	Ball bearing collar (A)	1.83
700-7170	Star Drag	14.70
700-7180	Star Drag	12.71
700-7340	Star Drag	20.91
700-7350	Star Drag	12.71
700-8211	Spool Assembly	35.71
700-8440	Handle	17.34
700-8450	Handle	28.45
700-8500	Handle	13.10
700-8510	Handle	13.43
700-8520	Handle	41.64
700-8530	Handle	51.58
700-8610	Handle Assembly	9.59
700-8620	Handle	19.89
700-8670	Handle	14.70
700-8730	Handle Assembly	14.82
700-8740	Handle Assembly	12.28
700-8760	Handle	8.59
700-8770	Handle	17.53
700-8780	Handle Assembly	28.68
700-8821	Spool Assembly	35.18
700-8940	Handle Assembly	32.49
700-9020	Yoke plate	4.41
700-9190	Spool	22.43
700-9240	Spool	22.43
700-9250	Handle	16.65
700-9260	Handle	18.04
700-9270	Handle	9.98
700-9280	Spool	37.00
700-9290	Handle	19.17
700-9350	Handle Assembly	20.23
700-9370	Handle	27.94
700-9380	Spool	37.00
700-9430	Spool	26.83
700-9440	Spool	28.68
700-9450	Spool	32.37
700-9460	Spool	37.00
700-9470	Spool	37.00
700-9520	Spool	26.59
700-9570	Spool	15.66
700-9571	Spool	15.66
700-9572	Spool	21.98
700-9610	Spool	26.59
700-9620	Spool	50.88
700-9650	Spool	37.00
700-9700	Spool Assembly	34.91

700-9710	Spool Assembly	35.57
700-9730	Spool Assembly	32.96
700-9740	Spool	36.57
700-9750	Spool	15.21
700-9760	Spool Assembly	33.46
700-9860	Spool Assembly	45.80
700-9900	Spool Assembly	52.03
700-9950	Handle Assembly	42.97
701-0000	Spool	41.64
701-1011	Yoke	4.10
701-1820	Spool Assembly	38.44
701-1830	Handle Assembly	37.31
701-1840	Handle Assembly	29.40
701-2031	Anti-reverse ratchet	2.68
701-2140	Spool Assembly	34.50
701-2200	Counter Cover	11.12
701-2250	Right Side Plate	21.48
701-2270	Spool Assembly	38.44
701-2280	Handle Assembly	46.35
701-2290	Right Side Plate	21.48
701-2300	Handle Assembly	36.63
701-2310	Left Side Plate	21.48
701-2330	Left Side Plate	21.48
701-2360	Spool Assy / Lexa-Cc400	45.80
701-2470	Counter Cover	6.77
701-2480	Left Side Plate	2.54
701-2490	Right Side Plate	21.98
701-2500	Star Drag	14.70
701-2510	Spool Assembly	25.32
701-2520	Handle Assembly	21.03
701-2530	Right Side Plate	7.97
701-2540	Star Drag	14.70
701-2720	Left Side Plate	16.85
701-2820	Line Guide	6.21
701-2830	Right Side Plate	17.12
701-2880	Right Side Plate	22.20
701-2890	Left Side Plate	18.49
701-2900	Right Side Plate	22.20
701-2910	Left Side Plate	18.49
701-2920	Spool Assembly	45.80
701-2930	Handle Assy (Pdd)	64.45
701-2940	Left Side Plate	18.76
701-2950	Gear side cover	26.15
701-2960	Right Side Plate	17.12
701-2970	Handle Assy (Pwr)	61.05
701-2980	Left Side Plate	18.76
701-3000	Line Guide	6.21

701-3010	Right Side Plate	18.49
701-3020	Spool Assembly	52.03
701-3030	Handle Assembly	67.83
701-3040	Handle Assembly	61.05
701-3050	Left Side Plate	18.49
701-3060	Right Side Plate	18.49
701-3070	Right Side Plate	18.49
701-3080	Left Side Plate	18.49
701-3630	Frame	10.84
701-3640	Right Side Plate	13.84
701-3650	Star Drag	3.06
701-3660	Spool Assembly	15.66
701-3670	Right Side Plate	13.84
701-3680	Frame	10.84
701-3690	Left Side Plate	13.84
701-3700	Star Drag	3.06
701-4010	Key washer (B)	1.83
702-1750	Frame	48.89
702-1770	Spool assembly	53.83
702-1780	handle assembly	63.64
702-1800	Right side plate	27.20
702-1810	RIGHT SIDE PLATE	27.20
702-1820	Frame	48.89
702-1830	Left side plate	27.20
702-1850	Frame	46.69
702-1860	Right side plate	26.47
702-1870	Handle assembly	50.12
702-1880	SPOOL ASSY	42.03
702-1890	Left side plate	11.76
702-1900	Right side plate	26.47
702-1910	R/S PLATE	14.76
702-1920	Frame	46.69
702-1930	Left side plate	26.47
702-1940	Right side plate	11.76
702-2520	Line guide	5.11
703-3010	Bearing washer (C)	0.50
703-4011	Pinion gear	22.55
704-3010	Anti-reverse pawl pin	1.70
704-9011	Key washer (A)	3.18
705-0020	Screw (E)	0.50
705-3011	Screw (C)	0.98
705-5012	Nut	3.69
705-6010	Drag spring washer	1.35
706-4011	Clutch cam spring	0.50
706-5011	Pin	1.83
706-7011	Screw (D)	0.50
706-8010	Screw (D)	3.91

706-8011	Screw (A)	3.91
706-9010	Clutch lever washer (A)	0.50
707-5010	Clutch cam	5.36
708-5011	Yoke spring	0.50
709-1011	Washer (E)	0.50
709-1031	Washer (H)	0.50
709-1051	Washer (G)	0.50
709-2010	Click leaf spring holder	0.98
709-5010	Bearing retainer (A)	0.50
709-7010	Frame plate screw (B)	0.50
709-8010	Washer (C)	0.50
709-9010	Washer (B)	0.50
710-0011	Anti-reverse pawl	4.73
710-5011	Bearing washer (B)	0.50
711-1010	Clutch lever washer (B)	0.50
711-2010	Bearing retainer (B)	0.50
711-2213	Main Shaft	6.08
711-3010	"O"ring (B)	0.50
711-5010	Washer (E)	0.57
711-5201	Main Shaft	11.03
711-5301	Main Shaft	10.87
711-5702	Main Shaft	3.87
711-5802	Main Shaft	5.76
711-6010	"O"ring (C)	0.50
711-7010	Spring	0.82
711-9011	Handle collar (B)	2.84
714-7010	Drag washer (A)	4.10
715-1011	Handle collar (A)	0.50
715-6010	Click leaf spring (B)	0.98
716-9080	Frame plate	11.34
716-9090	Frame plate	11.34
716-9100	Frame plate	11.34
717-9020	Yoke plate	5.51
718-3010	Yoke spring	0.50
718-4010	Anti-reverse pawl pin	2.21
718-6020	Anti-reverse ratchet	4.88
718-8010	Drag washer (A)	0.63
720-1010	Bearing retainer (B)	0.50
720-1331	Spool Metal	4.35
720-1721	Spool Metal	5.42
720-2010	"O"ring (B)	0.50
720-7010	Screw (G)	0.98
720-7020	Screw (F)	0.98
720-9010	Screw (A)	0.50
721-0010	Drag spring washer	1.42
721-1020	Star drag	19.07
721-5010	Nut	2.84

721-9010	Key washer (A)	3.15
722-0010	Drag washer (C)	9.45
722-1010	Eared washer	2.52
724-4010	Click gear	2.21
725-0010	Washer (F)	0.57
725-1011	Click button	5.10
725-1021	Click button	5.10
725-2010	Click plate	0.50
725-3010	Click collar	0.50
725-6010	"O"ring (A)	2.43
725-7010	"O"ring (A)	1.51
725-8512	Bail	2.58
725-8702	Bail	3.14
725-8802	Bail	2.58
729-6010	"O"ring (D)	0.79
731-6030	Click button washer (C)	0.50
731-6040	Click button washer (B)	0.50
734-3212	Spool	5.37
734-3412	Spool	5.99
734-3612	Spool	4.18
734-7002	Spool	12.12
734-7702	Spool	10.13
734-7902	Spool	14.35
735-1010	Pinion gear	18.45
736-7601	Rotor	3.20
736-7801	Rotor	4.69
736-8001	Rotor	3.59
740-3311	Drag Knob	2.55
740-3801	Drag Knob	3.24
740-4501	Drag Knob	2.87
742-0040	Clamp bolt	2.84
744-3010	Brake collar (A)	1.45
744-5010	Click pawl	1.26
744-7010	Click spring	2.21
744-8010	Click spring	2.52
747-2502	Handle Stand	3.37
747-8202	Handle	4.45
748-2010	Frame assembly	38.13
748-4010	Spool assembly	38.66
748-8010	Set plate	6.62
749-1010	Drive gear	18.45
749-2010	Drag washer (B)	3.78
749-3010	Key washer (C)	5.67
749-5010	Right side plate	28.29
749-5020	Right side plate	28.29
749-5030	Right side plate	28.29
749-7010	Clutch lever (A)	5.67

749-9010	bearing	1.73
750-0010	Cast control cap	4.88
750-0411	Osc Gear	2.55
750-1010	Handle assembly	29.73
751-0010	Set plate	7.25
751-1010	Right side plate	29.73
751-1020	Right side plate	34.85
751-1030	Right side plate	34.85
751-6010	Drive shaft	16.38
751-7010	Screw (B)	0.50
751-8010	Bearing retainer (A)	0.50
752-1010	Spool assembly	40.59
752-4010	Spool assembly	42.64
753-4010	Drive gear	22.55
753-6010	Key washer (D)	9.83
753-9010	bearing (D)	1.76
754-0010	Cast control cap	4.88
754-1010	Screw (F)	0.50
754-2010	Handle assembly	37.93
754-4011	Drive shaft	21.42
754-6011	Spool assembly	47.77
755-2011	Spool assembly	49.20
755-2203	Front Cover	6.33
755-2303	Front Cover	5.01
755-2403	Front Cover	6.71
757-4040	Bearing washer (A)	0.50
758-5010	Washer (A)	0.50
770-0301	A/R Claw	1.29
780-9103	Bail Screw	1.80
781-6319	Push Button	1.45
781-6320	Push Button	1.04
781-6519	Push Button	0.91
782-9932	Osc Plt	5.04
AG-SAS10	Daiwa AG-SAS10 AGS Single Leg Guide	21.11
AG-SAS12	Daiwa AG-SAS12 AGS Single Leg Guide	23.94
AG-SAS20H	Daiwa AG-SA20H AGS Single Leg Guide	43.97
AG-SAS6	Daiwa AG-SAS6 AGS Single Leg Guide	9.86
AG-SAS8	Daiwa AG-SA8 AGS Single Leg Guide	14.77
AG-SAZ16	Daiwa AG-SAZ16 AGS Single Leg Guide	26.37
AG-SAZ25H	Daiwa AG-SAZ25H AGS Single Leg Guide	48.57
AG-WAS10	Daiwa AG-WAS10 AGS Double Leg Guide	29.55
AG-WAS12	Daiwa AG-WAS12 AGS Double Leg Guide	23.94
AG-WAS8	Daiwa AG-WAS8 AGS Double Leg Guide	21.80
B00-8601	A/R Pawl Screw	0.50
B00-8602	L/S Cover Screw	0.50
B00-9701	Side Cover Screw	0.50
B00-9702	R/S Cover Screw	0.63

B01-4002	Bail Spring Cover	0.50
B02-0702	Click Gear	0.50
B03-2904	Screw	0.50
B03-2905	Screw	3.18
B03-4803	Handle Screw Cap	0.72
B05-5201	Spool Adj. Cap O'ring	0.72
B06-0205	Spool	19.25
B06-0405	Spool	32.37
B07-5302	Spool Click Pawl	0.50
B07-8201	Spool Click Claw	0.50
B09-1401	A/R Cam Spring	0.50
B09-4401	Drag Adj Dial	0.50
B09-5601	Ball Bearing Ret	0.50
B10-0801	Ratchet	1.04
B10-3802	SPOOL SHAFT BEARING	1.02
B10-5701	Rotor Nut	0.50
B12-0201	Drive Shaft Washer	0.50
B12-8201	Oscillating Slider Screw	0.50
B14-1802	Bail Kick Lever Cover	0.82
B15-6403	A/R Cam	1.39
B17-5401	Cap Metal Washer	0.50
B17-5402	Spool Adj Cap Metal	0.50
B17-5406	Spacer F	0.72
B17-5503	Cap Rubber Washer	0.72
B18-1601	Ball Bearing	6.21
B18-1602	SPOOL SHAFT BALLBEARING(A)	14.06
B18-4401	Bail Spring	0.50
B18-4701	Bail Kick Lever Spring	0.50
B18-5003	Bail	1.31
B18-7701	Bail Spring	0.50
B18-8302	Bail	2.46
B20-9301	Click Pawl	0.50
B21-1801	Bail Spring	0.50
B21-5801	Cog Wheel	0.54
B21-6601	Click Button	0.50
B21-6602	Click Button	1.76
B21-6701	Click Gear	0.95
B22-4501	Handle Screw Cap	0.82
B22-9901	Cam Kick Plt	0.82
B24-1601	A/R Claw	2.27
B27-0501	Ball Bearing Ret	0.50
B27-0703	Drag Screw Washer	0.50
B27-0706	Drag Adjusting Washer	0.50
B27-0707	Drag Washer	0.50
B27-2901	A/R Claw Spring	0.50
B28-6601	Click Gear	1.45
B28-6701	A/R Claw	2.55

B31-7501	Body Cover	3.38
B31-7502	Body Cover	2.85
B31-7601	Main Shaft	3.87
B31-7801	Bail Kick Lever Cover	0.82
B31-7901	Rotor	4.69
B31-8101	Rotor	3.53
B31-8401	Bail Kick Lever Cover	0.60
B31-8501	Bail Spring Cover	0.50
B31-8903	Body	6.56
B31-9201	Body Cover	3.14
B31-9505	Body	9.41
B31-9701	Body Cover	6.33
B31-9901	Body Cover	4.49
B32-0201	Bail Spring Cover	1.10
B32-0901	Bail Kick Lever	1.29
B32-1701	Cam Kick Plt	0.82
B32-1801	Bail Kick Lever	1.45
B33-5301	Main Shaft	1.29
B33-5401	Body Cover	2.50
B33-5601	A/R Claw	1.45
B33-7501	Pinion Yoke	0.60
B33-7601	Pinion Yoke Spring	0.50
B33-9801	Ret	0.50
B35-2701	Brake Collar	0.50
B35-2801	Brake Collar B	0.50
B35-2901	Brake Collar	0.50
B35-8601	Ball Bearing	6.77
B35-8605	Ball Bearing	9.64
B35-8607	Ball Bearing	8.66
B35-8608	Gear Shaft Ball Bearing	6.36
B35-8701	Ball Bearing Retainer	0.72
B35-8702	Bearing Retainer	0.66
B36-0204	Drag Washer	0.72
B36-0212	Drag Washer A	8.00
B36-0301	Key Washer	0.50
B36-0302	Drag Disc Washer	0.50
B36-0306	Key Washer B	3.37
B36-0308	Key Washer (B)	2.05
B36-0405	CLUTCH CAM PLATE SCREW	0.50
B37-9703	Pinion Gear	4.00
B38-0201	Handle	14.76
B40-5401	Line Roller	1.07
B40-5501	Roller Bushing	1.07
B41-1701	Washer	0.50
B41-1702	Worm Shaft Holder Washer	0.50
B41-1703	Washer (0.1Mm)	0.50
B41-1706	Worm Shaft Washer	0.50

B41-1711	Motor Gear (B) Washer	0.66
B41-3001	Line Roller Bushing	0.72
B42-1601	Ball Bearing Retainer	0.50
B43-3603	Handle Nut	1.01
B43-5701	Pinion Holder	0.50
B45-1501	Roller Collar	0.69
B45-6402	Ball Bearing Ret Washer	0.50
B53-6101	R/S PLATE SCREW (B) WASHER	0.50
B53-6103	Worm Shaft Washer	0.66
B54-6001	Ball Bearing	8.00
B54-6002	Ball Bearing A	22.02
B54-6401	Bearing	3.09
B55-0301	Bushing	0.50
B55-3801	Ball Bearing Washer	0.50
B55-3802	Spacing Sleeve	0.72
B55-3803	Washer E	0.50
B55-4301	Line Roller Washer	0.50
B55-4302	Idle Gear (B) Washer	2.68
B55-7601	Screw	0.50
B55-7605	Drag Metal Screw	0.50
B55-7606	Sensor Screw (A)	0.50
B55-7607	Set Plate (B) Screw	0.66
B56-4801	ARM LEVER	2.05
B61-7503	A/R Cam	3.34
B61-8002	Ratchet	2.99
B61-8801	Click Spring	0.50
B62-6801	Anti Reverse Claw	0.54
B62-8601	Ball Bearing	7.56
B62-9101	Click Spring	1.67
B63-0401	Collar	1.01
B63-7903	A/R Cam	2.68
B65-2302	KEY WASHER	1.73
B65-6201	Cog Wheel Collar	0.50
B66-2601	Handle Nut Plate	1.29
B67-9305	Line Roller Screw	0.63
B67-9308	Line Roller Screw	0.79
B68-4402	Drag Washer C	0.50
B71-3301	Handle	8.92
B71-3401	Handle	8.34
B71-3501	Handle	16.44
B71-3601	Handle	11.40
B71-5601	Worm Shaft Holder	0.50
B73-1501	Bail Arm	0.50
B73-8001	Bushing	1.61
B74-5501	A/R Claw	1.45
B74-7701	Spring	0.50
B74-7702	Spring	0.50

B83-4402	Screw	0.50
B83-5002	Side Cover Screw	0.50
B83-6301	A/R Pawl Screw	0.50
B84-2101	Screw	0.50
B85-0801	Handle Collar	0.50
B85-3101	O Ring	0.50
B86-1301	POWER LEVER HOLDER COLLAR	1.02
B86-1702	Ball Bearing	6.49
B86-1703	Ball Bearing	4.60
B86-1704	Ball Bearing	10.11
B86-1705	Ball Bearing (C)	5.42
B86-2102	Handle Nut	0.88
B86-2301	Handle Nut Plate	0.72
B86-4101	Ret	0.50
B88-4701	Handle Nut Plate	0.50
B88-4703	Handle Nut Plate	6.02
B88-7801	Ball Bearing	36.26
B90-3003	A/R Pawl	1.04
B90-3301	Handle Screw	0.50
B91-1730	R/S Plt Screw	0.82
B91-1731	R/S Plt Screw	0.60
B93-3001	Screw	0.66
B93-3002	Screw	0.50
B93-7802	Clamp Bolt Washer	0.72
B93-9601	Spool Tension Spring	0.50
B93-9702	Cast Control Cap	2.14
B95-8402	Drag Knob	2.58
B96-5204	A/R Lever	1.04
B96-5301	A/R Pawl Plt	0.57
B96-5501	A/R Pawl Collar	0.57
B96-5601	A/R Pawl Spring A	0.50
B96-5701	Pinion Holder	0.50
B97-9801	Line Roller Collar	0.50
B99-5101	Rotor Nut Holding Plt	0.50
CR2032	Lithium Battery	4.98
DCH100PADB	100Mm Custom Reel Handle	49.95
DCH100PADG	100Mm Custom Reel Handle	49.95
DCH100PWRB	100Mm Custom Reel Handle	49.95
DCH100PW RG	100Mm Custom Reel Handle	49.95
DCH100WINN	100Mm Custom Power Handle	49.99
DCH90WINN	100Mm Custom Paddle Handl	49.99
DCHKWINN	Winn Grip Power Knob	25.80
DSG101	Reel Repair Grease 2.5	79.79
DSO-3062	Magnetic Fluid P306	30.96
E00-4301	Ic Module Cover Screw	0.50
E00-7602	Screw	0.50
E02-7401	Screw	0.50

E03-3201	Brake Adj Knob Spring	0.50
E03-7704	YOKE	0.50
E03-7706	Yoke Washer	0.50
E08-8005	Bearing	9.58
E09-4401	A/R Pawl Screw	0.50
E09-6501	Rotor Washer	0.57
E09-6504	Idle Gear Washer	0.57
E10-7401	Screw	0.50
E11-3802	Rotor	5.19
E11-4002	Side Cover	3.05
E11-4501	Bail Kick Knock	3.59
E11-4607	Bail Kick Roller	1.45
E11-4701	Bail Kick Roller Collar	1.45
E11-4801	Bail Kick Roller Pin	0.57
E11-4901	A/R Cam	0.60
E11-5001	A/R Lever	1.29
E11-5101	Pinion Gear	5.21
E11-5203	Osc Slider	2.87
E11-5401	Worm Shaft	7.21
E11-5501	Worm Shaft Gear	2.30
E11-5601	Worm Shaft Retainer	0.50
E11-5701	Drive Gear	11.13
E11-5801	Bail Spring Shaft	1.20
E11-6101	Bail Arm Screw	0.72
E11-6201	Bail Trip Cover	0.50
E11-6501	Main Shaft	7.69
E11-6801	Osc Slider Cover	1.07
E11-6902	Rear Cover	3.75
E11-9601	Screw	0.50
E11-9602	Side Cover Screw A	0.95
E12-1102	Side Cover	1.95
E12-1306	Rotor	7.24
E12-1402	Drag Knob	8.25
E12-2101	Worm Shaft Bush	0.50
E12-2201	Worm Shaft Collar	1.39
E12-2301	Click Leaf Spring Holder	1.42
E12-2403	Osc Pawl	3.43
E12-2801	Drag Knob Click Plt	3.59
E12-3202	Side Cover	3.20
E12-3701	Bail Kick Knock	3.97
E12-4001	Pinion Gear	5.37
E12-4101	Worm Shaft Gear	2.14
E12-4201	Worm Shaft Bushing	0.50
E12-4303	Osc Slider	2.87
E12-4401	Worm Shaft	7.21
E12-4501	Drive Gear	8.75
E12-4601	Osc Pawl Bush	1.20

E12-4701	Bail Spring Shaft	1.01
E12-4801	Bail Spring	0.50
E12-4901	Bail Arm	1.45
E12-5001	Bail Arm Screw	0.57
E12-5302	Bail Trip Cam Screw	1.07
E12-5401	Main Shaft	5.42
E12-5703	Osc Pawl	7.21
E12-5801	Osc Pawl Bush	0.50
E12-5901	Osc Slider Cover	0.82
E12-6002	Rear Cover	2.99
E12-6802	Drag Knob	7.75
E12-9401	Bail Kick Knock	2.02
E12-9501	Pinion Gear	0.90
E13-0101	Worm Shaft	6.68
E13-0201	Drive Gear	6.81
E13-0301	Bail Trip Cover	0.57
E13-0401	Side Cover Screw	0.50
E13-0501	Side Cover Screw	0.50
E13-0602	Rotor	5.56
E13-0701	Bail Spring	0.50
E13-1001	Main Shaft	2.39
E13-1402	Rear Cover	2.39
E13-2101	Click Pawl	0.50
E13-2202	Drag Knob	6.21
E13-4501	Screw	0.50
E13-4503	Screw	1.48
E13-4505	Plate Screw	0.50
E13-4508	Screw	0.72
E13-4509	Screw	0.66
E13-4511	Bearing Ret Screw	1.01
E13-5901	Spool Washer	0.57
E13-6001	Drag Washer	0.57
E13-6102	Key Washer	1.20
E13-6201	Eared Washer	0.50
E13-6301	Drag Knob Click Plate	0.82
E14-4801	Worm Bearing	0.50
E14-6503	Spool Washer	0.50
E14-6703	A/R Cam Spring	0.50
E15-0101	Eared Washer	1.10
E15-0205	Osc Slider Cover Screw	0.50
E15-0502	Worm Shield Cover	3.69
E15-0602	Worm Shield Cover	2.17
E15-1102	WORM SHIELD COVER	0.98
E15-1802	Drive Gear	9.78
E15-3701	Handle	11.28
E15-3801	Handle	11.99
E15-3901	Handle	8.08

E15-4001	Ball Bearing	8.28
E15-4801	Washer	0.50
E15-4803	DRIVE BEARING (B) WASHER	0.68
E15-7502	Screw	0.50
E16-7101	Spring	0.50
E16-9504	Line Holder	0.50
E17-5504	Handle	11.50
E17-5802	Ball Bearing	28.41
E18-2801	Ball Bearing	5.45
E18-7101	Worm Shaft Ret	0.50
E18-7401	Osc Slider Cover	0.57
E18-8401	Bail Arm	0.60
E19-0110	Body	11.28
E19-0201	Bail Kick Knock	2.87
E19-0401	A/R Cam	3.75
E19-0502	Pinion Gear	6.58
E19-0603	Osc Slider	3.24
E19-0801	Worm Shaft	2.87
E19-0901	Worm Shaft Bush	0.50
E19-1001	Worm Shaft Gear	1.80
E19-1101	Worm Shaft Collar	1.80
E19-1202	Osc Pawl	5.04
E19-1301	Osc Pawl Bush	1.61
E19-1403	R/S Cover	1.80
E19-1603	Drive Gear	6.62
E19-1703	Side Cover	3.53
E19-1803	Rear Cover	4.57
E19-2002	Rotor	6.23
E19-2101	Bail Trip Cover	0.50
E19-2702	Spool	27.65
E19-9401	Drive Shaft Ret	0.72
E20-0201	Key Washer	1.23
E20-0801	A/R Ratchet	0.88
E20-0902	Drag Knob	6.08
E21-8801	Handle	6.46
E21-9701	Ret	0.50
E22-5001	Line Roller	2.02
E22-5101	Line Roller	3.24
E22-5501	Bail Trip Cam Screw	1.32
E22-5602	Bail	4.69
E22-5702	Bail	4.35
E22-5902	Bail	4.12
E22-8001	Main Shaft	7.28
E23-4201	A/R Pawl Spring	0.50
E24-1801	Counter Plate	0.76
E24-1901	Counter Gear	1.76
E24-6101	Spool Click Leaf Washer	0.50

E24-7806	Counter Lens	13.39
E24-8101	Rotor Nut Holding Plt Scr	0.50
E24-9803	Clutch Lever	2.87
E24-9808	Clutch Lever	1.29
E25-2102	Yoke	1.10
E25-2301	Anti Reverse Claw Pin	0.50
E25-2501	Drive Shaft Bushing	0.50
E25-2601	Drive Shaft	2.84
E25-2801	A/R Ratchet	0.88
E25-2903	A/R Ratchet	2.17
E25-3301	Ball Bearing Collar B	0.50
E25-3501	Drag Spring Washer	0.50
E25-3601	Star Drag	4.25
E25-3602	Star Drag	9.01
E25-3901	Spacing Sleeve	0.88
E25-9101	Yoke	1.23
E26-2101	A/R Pawl Collar	0.60
E26-2701	A/R Ratchet	0.60
E26-4302	Oscillating Slider Cover	1.04
E26-7501	Main Shaft Washer	0.66
E27-2501	Washer	0.57
E27-7001	A/R Pawl	0.91
E27-8602	A/R Pawl Spring B	1.07
E28-6001	Line Holder	0.98
E28-6003	Line Holder	0.50
E29-0601	Yoke	1.17
E29-2701	Idle Gear Ball Bearing	22.71
E29-2702	Ball Bearing	32.10
E29-3001	Magnet Set Plate Screw	0.50
E30-6801	Ball Bearing	7.06
E31-3901	Bail Spring Washer	0.50
E31-5401	Cast Control Cap	2.33
E31-5408	Cast Control Cap	7.09
E31-5501	Clutch Cam	3.59
E31-6001	Stabilizer Bar	1.45
E31-6003	Stabilizer Bar	1.54
E31-6004	Stabilizer Bar	3.34
E31-6101	Yoke Plt	0.69
E31-6201	Pinion Gear	7.05
E31-6401	A/R Pawl	0.66
E31-6502	A/R Pawl Spring	0.50
E31-6601	Drive Shaft	8.28
E31-6701	Drive Shaft Ret Screw	0.50
E31-6801	Drive Gear	11.13
E31-6901	Drag Washer A	0.72
E31-7001	Key Washer A	0.98
E31-7101	Eared Washer	1.29

E31-7201	Key Washer B	1.29
E31-7301	R/S Outer Ring	2.99
E31-7304	R/S Outer Ring	10.33
E31-7401	L/S Plt Screw	0.50
E31-8001	Ball Bearing Collar A	0.57
E31-8201	Left Side Outer Ring	7.69
E31-8204	L/S Outer Ring	8.25
E31-8301	Rod Clamp	3.97
E31-8401	Rod Clamp Screw	0.66
E32-2301	Clutch Spring	0.50
E32-5503	Drag Washer	4.16
E32-6301	Spacing Sleeve	0.50
E32-6401	Spacing Bushing	0.63
E32-6501	Drag Washer B	0.88
E32-6601	Bearing Washer A	0.50
E32-6701	Bail Spring Shaft	1.20
E32-6702	Bail Spring Shaft	4.35
E32-6902	Bail	3.75
E32-7702	A/R Ratchet	1.29
E33-2101	Pinion Holder	0.50
E33-2501	Ball Bearing	8.38
E33-9701	Washer B	0.50
E34-4501	Bail Spring	0.50
E34-5208	L/S Plt	11.30
E34-5210	L/S Plt	11.30
E35-1501	Bushing B	0.79
E35-4101	Pawl Cap	1.04
E36-1101	Yoke	1.01
E36-1301	Click Button	2.99
E36-1402	Click Spring Washer	0.50
E36-2401	Line Guide	7.81
E36-4202	Screw	0.50
E39-5302	Drive Gear	2.83
E39-8002	Spool Washer	0.50
E39-8003	Spool Washer (C)	0.50
E39-9201	Spool Washer A	0.50
E40-2901	O Ring	4.38
E40-4601	Stabilizer Bar	1.01
E40-4604	Stabilizer Bar	1.80
E42-5302	Drive Shaft Washer B	0.50
E42-6805	Clutch Lever	0.88
E43-2822	Bail Spring Cover	3.72
E44-0001	Handle Nut Plate	0.88
E44-0004	Handle Nut Plate	0.50
E44-2501	Drag Washer Retainer	0.50
E45-3901	Ball Bearing	7.09
E45-4003	A/R Pawl Screw	0.72

E45-4007	Screw B	0.95
E46-5402	Right Side Plate Screw	2.30
E46-7101	Washer	0.60
E46-7201	Key Washer	0.50
E48-9001	A/R Pawl	2.87
E48-9503	Drive Shaft Washer	1.01
E48-9621	Brake Adj Knob	6.14
E48-9622	Brake Adj Knob	0.76
E49-2001	Screw	0.50
E49-2101	Handle Screw	0.50
E49-4801	A/R Claw	2.02
E51-0913	R/S Plt	4.31
E52-7805	Frame	8.18
E52-9201	Osc Plt	5.51
E54-1101	Worm Shaft	6.62
E54-1301	Body	10.97
E54-1302	Body	7.91
E54-1401	Body	8.08
E54-1402	Body	9.41
E55-3801	Spool	7.32
E57-1301	Clutch Spring	0.50
E57-1401	Clutch Cam	0.72
E57-1502	Clutch Lever	0.63
E57-1801	COUNTER	1.58
E57-2101	Counter Gear	1.76
E57-2201	Counter Gear	1.07
E57-2901	Ball Bearing	16.82
E57-3101	Line Guide	7.47
E57-3102	Line Guide	10.80
E57-3301	Worm Shaft	8.88
E57-3302	Worm Shaft Assembly	10.14
E57-3601	Worm Bearing	1.48
E57-3801	Counter Gear	0.54
E57-4001	Line Guide Pawl	3.81
E57-4101	Pawl Cap	1.07
E57-4102	Pawl Cap	7.97
E57-4601	Yoke Spring	0.50
E57-4701	Pinion Gear	5.56
E57-4801	Pinion Gear	4.86
E57-5001	A/R Pawl Pin	0.54
E57-5101	A/R Pawl	3.84
E57-5201	A/R Pawl Spring	0.50
E57-5401	Drive Shaft	2.14
E57-5501	Drive Shaft Retainer	1.73
E57-5602	A/R Ratchet	0.88
E57-6001	Drive Gear	9.72
E57-6101	Drag Washer	0.88

E57-6102	Drag Washer	4.25
E57-6201	Key Washer A	2.24
E57-6501	Spacer B	1.01
E57-6601	Spacing Sleeve A	0.88
E57-6701	Bearing	0.76
E57-6803	Right Side Outer Ring	8.88
E57-6901	Star Drag	6.39
E57-7104	Side Plt L	8.45
E57-7105	Left Side Plt	3.46
E57-7401	Click Spring	2.27
E57-7501	Click Button	1.76
E57-7502	Click Button	1.76
E57-7601	Idle Gear	0.54
E57-8301	Click Lever Washer	0.50
E57-8401	Spool Gear	2.14
E57-8503	Left Side Outer Ring	8.88
E57-9901	Click Pawl	0.50
E59-1601	R/S Plt Screw	0.95
E59-1602	Screw (E)	0.95
E59-8901	Bushing	1.80
E60-4502	Left Side Plate	34.69
E60-5101	Spacing Sleeve	6.39
E60-8801	Bushing	0.50
E60-8901	Bearing Washer	0.50
E61-0501	Bearing Washer	0.50
E61-0502	Washer C	0.50
E61-0601	Click Spring	1.73
E61-0701	Roller Clutch Sleeve	10.87
E61-0702	Collar	5.67
E61-0902	Cast Control Cap	4.06
E61-1001	Click Pawl	1.70
E61-1101	Clutch Cam Spring	0.63
E61-1301	Pinion Gear	6.13
E61-1401	Drive Gear	12.14
E61-5101	Yoke Washer	0.50
E61-7301	Click Button Washer	0.50
E61-7302	Click Button Washer	0.57
E61-7401	Click Button Washer	0.50
E61-7402	Washer E	0.57
E61-7403	Washer	0.50
E61-7601	Clutch Cam	2.24
E61-9501	Handle	5.43
E61-9801	Spool	17.63
E62-0001	Right Side Plate Screw	0.50
E62-1301	Counter	12.44
E62-1602	Star Drag	28.86
E62-2302	Left Side Plate	31.22

E62-2601	Drive Shaft Retainer	2.11
E62-2701	Yoke Plate	2.36
E62-2702	Yoke Plate	4.82
E62-2801	Pinion Gear	5.78
E62-2901	Drive Gear	10.97
E62-3002	Drag Washer	6.21
E62-3101	Key Washer	1.67
E62-3201	Eared Washer	1.58
E62-3601	Clutch Lever	9.23
E62-3603	Clutch Lever	9.23
E62-3801	Star Drag	16.93
E62-3804	Star Drag	24.05
E62-4401	Rod Clamp	2.84
E62-4402	Rod Clamp	3.02
E62-4501	Clamp Bolt	2.43
E62-4601	Click Spring	1.89
E62-4701	Click Button	4.22
E62-4801	Click Pawl	0.63
E62-4901	Yoke	2.05
E62-4902	Yoke	5.67
E62-5001	Anti Reverse Ratchet	2.90
E62-5101	Drag Washer	0.50
E62-5401	Clutch Lever Collar	1.70
E62-5501	Clutch Cam Spring	0.76
E62-5601	Click Spring Retainer	3.12
E62-6101	Clamp Nut	4.44
E62-6701	Clutch Cam	0.88
E62-7202	Screw	0.50
E62-7203	Screw	0.50
E62-7301	Key Washer	5.67
E62-7401	Frame	59.61
E62-7801	Spool	52.95
E62-8201	Spool Gear	4.25
E62-8501	Left Side Plate	27.76
E62-8601	Click Spring Retainer	2.24
E62-8701	Idle Gear	1.76
E62-9001	Worm Shaft Asembly	19.18
E62-9301	Worm Shaft Washer	0.50
E62-9401	Level Wind Guard	4.95
E62-9901	Stabilizer Bar(A)	4.06
E62-9902	Stabilizer Bar A	5.10
E63-0101	Stabilizer Bar	4.06
E63-0102	Stabilizer Bar B	5.10
E63-0201	Gear Shaft	17.33
E63-0401	Drag Washer	6.08
E63-0402	Drag Washer	0.66
E63-0601	Right Side Plate	72.43

E63-0602	Right Side Plate	78.45
E63-0604	Right Side Plate	63.39
E63-0801	Handle	31.94
E63-1801	Frame	63.90
E63-2001	Spool	56.72
E63-2301	Worm Shaft	37.55
E63-2501	Level Wind Guard	5.39
E63-2601	Stabilizer Bar(A)	4.50
E63-2602	Stabilizer Bar A	5.67
E63-2701	Stabilizer Bar(B)	4.50
E63-2702	Stabilizer Bar B	5.67
E63-2901	Rigt Side Plate	72.43
E63-3301	Roller Clutch	4.85
E63-3401	Clutch Lever	9.23
E63-3402	Clutch Lever	9.23
E63-3701	Star Drag	31.26
E63-4101	Handle	27.39
E63-4201	Click Button	5.20
E63-4202	Click Button	7.97
E63-4301	Right Side Plate Screw	0.66
E63-4302	Right Side Cover Screw	0.60
E63-4501	Key Washer	4.25
E63-4601	Yoke Plate	7.65
E63-4701	Frame	51.09
E63-4702	Frame	55.31
E63-4901	Spool	45.61
E63-5101	Left Side Cover	25.44
E63-5102	Left Side Plt	30.07
E63-5201	Click Spring Washer	2.24
E63-5301	Click Button	3.91
E63-5302	Click Button	7.97
E63-5401	Idle Gear	1.61
E63-5501	Worm Shaft Asembly	17.77
E63-5701	Level Wind Guard	3.02
E63-5801	Stabilizer Bar	2.43
E63-5802	Stabilizer Bar A	5.10
E63-5901	Stabilizer Bar	2.43
E63-5902	Stabilizer Bar B	5.10
E63-6001	Drive Shaft	16.54
E63-6101	Yoke Plate	7.21
E63-6201	Anti Reverse Ratchet	2.58
E63-6401	Right Side Plate	34.69
E63-6402	Right Side Plate	69.19
E63-6403	Right Side Plate	69.19
E63-6601	Handle Assembly	16.65
E63-7001	Frame	55.35
E63-7002	Frame	57.09

E63-7201	Spool	49.36
E63-7501	Worm Shaft	18.49
E63-7701	Level Wind Guard	5.17
E63-7801	Stabilizer Bar(A)	2.49
E63-7802	Stabilizer Bar A	5.10
E63-7901	Stabilizer Bar(B)	4.06
E63-7902	Stabilizer Bar B	5.10
E63-8101	Right Side Plate	63.90
E63-9501	Click Button	5.10
E63-9601	Click Button Plate	1.13
E63-9701	Click Pawl	2.27
E64-0101	Collar	5.04
E64-0201	Click Spring	1.13
E64-0301	Frame Plate	7.69
E64-0501	Spool	51.43
E64-0701	Drag Washer	0.66
E64-0801	Spool Shaft	12.79
E64-1101	Frame	69.19
E64-1201	Drag Spring Washer	1.13
E64-1301	Spring	1.13
E64-1401	Drive Shaft Retainer	0.60
E64-1501	Screw	1.29
E64-1502	Screw	1.29
E64-1601	Drive Shaft Pin	0.79
E64-1701	Right Side Plate	32.37
E64-1702	Right Side Plate	64.58
E64-1703	Right Side Plate	64.58
E64-1707	Right Side Plate	32.37
E64-1708	Right Side Plate	32.37
E64-1801	Drive Shaft B	56.01
E64-1901	Drive Shaft Pin	22.18
E64-2001	Drive Shaft Spring	1.70
E64-2101	Drive Shaft Screw	8.54
E64-2201	Drive Gear Collar A	1.70
E64-2301	Drive Gear A	17.34
E64-2401	Drive Gear Collar	2.84
E64-2501	Drive Gear B	16.65
E64-2601	Drive Gear Collar	1.70
E64-2701	Drive Shaft Nut	12.22
E64-2801	Pinion Gear A	8.10
E64-2901	Pinion Gear B	9.72
E64-3001	Drag Plate	54.39
E64-3401	Drag Ratchet	5.39
E64-3501	A/R Claw	0.72
E64-3701	A/R Pawl Retainer	2.52
E64-3801	Screw	0.63
E64-3902	Spring	1.10

E64-4001	Pin	0.88
E64-4101	Washer B	0.50
E64-4301	Collar A	0.63
E64-4501	Screw	0.50
E64-4502	Screw F	0.50
E64-4503	Screw (G)	0.50
E64-4601	Drag Lever	64.58
E64-5001	Drag Lever Plate	1.07
E64-5201	Pin	1.61
E64-5301	Pre-Set Cam	13.36
E64-5501	Pre-Set Cam	16.76
E64-5601	Pre-Set Drag Knob	1.95
E64-5602	Pre-Set Drag Knob	5.36
E64-5701	Pre-Set Click Spring	2.84
E64-5801	Drag Knob Spring	1.70
E64-5901	Collar B	15.06
E64-6001	Handle	41.64
E64-6601	Handle Knob	24.40
E64-7001	O Ring	0.76
E64-7101	Screw	6.36
E64-7201	Drive Shaft Spring	1.70
E64-7301	Handle Screw	13.64
E64-7401	Handle Button	7.97
E64-7601	Handle Cap	4.82
E64-7701	Spring	0.50
E64-7801	Plate	5.39
E64-7901	Handle Lever	17.92
E64-8201	Handle Cap	13.92
E64-8401	Frame	73.82
E64-8601	Spool	55.31
E64-8801	Spool Shaft	13.64
E64-9101	Drive Shaft B	53.17
E64-9201	Drive Shaft Pin B	2.27
E64-9301	Washer	1.13
E64-9401	Drive Gear	15.83
E64-9501	Drive Shaft Nut	3.69
E64-9801	Drag Lever	49.74
E65-0001	Handle	41.64
E65-0601	Idle Gear	1.61
E65-0701	Yoke Plate	7.65
E65-1201	Collar A	0.50
E65-1401	Spring A	0.63
E65-1501	Anti-Reverse Ratchet	2.58
E65-2001	Star Drag	33.87
E65-2501	Counter Cover	30.71
E65-3501	Idle Gear	4.60
E65-3601	Yoke Plate	8.35

E65-4001	Anti-Reverse Ratchet	5.39
E65-4301	Spool	50.70
E65-4401	Clutch Lever	18.49
E65-4501	Handle	16.65
E65-4801	Bushing B	1.70
E65-4901	Spool	54.57
E65-5001	Spool	58.65
E65-5201	Clutch Lever	9.23
E65-5301	Star Drag	33.87
E65-5401	Handle	34.60
E65-5402	Handle	34.60
E65-5501	Spring A	1.98
E65-5801	Spool	62.53
E65-6201	Washer D	0.85
E65-6501	Click Spring	0.54
E65-6502	Click Spring	5.04
E65-6701	Collar C	12.19
E65-6801	Drive Gear Collar	2.27
E65-7601	Left Side Plate	20.91
E65-7701	Left Side Plate	23.12
E65-7801	Left Side Plate	23.12
E65-7901	Gear	4.82
E65-8202	Drag Lever	69.37
E65-8601	Spool Gear	8.54
E65-8701	Spool Gear	8.54
E65-9401	Drive Gear	18.49
E65-9501	Pinion Gear	9.25
E65-9601	Handle	41.64
E65-9701	Spool	32.37
E65-9801	Spool	30.07
E65-9901	Pin	0.88
E66-0001	Frame	28.27
E66-0201	Spool	31.92
E66-0401	Spool Pin	1.48
E66-0501	Drive Shaft	10.14
E66-0601	Pinion Gear	6.66
E66-0801	Handle	18.04
E66-0901	Washer C	2.17
E66-1001	Frame	31.22
E66-1101	Spool	34.24
E66-1301	Frame	32.37
E66-1701	Spool	32.37
E66-1901	Drive Shaft	29.86
E66-2001	Pinion Gear	8.10
E66-2201	Right Side Plate	39.57
E66-2401	Right Side Plate	40.47
E66-2601	Right Side Plate	92.50

E66-2701	Handle	16.65
E66-2801	Frame	34.69
E66-3001	Spool	34.69
E66-3301	Right Side Plate	92.50
E66-3401	Frame	37.00
E66-3601	Spool	36.18
E66-3901	Right Side Plate	92.50
E66-4101	Spring D	0.54
E66-4501	Frame	163.18
E66-4701	Click Paw	3.97
E66-4801	Click Spring B	0.85
E66-4901	Spool	55.08
E66-5001	Drag Washer	24.57
E66-5101	Spool Shaft	10.08
E66-5501	Spring A	1.13
E66-5601	Drag Plate	45.49
E66-5801	Packing	2.55
E66-6001	Drag Washer Cover	17.04
E66-6101	Right Side Plate	50.88
E66-6102	Right Side Plate	55.49
E66-6103	Right Side Plate	50.88
E66-6104	Right Side Plate	50.88
E66-6201	Drive Shaft B	35.25
E66-6301	Drive Shaft Spring	0.50
E66-6401	Drive Shaft Screw	5.99
E66-6501	Drive Shaft Pin	0.50
E66-6601	Collar B	3.40
E66-6701	Drive Shaft Spring	1.61
E66-6801	Pinion Gear A	23.68
E66-6901	O Ring A	1.42
E66-7001	Drag Lever	34.84
E66-7401	Pre-Set Cam A	30.43
E66-7501	Ring A	2.84
E66-7601	Pre-Set Cam B	16.41
E66-7801	Pre-Set Drag Knob	7.88
E66-7901	Click Leaf Spring	2.52
E66-8101	Collar C	12.98
E66-8201	Handle	32.37
E66-8501	Handle Button	7.59
E66-8601	Handle Cap A	4.44
E66-8801	Drag Click Cap	2.52
E66-8901	Screw D	0.95
E66-9001	Washer D	0.91
E66-9101	Washer C	0.57
E66-9301	Screw I	0.50
E66-9501	Frame	174.46
E66-9701	Spool	39.32

E66-9801	Spool Shaft	24.66
E67-0001	Frame Plate	6.62
E67-0002	Frame Plate	3.72
E67-0201	Drive Shaft	26.65
E67-0301	Drive Shaft Nut	6.05
E67-0401	Handle	81.18
E67-0701	Handle Screw	6.39
E67-0801	Handle Nut Plate	2.84
E67-0901	Screw I	0.91
E67-1101	Level Wind Guard	1.61
E67-1301	Washer A	0.50
E67-1401	Ring Holder	7.12
E67-1501	Screw	0.50
E67-1601	Side Plt R	9.25
E67-1701	Frame Assembly	22.20
E67-1901	Right Side Cover	9.68
E67-1902	Side Plt R	9.68
E67-2001	Frame	24.05
E67-2101	Frame	26.14
E67-2201	Right Side Plt	6.48
E67-2202	Right Side Plate	6.48
E67-2301	Frame	13.18
E67-2401	Handle	13.37
E67-2901	Spool	23.60
E67-3001	Handle	7.24
E67-3401	Frame	16.89
E67-3601	Spool	24.74
E67-3701	Right Side Plt	6.01
E67-3801	Frame	10.87
E67-4001	Spool	22.43
E67-4301	Frame	34.69
E67-4401	Spool	33.54
E67-4701	Right Side Plate	39.32
E67-4801	Clutch Lever	9.23
E67-4901	Star Drag	16.93
E67-5001	Handle	21.98
E67-5301	Frame	37.00
E67-5401	Spool	35.85
E67-5701	R/S Plate	34.69
E67-6702	Handle Nut Screw	11.62
E67-7101	Harness Lug R/S	4.25
E67-7201	Harness Lug L/S	6.21
E67-8801	Frame	72.37
E67-9101	Click Button	2.49
E67-9201	Click Plate	0.50
E67-9301	Click Pawl	0.72
E67-9401	Click Button Washer	0.50

E67-9501	Click Spring	0.50
E67-9601	Frame Plate	3.97
E67-9602	Frame Plate	6.39
E67-9604	Frame Plate	3.97
E67-9801	Spool	64.76
E67-9901	Drag Washer	28.41
E68-0201	Drag Spring Washer	0.91
E68-0301	Ball Bearing	24.66
E68-0601	Spring A	0.50
E68-0701	Spool Shaft	9.10
E68-0801	Clicking Gear	13.51
E68-1001	Drag Metal	23.69
E68-1101	Drag Plate	23.69
E68-1201	Drag Washer Cover	15.12
E68-1301	Packing	0.88
E68-1401	Pin	0.60
E68-1601	Right Side Plate	67.83
E68-1602	Right Side Plate	177.78
E68-1701	Push Button	0.54
E68-1901	Drive Shaft	21.98
E68-2001	Drive Shaft Pin B	11.03
E68-2101	Drive Shaft Spring A	1.23
E68-2201	Drive Shaft Screw	7.81
E68-2301	Collar A	0.63
E68-2401	Drive Shaft Spring B	1.23
E68-2601	Drive Gear Collar D	0.88
E68-2701	Drive Gear Collar A	0.54
E68-2801	Drive Gear A	32.06
E68-2901	Drive Gear Collar B	0.88
E68-3001	Drive Gear B	30.20
E68-3101	Drive Shaft Nut	10.46
E68-3201	Pinion Gear B	22.20
E68-3301	Pinion Gear A	25.30
E68-3401	Drag Ratchet	2.84
E68-3501	A/R Pawl	4.25
E68-3801	Pin B	0.91
E68-3901	Washer B	0.72
E68-4101	Drag Lever	67.50
E68-4201	Collar C	0.50
E68-4202	Collar (C)	0.50
E68-4301	Drag Lever Plate	1.42
E68-4401	Drag Lever Plate	1.07
E68-4501	Pre-Set Cam	17.77
E68-4601	Ring	1.07
E68-4701	Pre-Set Cam B	21.33
E68-4801	Click Leaf Spring	0.88
E68-4901	Pre-Set Drag Knob	3.02

E68-5001	Collar	12.98
E68-5101	Handle Assembly	43.93
E68-5401	Handle Screw	12.22
E68-5501	Handle Button	7.59
E68-5601	Ball Bearing D	24.66
E68-5901	Screw	0.50
E68-6101	Screw	0.91
E68-6201	Spring D	0.91
E68-6301	O-Ring	0.50
E68-6500	Washer D	0.50
E68-6501	Washer D	0.85
E68-6601	Pinion Gear Holder	7.81
E68-6701	Drive Shaft B	20.92
E68-6801	Drive Shaft Pin B	11.03
E68-6901	Pinion Gear B	22.20
E68-7001	Washer B	1.92
E68-7101	Drive Gear	32.06
E68-7201	Drive Shaft Nut	10.74
E68-7301	Handle Assembly	68.24
E68-7601	Handle Nut Plate	2.14
E68-7801	Roller Clutch	12.44
E68-8801	O'ring (C)	0.50
E68-9201	Collar	0.76
E68-9701	Plate	1.23
E68-9901	Stopper	1.83
E69-9101	Plate	6.90
E69-9102	Plate	6.90
E69-9201	Frame Plate	11.34
E69-9202	Frame Plt	11.34
E69-9203	Frame Plate	11.34
E69-9204	RS COVER PLATE	19.27
E69-9205	RS COVER PLATE	19.27
E69-9206	RS COVER PLATE	19.27
E69-9209	RS COVER PLATE	19.27
E69-9210	RS COVER PLATE	19.27
E69-9801	A/R Ratchet	2.77
E69-9902	R/S Plate	38.87
E69-9905	R/S Plate	87.88
E69-9914	Right Side Plate	85.92
E69-9915	Right Side Plate	85.92
E70-0101	Plate	0.76
E70-0301	Collar	2.05
E70-0401	Washer	0.50
E70-0501	Set Plate	14.58
E70-0601	Plate	0.95
E70-0701	Collar	2.02
E70-0801	Plate	0.76

E70-0901	Slide Plt (Manual Clutch)	11.91
E70-0902	Yoke Plate	4.85
E70-1101	Yoke	4.63
E70-1201	Ratchet (Manual-Clutch)	4.69
E70-1202	Ratchet (Manual-Clutch)	4.69
E70-1203	A/R Ratchet	2.96
E70-1401	Eared Washer	2.05
E70-1801	Set Plt	14.93
E70-1901	Plate	0.76
E70-2001	Slide Plt (Manual Clutch)	11.91
E70-2301	L/S Plate	87.88
E70-2303	L/S Plate	87.88
E70-2401	Click Button	9.10
E70-2403	Click Button	9.10
E70-3001	Collar	1.23
E70-3101	Spring	0.54
E70-3201	Plate	3.15
E70-3301	Washer	0.50
E70-3401	Pinion Gear	24.87
E70-3601	Main Shaft Bb Pin	1.48
E70-3901	Gear Shaft	12.44
E70-3902	Gear Shaft	12.44
E70-4301	Pin	1.92
E70-4901	Washer	3.59
E70-5001	Screw	0.50
E70-5002	Screw	0.50
E70-5301	Screw	1.10
E70-5401	Spring	0.50
E70-5501	Nut	4.16
E70-5502	Nut	4.16
E70-5601	Spring Washer	1.54
E70-5801	Drive Gear	20.81
E70-5802	Drive Gear	20.36
E70-5901	Lever	16.00
E70-6001	Screw	0.88
E70-6201	Spool Assembly	54.82
E70-6401	Spring	0.50
E70-6501	Pin	2.05
E70-6701	Screw	0.50
E70-6801	Screw	4.41
E70-6901	Washer 0.3T	0.50
E70-6902	Washer 0.2T	0.50
E70-7001	Frame	80.93
E70-7401	Clutch Lever	20.48
E70-7501	Plate Assembly	4.44
E70-7701	Cast Control Cap	17.53
E70-8101	Slide Plt (Auto Clutch)	14.93

E70-8401	Handle	48.56
E70-8501	Yoke Spring	0.50
E70-8901	Drag Washer	0.66
E70-9101	Washer	0.50
E70-9103	Washer	0.50
E70-9105	Washer (G)	0.50
E70-9201	Click Leaf Holder	3.69
E70-9401	Click Plate	0.50
E70-9501	Ring	0.50
E70-9601	Screw	0.50
E70-9701	Screw	0.50
E70-9801	Washer	0.50
E70-9901	Washer	0.50
E71-0001	Stopper	5.26
E71-0501	Washer	0.57
E71-0601	Adj Washer (0.2T)	0.50
E71-0602	Adj Washer (0.1T)	0.50
E71-0603	Adj Washer (0.3T)	0.50
E71-0701	Leaf Spring	1.48
E71-0801	Plate	3.43
E71-0901	Washer	1.23
E71-1001	Washer	0.95
E71-1101	Washer 0.5T	0.50
E71-1201	RETAINER	0.50
E71-1301	O-Ring	0.50
E71-1401	Leaf Spring	0.54
E71-1501	Washer	0.63
E71-1601	O-Ring	0.50
E71-1701	Spring	0.91
E71-1801	Handle Lock Screw	0.72
E71-1901	Washer	3.21
E71-2201	Plate	3.15
E71-2301	Plate	1.23
E71-2401	Slide Plt (Auto-Clutch)	14.93
E71-2601	Pinion Gear	25.44
E71-2701	Drive Gear	20.81
E71-2901	Clutch Lever	20.48
E71-3001	Clutch Lever	20.48
E71-3201	Plate Assembly	4.44
E71-3301	Spring	0.50
E71-3401	Plate	0.76
E71-3501	Frame	80.93
E71-3601	Frame	80.93
E71-3801	Spool	58.73
E71-4201	Spring	0.50
E71-4301	Pinion Gear	24.87
E71-4401	Drive Gear	20.81

E71-4601	Frame	80.93
E71-4701	Drag Washer	0.69
E71-5001	Washer	0.50
E71-5002	Washer	0.50
E71-5101	Washer	0.50
E71-5601	Click Leaf Spring	2.02
E71-6801	Plate	6.96
E71-6901	Frame Plate	12.41
E71-6902	Frame Plate (B)	12.41
E71-6908	RS COVER PLATE	21.93
E71-6909	RS COVER PLATE	21.93
E71-6910	RS COVER PLATE	21.93
E71-6911	RS COVER PLATE	21.93
E71-6912	RS COVER PLATE	21.93
E71-6913	RS COVER PLATE	21.93
E71-7601	Set Plate	15.12
E71-7701	Plate	0.72
E71-7902	Yoke Plate	6.08
E71-8301	Yoke Spring	0.50
E71-8401	Pin	2.43
E71-8602	A/R Ratchet	5.39
E71-8801	Drag Washer	0.69
E71-9002	Drive Gear	23.19
E71-9101	Drag Washer (B)	0.66
E71-9304	Right Side Plate	90.45
E71-9305	Right Side Plate	90.45
E71-9306	Right Side Plate	90.45
E71-9307	Right Side Plate	90.45
E71-9308	Right Side Plate	90.45
E72-0101	Bearing Retainer	0.50
E72-0201	O'ring (B)	0.50
E72-0301	Click Leaf Spring	0.79
E72-0401	Washer (D)	0.57
E72-0501	Cast Control Cap	18.53
E72-0701	Screw (G)	1.07
E72-0702	Screw (F)	1.07
E72-0801	Screw (F)	0.50
E72-0901	Screw (A)	0.50
E72-1001	Washer	1.58
E72-1101	Star Drag	21.03
E72-1102	STAR DRAG	27.45
E72-1104	STAR DRAG	27.45
E72-1501	Nut	3.12
E72-1701	Key Washer (A)	1.89
E72-1801	Washer (B)	1.58
E72-1901	Washer (C)	3.47
E72-2001	Drag Washer	1.13

E72-2101	Eared Washer	2.77
E72-2301	Collar	7.47
E72-3202	Drive Gear	22.61
E72-3501	Frame	90.45
E72-3901	Spool	50.88
E72-4401	A/R Ratchet	2.43
E72-4601	Handle Assembly	53.14
E72-4801	Key Washer (D)	3.81
E72-5001	Washer (E)	0.63
E72-5101	Click Button	5.64
E72-5102	Click Button	5.64
E72-5201	Click Plate	0.54
E72-5301	Click Collar	0.54
E72-5601	O'ring (A)	2.68
E72-5701	O'ring	1.67
E72-5801	Pre-Set Drag Knob	3.02
E72-5901	Drag Lever	19.12
E72-6301	Frame	101.76
E72-6501	Spool	52.01
E72-7001	Right Side Plate	67.83
E72-7301	Frame	72.37
E72-7501	Spool	64.76
E72-7601	Spool Shaft	9.10
E72-8001	Pin (A)	0.54
E72-8101	Drive Shaft (B)	33.77
E72-8201	Collar (A)	0.50
E72-8301	Washer (C)	0.72
E72-8501	O-Ring (B)	0.50
E72-8601	Drag Lever Plate	1.42
E72-8701	Pre-Set Cam (A)	17.77
E72-8801	Retainer	0.50
E72-8901	Washer (D)	0.50
E72-9001	O-Ring (C)	0.50
E72-9101	Pre-Set Cam (B)	21.33
E72-9301	Collar	12.98
E72-9501	Handle Assembly	43.93
E72-9601	O'ring (D)	0.69
E72-9701	Clutch Lever	21.80
E72-9801	Bearing	3.94
E72-9901	Key Washer	5.76
E73-0101	Plate	2.08
E73-4401	Frame Assembly	101.76
E73-4701	Spool	54.26
E73-5101	Pinion Gear	25.99
E73-5301	Handle Assembly	56.54
E73-5501	Frame Assembly	113.06
E73-5701	Spool	57.67

E73-6101	Frame Assembly	124.37
E73-6301	Spool	57.67
E74-1001	Washer	1.64
E74-1101	Washer	1.64
E74-2002	CLAMP BOLT	9.19
E74-2003	Clamp Bolt	3.12
E74-2004	Clamp Bolt	3.12
E74-2301	Pinion Gear	18.08
E74-3601	Click Spring	0.50
E74-3701	Click Button	2.49
E74-3801	Drag Metal	23.69
E74-3901	Drag Plate	23.69
E74-4001	Screw (F)	0.50
E74-4101	Drive Shaft	13.39
E74-4201	Drive Shaft	23.74
E74-4301	Brake Collar	1.61
E74-4501	Click Pawl	1.39
E74-4701	Click Spring	2.43
E74-4801	Click Spring	2.77
E74-8201	FRAME ASSY	54.79
E74-8401	SPOOL ASSY	47.65
E74-8801	SET PLATE	19.74
E74-9101	DRIVE GEAR	26.58
E74-9201	DRAG WASHER (A)	11.23
E74-9301	DRAG DISC WASHER (B)	16.68
E74-9501	RS PLATE	40.74
E74-9502	RS PLATE	40.74
E74-9503	RS PLATE	40.74
E74-9504	RS PLATE	40.74
E74-9505	RS PLATE	40.74
E74-9701	CLUTCH LEVER (A)	13.62
E74-9901	PINION BEARING	7.83
E75-0001	MECHANICAL BRAKE KNOB	14.64
E75-0101	HANDLE ASSY	42.79
E75-1001	SET PLATE	21.44
E75-1101	RS PLATE	42.79
E75-1102	RS PLATE	50.14
E75-1103	RS PLATE	50.14
E75-1104	RS PLATE	42.79
E75-1105	RS PLATE	50.14
E75-1106	RS PLATE	50.14
E75-1601	GEAR SHAFT	15.34
E75-1701	GEAR SHAFT PLATE SCREW	1.36
E75-1801	SET PLATE BEARING RING	1.02
E75-2101	SPOOL ASSY	50.03
E75-2401	SPOOL ASSY	52.62
E75-2501	Frame assembly	30.44

E75-2701	Frame assembly	30.61
E75-3001	Frame Assy	51.91
E75-3101	Spool Assy	52.62
E75-3401	DRIVE GEAR	32.42
E75-3601	DRAG DISC WASHER (B)	19.05
E75-3901	PINION BEARING	7.83
E75-4001	MECHANICAL BRAKE KNOB	14.64
E75-4101	RS PLATE SCREW (C)	1.02
E75-4201	Handle Assembly	47.48
E75-4401	GEAR SHAFT	20.10
E75-4501	Frame assembly	31.82
E75-4601	SPOOL ASSY	58.89
E75-5101	Frame assembly	32.08
E75-5201	SPOOL ASSY	60.62
E75-7301	DRIVE GEAR	26.58
E75-7501	DRIVE GEAR	32.42
E77-4101	Clamp Bolt	1.42
F00-8001	Spring Holder	0.50
F02-0301	Clutch Spring	0.50
F02-8203	Click Leaf Spring Holder	4.54
F03-2201	Bearing Retainer	0.50
F03-2401	Click Leaf Spring	0.72
F04-3401	Spool Washer	0.50
F04-3402	Washer	0.50
F04-9901	Washer	0.79
F05-0002	Spool Washer B	0.50
F05-0104	SPOOL WASHER (A)	0.50
F05-1701	Brake Click Spring	0.72
F05-5502	Ball Bearing	3.91
F06-2601	Drag Washer Ret	0.50
F06-3501	Bearing	1.01
F07-8301	Bushing B	1.61
F09-2001	Clutch Cam	0.72
F09-2101	Counter	12.44
F09-2201	Counter Gear B	0.63
F09-2601	Worm Shaft	8.88
F09-2801	Level Wind Guard	1.61
F09-2901	Counter Gear	0.63
F09-3001	Stabilizer Bar	1.42
F09-3201	Pinion Gear	4.76
F09-3401	Drive Gear	10.17
F09-3503	Right Side Outer Ring	9.23
F09-3601	L/S Plt Screw	0.50
F09-3710	Left Side Platee	8.84
F09-3711	Left Side Plt	3.69
F09-3903	Left Side Outer Ring	9.23
F09-4802	Click Button Washer	0.50

F09-5501	Worm Shaft	10.65
F09-5701	Level Wind Guard	1.73
F09-5801	Stabilizer Bar	1.29
F09-6921	R/S Plt	13.82
F09-6922	R/S Plt	13.12
F09-7205	R/S Outer Ring	9.51
F09-7301	Clutch Cam	1.07
F09-7901	Yoke Plt	1.32
F09-8201	A/R Pawl Pin	0.98
F09-8401	Drive Shaft Ret	0.82
F09-9303	Stabilizer Bar	1.61
F09-9404	L/S Outer Ring	7.09
F13-1801	Click Spring Ret	0.60
F13-1802	Click Spring Ret	0.82
F13-2602	Spacer	0.50
F13-5401	Pinion Gear	5.02
F13-7502	Spool Washer	0.50
F17-0501	Drag Holder	7.37
F18-7601	Rod Clamp Screw	1.45
F18-7701	Clamp Nut	2.17
F18-7702	Rod Brace Nut	4.69
F18-7801	Rod Brace Nut	0.50
F20-4001	Click Leaf Spring Holder	1.76
F20-6901	Spool Plate Screw	0.50
F20-6902	Osc Gear Screw	0.50
F21-1102	Drive Shaft Ret Screw	0.50
F21-1103	Clutch Lever Screw	0.50
F21-2201	Bearing Ret Screw	0.50
F21-6201	Bearing Ret	0.79
F23-5407	Handle Screw	1.54
F23-8401	Bail Arm	1.29
F24-0001	Ball Bearing	6.71
F25-2901	Ball Bearing	11.03
F26-2701	Brake Click Spring	0.50
F27-0901	CLUTCH CAM MAGNET	5.45
F27-3301	Motor Holder O Ring	1.01
F27-4501	Motor Case O Ring	1.04
F28-3101	Ball Bearing	8.22
F28-5901	Power Lever Washer	0.60
F28-7901	Yoke Plt Spring	0.50
F28-8001	Pin	2.27
F30-3102	Power Lever Nut	1.20
F30-4701	CLUTCH SPRING	0.50
F30-6402	Washer	0.50
F33-6102	Rotor Nut	0.50
F35-2701	Washer	0.50
F35-2702	Washer G	0.57

F36-6801	Handle Bearing Washer	0.57
F36-6804	HANDLE BEARING WASHER(A)	0.68
F37-3301	Drag Washer Ret	0.50
F38-5801	Clutch Spring	0.50
F38-9102	Ball Bearing	24.63
F40-2801	Osc Pawl Holder Nut	0.82
F40-3003	Cast Control Cap	0.57
F40-3203	Star Drag	1.13
F40-3701	Bushing A	0.50
F40-4801	Handle Collar	0.50
F40-9001	Handle Collar	0.66
F42-8801	Clutch Trip Plt	0.98
F42-9701	Power Lever	14.08
F42-9702	Power Lever	5.36
F43-0002	Power Lever Cover	4.98
F43-0005	Power Lever Cover	1.13
F44-0201	Clutch Trip Plate Washer	0.50
F44-6202	Line Roller Washer	0.50
F44-6302	Line Roller Collar	1.29
F45-4901	Line Roller	2.96
F46-5901	Motor Holder O Ring	1.04
F46-6601	Motor Case Ring	0.50
F46-7201	Worm Shaft Bush	1.80
F46-7602	Frame Screw	2.55
F46-9006	Clutch Lever	5.23
F46-9016	Clutch Lever	16.25
F47-0002	Click Leaf Spring Holder	3.24
F47-0101	Friction Washer	0.95
F47-1205	Handle Nut Plate	1.80
F47-1207	Handle Nut Plate	6.84
F47-2107	Bail Arm	5.51
F50-5703	Screw	0.50
F50-5705	Front Cover Screw (B)	0.66
F51-6501	Line Guide Pawl	2.17
F53-2701	Worm Shaft Gear	4.13
F54-2401	Counter	25.44
F54-2601	Idle Gear Collar	1.51
F55-0408	Star Drag	4.35
F55-0415	Star Drag	5.76
F55-0424	Star Drag	15.95
F55-0501	Retainer	0.50
F55-2704	ROLLER CLUTCH	17.33
F55-5102	A/R Ratchet	1.80
F55-6501	R/S Plt Screw	1.04
F57-1902	Idle Gear Screw Washer	0.50
F57-1903	WORM SHAFT WASHER(A)	0.68
F57-3101	Idle Gear A Collar	2.55

F57-4303	Spacer B	0.50
F57-4403	Cast Control Cap	2.74
F57-5601	Drive Shaft Washer	0.50
F57-5602	Drive Shaft Washer A	0.50
F57-6601	Handle Collar	0.72
F57-7802	Brake Adj Knob	6.71
F57-7901	Set Plt Screw	5.42
F57-7902	Screw	7.75
F58-2501	Ball Bearing	7.94
F59-0101	Power Lever Collar	0.66
F59-2101	Idle Gear	1.54
F59-4001	Motor Gear D Bushing	4.06
F59-4101	Spool Plate	9.95
F59-4104	Spool Plt	9.29
F59-5101	Motor Holder	19.28
F59-5301	Motor Holder O Ring	1.80
F59-5801	Motor Case O Ring	1.67
F59-5901	Motor Case Ring	0.82
F59-6501	Worm Shield	5.64
F59-6601	Level Wind Post	2.80
F59-6907	Motor Cover	3.34
F59-6910	Motor Cover	5.86
F59-7001	Yoke Plt	2.02
F59-7201	A/R Pawl	1.01
F59-7301	A/R Ratchet	2.58
F59-7609	Finger Cover	6.11
F59-7610	Finger Cover	4.10
F59-7901	Clutch Cam	2.58
F59-8201	Clutch Cam Spring	0.79
F59-8301	R/S Plt Screw B	1.51
F60-8001	Bail Spring	0.69
F60-8301	A/R Pawl Spring	0.79
F60-8901	Line Roller Screw	0.72
F61-3401	Brake Dial Retainer	1.04
F62-3305	Screw	1.04
F62-5002	Line Roller	4.38
F62-5005	Line Roller	1.73
F62-5502	Washer B	1.20
F62-5503	Washer (B)	2.05
F62-7201	Key Washer	0.82
F62-7301	Eared Washer	2.17
F63-5001	Drag Washer	0.72
F63-5101	Key Washer	0.82
F63-5201	Eared Washer	1.42
F63-7701	Brake Dial Washer	3.24
F63-9701	Frame Screw B	8.66
F64-1101	Ball Bearing	5.80

F64-1401	Clutch Cam	1.04
F64-1602	Ball Bearing	27.12
F64-3601	Pin	1.01
F64-4702	Key Washer	0.91
F64-7201	Drive Shaft Washer	0.50
F64-8301	Bushing	0.72
F65-5501	Worm Shaft Washer	0.91
F65-7001	Spool Gear Ring	0.50
F65-7701	Cord Shield	0.69
F65-7801	O Ring	2.55
F65-8501	Cord Shield	0.69
F65-9306	Drag Washer	7.62
F65-9404	Eared Washer	0.57
F65-9505	Drag Lip Washer	0.79
F66-1002	Connector Cap	3.24
F67-3401	A/R Pawl Spring	0.57
F67-3501	Ret	0.50
F67-3601	Drag Spring Washer	0.82
F67-3802	Mechanical Brake Washer	0.50
F68-2001	Power Cord Cover A	1.76
F68-2601	Spool Plate Washer	0.50
F68-2605	Spool Plate Washer	0.54
F68-2802	Level Wind Nut	4.79
F69-1001	Drag Washer	0.50
F70-1101	Motor Screw	4.85
F70-1201	Motor Washer	0.82
F70-4902	Spool Click Leaf Spring	1.04
F70-9002	Spool Click Leaf Spring	0.82
F70-9801	Spacing Sleeve	11.88
F71-0001	Drag Washer Ret	0.72
F71-3701	Spool Bushing	2.84
F71-4601	Cord Shield	0.79
F71-4801	Motor Gear O Ring	3.06
F71-5302	Drive Shaft	6.21
F71-5303	Drive Shaft	6.93
F71-5601	Drag Collar Bushing	3.24
F71-7702	Magnet Holder	6.21
F72-1001	Handle Collar	0.50
F72-1202	Handle Collar	0.50
F73-2701	Pinion Shaft	9.01
F73-2801	Pin	2.80
F73-3201	Bushing	4.63
F73-3301	Pinion Gear	6.40
F73-3401	A/R Pawl	2.80
F73-3501	Drive Shaft Washer	0.50
F73-3602	Drive Shaft	9.73
F73-3701	Drive Shaft Washer	0.50

F73-3702	Drive Shaft Washer A	0.50
F73-3801	Drive Gear	7.89
F73-3901	Water Shield	5.67
F73-4001	Ball Bearing Collar	5.01
F73-4201	Bearing Washer	1.83
F73-4302	R/S Plt Screw	1.04
F73-6202	L/S Plt Screw A	0.50
F73-6803	Stabilizer Bar	2.99
F73-9601	Motor Case Plate	9.58
F73-9701	Motor Case Bushing	1.61
F74-0201	Pinion Gear	6.11
F74-2501	Drag Washer Ret	0.50
F74-4101	Pinion Shaft	3.34
F75-5504	Drag Washer B	0.50
F75-5701	Eared Washer	1.35
F76-1701	A/R Ratchet	0.72
F76-5401	Roller Clutch	27.56
F76-6106	Spool Shaft Washer	0.95
F76-6301	Spool	18.78
F77-0704	Brake Dial Washer	4.79
F77-0709	Washer	6.90
F77-3001	Spring Holder	3.59
F77-4401	A/R Pawl Spring	0.50
F77-4601	Washer	0.50
F77-4603	Clutch Trip Plt Washer	0.50
F77-4701	Collar	5.76
F77-7901	Bail Spring	0.72
F78-8204	L/S Plt	5.33
F78-8302	Spool	48.13
F78-8508	L/S Plt	5.33
F78-8602	Spool	33.54
F78-9801	Pinion Gear	3.05
F78-9901	Drive Gear	12.55
F79-3203	Clutch Lever Plt B	0.82
F79-3305	Clutch Lever Plt A	0.82
F79-3306	Clutch Lever Plt A	1.80
F79-3401	Clutch Cam Retainer	0.50
F79-3501	Clutch Cam	0.82
F79-3702	Yoke Plt	5.42
F79-3801	Yoke Plate Screw	4.41
F79-3901	Clutch Trip Lever	3.24
F79-4101	Drive Shaft Ret	2.24
F79-4401	Pin	1.29
F79-4501	Clutch Cam Spring	1.01
F79-4601	Pin	1.39
F79-4701	Clutch Trip Plt Spring	1.01
F79-4801	Yoke	1.80

F79-4901	Yoke Spring	0.50
F79-5001	Pinion Gear	4.04
F79-5201	Line Guide	32.82
F79-5501	Worm Shaft Holder	1.26
F79-5801	Worm Shaft Holder	1.29
F79-5901	Drive Gear	2.15
F79-6001	Drive Gear	4.49
F79-6101	Eared Washer	1.45
F79-6102	Eared Washer	2.74
F79-6201	Drag Washer	2.52
F79-6301	Key Washer	1.04
F79-6303	Key Washer A	2.74
F79-6401	Key Washer	1.42
F79-8110	L/S Outer Ring	20.19
F79-8111	R/S Outer Ring	23.25
F79-8201	Bearing Ret A	0.66
F79-8301	O Ring	1.29
F80-0501	Pinion Shaft	4.35
F80-0701	Bail Spring	0.50
F81-1801	Bearing	5.58
F81-2103	Ball Bearing C	10.40
F81-7001	Drag Collar Shiled	4.41
F81-7101	Bushing B	1.39
F81-9001	Rotor Nut Holding Plate	0.69
F81-9401	Worm Shaft	3.37
F81-9901	Level Wind Guard	7.94
F82-6301	A/R Ratchet	1.13
F82-6303	RATCHET	3.40
F83-4701	Ball Bearing Collar	0.66
F83-6502	Worm Shield	1.35
F84-5601	Pinion Gear	5.19
F84-5702	Clutch Cam	3.69
F84-6603	Level Wind Guard	1.61
F84-6703	Level Wind Guard	1.45
F84-6801	Drive Shaft	4.00
F84-6901	Worm Shaft	7.34
F84-7001	Worm Shaft	7.18
F84-7101	L/S Cover	1.05
F84-7301	Clutch Lever Plt	0.50
F84-7401	Clutch Lever Plt	0.72
F84-7501	Yoke	0.50
F84-7701	Right Set Plt	2.08
F84-8101	L/S Plt	3.38
F84-8102	L/S Plt	3.38
F84-8301	Frame	10.52
F84-8501	Clutch Lever	0.79
F84-8601	Clutch Lever	0.72

F84-9001	Drive Shaft	5.95
F84-9002	Drive Shaft	5.01
F84-9901	Handle Nut	1.39
F84-9903	Handle Nut	0.72
F84-9904	Handle Nut	1.45
F85-0401	Handle Collar	3.97
F85-0402	Handle Collar	5.42
F85-0404	Spacer C	3.56
F85-1201	R/S Plt	4.35
F85-1202	R/S Plt	5.74
F85-1301	Worm Shaft Holder	0.50
F85-1401	Click Lever	0.50
F85-1501	Gear Shaft Collar	17.26
F85-1601	L/S Outer Ring	5.20
F85-1701	Pin	1.95
F85-1801	Pin	1.20
F85-1901	Pinion Gear Washer	0.60
F85-2001	Collar	1.42
F85-2301	Click Gear	0.66
F85-3501	Mechanical Washer	0.50
F85-3602	Mechanical Brake Washer	0.50
F85-9101	Worm Shaft Bushing	1.20
F85-9401	Line Guide Pawl	2.39
F86-2301	Power Lever	14.08
F86-2801	Power Lever Cover	6.84
F86-2807	MECHANICAL BRAKE COVER	2.63
F86-2901	Drag Click Spring Holder	2.21
F86-3202	Handle Collar	2.77
F86-4101	Yoke Spring	0.50
F86-4501	Line Guide	8.63
F86-4601	Left Set Plt	3.06
F86-7201	Frame	16.71
F87-7501	Drag Washer	0.82
F87-8801	Stabilizer Bar	1.01
F87-8901	Idle Gear	1.54
F87-9301	Handle	3.36
F88-0001	A/R Ratchet	0.50
F88-0311	Side Cover	4.78
F88-1101	Roller Clutch	18.99
F88-1702	Key Washer	0.60
F88-4001	Drag Washer Ret	0.50
F88-4506	Rear Cover (A)	4.13
F88-7801	Drive Shaft Ret	1.32
F88-8701	Brake Adj Knob	1.07
F88-8801	Shield Plt	1.07
F88-8901	Brake Collar	0.50
F88-9103	Idle Gear Washer	0.50

F88-9105	STOPPER WASHER	0.50
F88-9507	A/R Lever	4.13
F89-1503	Screw F	4.06
F89-5301	Drag Knob Click Plt	10.11
F89-5302	Drag Knob Click Plt	8.73
F89-5304	Drag Knob Click Plt	7.12
F89-5305	Drag Knob Click Plate	5.86
F89-5307	Drag Knob Click Plt	5.64
F89-7102	POWER LEVER PLATE WASHER	0.68
F90-4903	Key Washer A	4.00
F90-8701	Drag Knob Click Plt	8.73
F90-8703	Drag Knob Click Plate	12.03
F90-8704	Drag Knob Click Plt	6.36
F91-0901	Clutch Lever	9.01
F91-4401	Motor Screw	0.50
F91-7401	Worm Shaft Holder A	1.29
F91-7501	Level Wind Guard	5.23
F91-8201	Worm Shaft	10.49
F91-8801	Idle Gear	1.80
F91-8901	Idle Gear Collar	2.74
F92-4001	Pin	3.72
F92-4101	Click Lever Spring	0.60
F92-4201	Click Lever	6.33
F93-5201	Yoke Spring	2.84
F93-5401	Idle Gear Screw	0.50
F93-8601	Drive Shaft	5.01
F93-8602	Drive Shaft	10.40
F93-8801	A/R Pawl	4.79
F93-9201	Drive Gear	8.47
F93-9701	Screw	0.50
F94-0301	Click Lever Collar	1.45
F94-6901	Pinion Shaft	7.09
F94-7102	Spacer B	0.57
F95-0201	Line Guide Washer	0.50
F95-6701	Washer (A)	0.72
F95-6702	Spacer	1.20
F96-2801	Click Lever Spring	0.50
F96-6001	Line Guide Pawl	1.48
F96-7901	Clutch Cam Spring	0.50
F96-8401	Spool	21.85
F97-1201	Line Guide	33.86
F97-2402	Bail Assembly	5.72
F97-3808	R/S Plt	10.78
F97-4101	Bearing Ret A	2.02
F97-4201	Pinion Gear	15.95
F97-4301	Drive Shaft	11.21
F97-4401	Drive Gear	13.98

F97-4501	Drag Washer	2.55
F97-4601	Eared Washer	1.61
F97-4701	Key Washer	1.29
F97-4801	Water Shield	5.42
F97-4901	Collar	9.99
F97-5601	Ball Bearing Collar B	4.35
F99-5501	Click Spring	0.50
F99-7401	Clutch Cam	1.01
F99-7601	Clutch Lever	5.67
F99-7801	Yoke Plt	2.99
F99-7901	Clutch Trip Plt	2.39
F99-8001	Drive Shaft Ret	1.61
F99-8201	Yoke	1.29
F99-8301	Pinion Gear	5.84
F99-8302	Pinion Gear	6.05
F99-8501	Drive Gear B	10.09
F99-9803	Roller Clutch	23.09
FLT1020-GU	Pinion + Drive Gear Unit	14.08
FLT2530-GU	Pinion + Drive Gear Unit	15.03
FLT2530XGU	Pinion + Drive Gear Unit	15.03
FLT4050-GU	Pinion + Drive Gear Unit	15.03
G00-2901	Yoke Pin	2.46
G00-4601	Magnet Holder Ret	0.79
G00-6010	R/S Plt	36.26
G00-6601	R/S BEARING	2.72
G00-7203	Spool	21.38
G00-7303	Spool	23.92
G00-7401	Bushing A	3.18
G00-7501	Collar	2.39
G00-8001	Bushing B	1.29
G00-9302	Clutch Lever Plt A	1.04
G00-9402	Clutch Lever Plt B	0.91
G00-9701	Clutch Cam Screw	5.29
G01-0201	Clutch Trip Plt Spring	0.69
G01-0701	Worm Shaft Collar	3.59
G01-1201	Worm Shaft Gear	2.52
G01-1401	Gear Shaft Collar	7.21
G01-1702	Stabilizer Bar	5.99
G01-5501	Pinion Shaft	3.59
G01-6003	CLUTCH CAM PLATE SCREW	0.50
G01-7503	Bail Spring Shaft	0.72
G01-7504	Bail Spring Shaft	0.57
G02-1201	Drive Shaft Ret Screw	5.04
G03-4601	Clutch Spring	1.29
G03-6829	L/S Plate	18.06
G03-9701	Click Pawl	1.86
G04-0701	Yoke Plt	3.34

G04-0803	Handle Nut Plt Screw	0.72
G04-0805	Plt Screw A	0.50
G04-0806	R/S Plt Screw B	0.50
G04-0809	Handle Screw	0.69
G04-0814	R&L/S Plt Screw	0.50
G04-0815	R/S Plt Screw B	0.50
G04-0820	Side Plate Screw	1.01
G04-0821	Screw	2.96
G04-0823	Screw	2.87
G04-0824	L/S PLATE SCREW(A)	3.40
G04-0825	Right Side Plt Screw	0.50
G04-0826	Screw	4.00
G04-0828	Side Plate Screw	1.01
G04-0829	Rs Plate Screw B	1.01
G04-0830	RS PLATE SCREW (A)	1.36
G04-0831	LS PLATE SCREW (A)	1.02
G04-0832	RS PLATE SCREW (C)	0.50
G04-7601	Line Roller Collar	2.39
G05-1701	Bushing	1.45
G05-1801	Bushing A	0.57
G05-1901	Bushing B	0.50
G05-5101	Idle Gear Ball Bearing	12.60
G05-6201	Drag Collar	1.80
G05-6301	Gear Shaft Collar	7.81
G07-0101	Idle Gear	12.10
G07-0201	Motor Gear A Ret	0.76
G07-0301	Ball Bearing	21.64
G07-2101	Worm Shield	6.71
G07-2701	Stabilizer Bar	2.27
G07-3001	Motor Washer	1.42
G07-4101	Ball Bearing	21.61
G07-4501	Spool Gear	1.51
G07-4601	Spool Gear Ring	0.50
G07-6501	Idle Gear Collar	4.03
G07-6601	Idle Gear	1.51
G07-6701	Idle Gear	1.26
G07-7201	Idle Gear Collar	0.76
G07-8001	Frame Screw	5.80
G07-8103	Frame Screw (A)	1.04
G07-9501	CODE COVER	2.04
G07-9502	Shrink Tubing Wrap	2.33
G08-1901	Drive Shaft Bushing	1.76
G08-2301	Clutch Cam Lever Pawl	1.13
G09-9801	Washer	0.69
G11-5001	Screw	0.50
G12-0901	A/R Ratchet	1.07
G12-3301	Rotor Nut	0.50

G12-6402	Spool Gear	6.33
G12-6501	Spool Shaft Gear A Retain	0.50
G12-6602	Spool Transmission Gear	32.06
G12-7001	Yoke Spring	0.50
G13-9601	Power Lever Nut	1.04
G14-1302	Motor Transmission Gear	34.97
G14-4705	R/S Plt	54.49
G14-4904	Frame	101.66
G14-5806	L/S Plt	23.12
G14-6506	L/S Plt	42.64
G15-0301	Washer	0.50
G15-2502	Collar	3.24
G15-2503	Collar C	0.69
G15-6801	Ball Bearing	19.06
G15-6803	Ball Bearing B	22.46
G15-6805	CLUTCH CAM BALL BEARING	16.34
G15-7301	Oscillating Gear	1.80
G15-7401	Oscillating Gear Spring	0.50
G15-8101	Roller Clutch Washer	1.07
G15-8601	O Ring	1.61
G15-9301	A/R Pawl	5.01
G16-0101	Side Cover Screw	0.72
G16-0106	Screw	1.73
G16-0401	Bail Spring	0.79
G16-2001	Line Roller Bushing	4.66
G16-2101	Line Roller	4.00
G16-2202	Line Roller Screw	1.39
G16-2401	"O" Ring	1.07
G16-2701	Key Washer	2.08
G16-2702	Key Washer	0.91
G16-2801	Pin	1.70
G16-2901	Spool Metal B	3.18
G16-3001	O Ring A	0.50
G16-3101	Spool Metal A	2.27
G16-3201	O Ring B	0.72
G16-3801	Drive Shaft Pin B	0.91
G16-5602	Drag Knob Click Plate	5.99
G16-5603	Drag Knob Click Plate	6.21
G16-5801	Drag Washer	9.89
G16-5901	Eared Washer	1.80
G16-5902	Eared Washer	1.29
G16-5903	Eared Washer	1.26
G16-7201	Washer	0.50
G17-1401	LS PLATE SCREW(C)	1.02
G17-1402	Rotor Nut Lock Screw	0.50
G17-3401	Cord Shield	2.33
G17-5301	Roller Clutch Cover	1.26

G17-5401	Collar E	1.04
G17-5501	Anti Reverse Claw Plate	0.50
G17-5601	Anti-Reverse Pawl	2.05
G17-5701	Body Shield	1.80
G17-5803	Anti-Reverse Lever	2.30
G17-6201	Worm Shaft Gear	1.80
G17-6401	Stabilizer Bar	9.45
G17-6501	Worm Shaft Retainer B	2.55
G17-6601	Pinion Gear	8.30
G17-6701	Anti-Reverse Ratchet	0.79
G17-6702	Ratchet	1.20
G17-6802	Collar	3.09
G17-6901	Collar C	1.04
G17-7001	Bearing Retainer	4.06
G17-7101	Oscillating Slider	8.16
G17-7301	Collar H	3.81
G17-7603	Side Cover	6.15
G17-7701	Rotor Plate	2.05
G17-7801	Screw J	4.85
G17-8001	Rear Cover Shield	5.64
G17-8109	Rear Cover	24.48
G17-8201	Rotor Shield	1.80
G17-8303	Rotor	62.12
G17-8403	Bail Arm	4.41
G17-8503	Cover A	1.26
G17-8603	Bail	68.27
G17-9201	Rotor Shaft	9.45
G17-9303	Cover B	1.26
G17-9702	Collar B	7.40
G18-0001	Screw K	3.81
G18-0101	Rotor Nut	10.46
G18-0301	Rotor Nut Retainer	0.50
G18-5101	Spacer C	0.50
G18-8501	Screw D	5.36
G18-9001	Spool Ring	3.50
G19-3701	Screw	0.50
G19-4301	Brake Shoe	3.59
G19-5501	Collar B	0.69
G19-5602	Screw	0.50
G20-1501	Spool	32.41
G20-1601	Spool	26.90
G20-1701	Spool	32.49
G20-2701	Clutch Cam Bushing	3.40
G20-3801	Spool Metal	4.38
G20-5001	Screw	0.50
G20-5101	Screw	0.50
G20-5500	Washer F	0.50

G20-5501	WASHER (F)	0.50
G20-5503	Washer	0.50
G20-5505	Washer	0.50
G21-0801	Body	6.27
G21-0901	BODY	6.38
G21-1001	Body	5.72
G21-1701	Pin	1.01
G21-2401	Spacer	3.24
G21-2402	Washer A	0.85
G21-2502	Ball Bearing	5.64
G21-2503	Ball Bearing	11.15
G21-2901	Screw	0.50
G21-3001	O Ring	2.52
G21-8201	Screw	4.35
G21-8401	Body	8.26
G21-8501	Body	7.54
G21-8601	Body	7.24
G22-0305	Handle Nut	8.25
G22-0701	Collar	0.50
G22-4101	Pin	1.07
G22-5103	Brake Washer	0.79
G22-5201	Motor Gear A	10.78
G22-5601	Spool Shaft	6.90
G22-5701	Motor Gear C	4.41
G22-7401	Bearing Retainer	0.50
G24-2901	Motor Case Plt	4.60
G25-2201	O Ring	0.50
G25-2202	LEVEL WIND O RING	2.38
G25-3101	Collar J	3.87
G25-3201	Screw L	5.36
G25-3401	Collar L	1.51
G25-3601	Washer	0.50
G25-4101	Collar G	3.34
G25-4201	Line Roller	6.36
G25-6801	Collar	1.51
G26-0702	Clutch Lever Plt B	1.07
G26-0802	Clutch Lever Plt A	1.07
G26-0901	Clutch Lever	7.06
G26-1505	Front Plt	12.00
G26-1619	R/S Plate	20.46
G26-1801	Right Set Plt	17.36
G26-2301	Clutch Cam Plate	1.10
G27-0001	Pinion Gear	6.01
G27-0601	Retainer	0.50
G27-0701	Handle Metal Plt Screw	0.50
G27-0801	ARM LEVER SPRING COVER SCREW	0.50
G27-0901	Screw	0.50

G27-6301	Spacer	1.01
G27-9601	Ball Bearing	20.22
G27-9602	Ball Bearing D	8.19
G27-9603	PINION BALLBEARING (A)	7.15
G28-1401	Washer	0.50
G28-1601	Ball Bearing	16.03
G28-1605	Ball Bearing	7.37
G28-1607	Ball Bearing	10.77
G28-5801	Ball Bearing	8.03
G28-7801	Ring	1.67
G28-8012	Dial	37.77
G28-8101	Click Spring	1.01
G28-8402	Magnet Holder	5.99
G28-8809	COVER	20.76
G29-0901	Collar	7.47
G29-2301	Screw C	0.79
G29-2401	Screw B	0.79
G29-4201	Power Lever Spring	0.50
G29-7001	Screw B	0.50
G29-7006	GEAR SHAFT PLATE SCREW	3.40
G29-8201	Bail Spring Shaft	1.61
G29-9005	POWER LEVER PLATE SCREW(B)	0.68
G30-1101	Collar A	1.04
G30-1301	Ball Bearing B	7.50
G31-4501	Roller Clutch	20.60
G31-4901	Ball Bearing	6.43
G31-4902	R/S Cover A Ball Bearing	9.36
G31-5301	Washer	0.50
G31-5302	REAR CAP SCREW WASHER(A)	1.02
G31-7501	Washer	0.72
G31-7504	WASHER	0.88
G31-8501	Screw B	0.50
G31-8503	Screw	1.45
G32-2701	Drive Shaft Pin	2.17
G32-6201	Collar F	1.80
G33-2704	Screw	0.50
G33-2904	Screw	0.50
G33-2906	BODY COVER SCREW	0.86
G33-4702	Oscillating Gear Pinion	15.81
G33-4703	Oscilating Gear Pinion	17.64
G33-4901	Oscilating Gear	2.33
G33-6201	Anti Reverse Claw Collar	1.13
G33-6601	A/R Claw Spring	1.48
G33-6701	Oscillating Gear Shield	0.69
G33-7101	Body Ring	2.30
G33-7301	Bail Spring Shaft	5.04
G33-7501	Bail Spring Holder	1.13

G33-7601	Rotor Brake Spring	1.39
G33-8401	Rotor Nut O Ring	0.88
G33-8901	Main Shaft Pin	1.39
G33-9001	Spool Metal	5.89
G33-9101	O Ring	0.82
G33-9202	Spool Metal	7.94
G33-9301	Spool Metal Pin	0.91
G33-9401	O Ring	1.07
G34-1203	BAIL HOLDER NUT	10.52
G34-1301	Click Leaf Spring Holder	5.01
G34-1401	Click Leaf Spring	2.05
G34-1501	Spool Washer	0.50
G34-5301	Stopper Spring	0.57
G34-5701	Strike Stopper Button	2.77
G34-5901	Spring	0.50
G34-7801	Pinion Gear	22.88
G35-0501	Click Spring	6.02
G35-0601	Click Lever	6.46
G35-0703	Harness Lug A	5.73
G35-2301	Right Side Cover Screw	0.50
G35-2302	Screw	0.50
G35-6401	Rod Clamp	22.76
G35-6901	Spacer B	0.91
G35-7001	Spacer C	0.91
G35-7101	Clutch Cam	0.82
G35-7202	Clutch Lever	4.38
G35-7301	Yoke Plt	2.99
G35-7401	Clutch Trip Plt	1.29
G35-7701	Drive Shaft Ret	1.80
G35-7801	Yoke Plt Spring	0.79
G35-7901	Yoke	1.45
G35-8001	Yoke Spring	0.72
G35-8501	Key Washer B	0.82
G35-8703	Stabilizer Bar	5.04
G35-8704	Stabilizer Bar	6.43
G35-8705	Stabilizer Bar	6.43
G36-0502	Brake Adj Knob	5.89
G36-0715	Left Side Plate	7.48
G36-2601	Motor Holder	30.81
G36-2801	Worm Shield	5.95
G36-2901	Level Wind Post	2.52
G36-3001	Frame Screw	3.24
G36-3101	Frame Screw	7.25
G37-0905	Ball Bearing	12.19
G37-2901	Main Shaft	9.20
G37-3601	Drag Knob Click Plt	9.45
G37-3701	Spool Retainer	5.20

G37-4502	Motor Cover	5.80
G37-4506	Motor Cover	5.13
G37-4805	Finger Guard	4.35
G37-5001	Pin	1.39
G37-8001	O Ring	0.82
G38-2502	Frame	97.58
G38-3201	Stand Screw	0.50
G38-5901	Motor Screw	3.59
G38-7901	Rod Clamp	4.69
G39-1601	Screw	9.95
G39-2201	Rotor Nut Holding Plt	0.50
G39-2202	Rotor Nut Plt	1.26
G39-2401	CLAMP PLATE NUT WASHER	0.68
G39-9702	O Ring C	0.85
G40-0401	Collar F	0.50
G40-3218	Handle Nut Plate	1.07
G40-5901	R/S Plt Screw B	2.17
G40-8301	Line Guard Washer	0.50
G41-0301	Line Guide	17.23
G41-0601	Screw	0.50
G41-0701	Screw H	0.50
G41-7801	Worm Shaft Holder B	2.33
G41-8001	Worm Shaft Assembly	15.15
G41-8002	Worm Shaft	18.93
G41-8101	Bail Spring	0.50
G42-1401	Drag Ratchet	4.22
G42-6301	Ball Bearing	8.98
G42-6302	Ball Bearing E	7.75
G42-7201	Ball Bearing	10.84
G42-7202	Ball Bearing	7.40
G42-7701	Ball Bearing	19.91
G42-7702	LS BALL BEARING	19.49
G42-7703	LS BALL BEARING	8.17
G42-8501	Drag Washer	2.90
G43-0604	Ic Module	568.55
G43-1001	Ball Bearing	12.63
G43-1002	Ball Bearing	12.63
G43-1007	Ball Bearing B	8.66
G43-1101	Ball Bearing	8.10
G43-1102	Ball Bearing F	7.94
G43-1104	Ball Bearing	7.69
G43-1105	Ball Bearing E	10.49
G43-1401	Set Plate	210.08
G43-1403	R/S Ring	366.68
G43-1501	Palming Plate	94.96
G43-1502	Palming Plate	92.17
G43-1504	Palming Plate	116.15

G43-1801	Stand Plate	59.98
G43-1901	Stand	70.56
G43-2001	Stand Screw	2.58
G43-2101	Finger Guard	20.41
G43-2102	Finger Guard	30.40
G43-2201	L/S Ring	187.78
G43-2402	Left Set Plt	79.17
G43-2501	Set Plate	53.96
G43-3501	Idle Gear (A)	16.66
G43-3601	Collar	6.36
G43-3901	Motor Metal	52.79
G43-4202	Motor	89.50
G43-4701	Motor Holder	60.48
G43-4801	Ball Bearing	139.54
G43-4901	Motor Holder Shield	3.78
G43-5301	Spool	206.31
G43-5801	Spool Gear A	18.77
G43-6301	Screw	4.00
G43-6501	Spool Transmission Gear C	67.57
G43-7001	Spool Plt	9.32
G43-7101	Spool Plt Screw	1.01
G43-7201	Click Plt	14.87
G43-7301	Ball Bearing	63.65
G43-7401	Motor Holder Screw	2.84
G43-7601	Level Wind	54.02
G43-7701	Motor Cord Cover	1.29
G43-7801	Level Wind Collar	6.84
G43-8001	Level Wind Post	5.04
G43-8101	Worm Shield	16.25
G43-8201	Worm Shaft	27.44
G43-8301	Worm Shaft Bushing	6.62
G43-8401	Worm Shaft Gear	33.42
G43-8501	Line Guide Pawl	24.91
G43-8601	Pawl Cap	10.05
G43-8901	Ic Module Protector Plate	11.59
G43-9001	Receptacle Holder	46.78
G43-9101	Receptacle	4.45
G43-9301	L/S Plt	143.66
G43-9401	Ball Bearing C	19.91
G43-9402	Ball Bearing	14.62
G43-9501	Drive Shaft	21.67
G43-9601	Drive Shaft Ret	4.79
G43-9701	Drive Gear	38.87
G43-9801	Drive Gear Plt	8.57
G43-9901	Drive Shaft Bushing	4.79
G44-0001	Drag Holder	125.30
G44-0002	Pinion Gear	225.52

G44-0402	Drag Washer A	30.03
G44-0601	Key Washer	2.77
G44-0701	Eared Washer	2.77
G44-0801	Drag Collar Shield	4.54
G44-0901	Drag Collar	17.89
G44-1001	Drag Spring Washer	3.53
G44-1101	Eccentric Cam	57.01
G44-1201	A/R Pawl Pin	4.28
G44-1301	A/R Pawl	5.80
G44-1401	A/R Pawl Spring	3.09
G44-1501	A/R Claw Spring Pin	2.27
G44-1601	R/S Plt	223.70
G44-1602	R/S Plate	250.12
G44-1701	Right Set Plt	266.17
G44-1801	Power Lever Collar	23.12
G44-2001	Click Lever	69.97
G44-2401	Click Lever Ret	4.54
G44-2501	Power Lever	42.03
G44-3002	Drag Lever Plt	31.25
G44-3401	Drag Lever	35.78
G44-3501	Drag Lever Metal	35.78
G44-3601	Drag Lever Metal Washer	2.77
G44-3701	Drag Lever Collar	52.42
G44-3801	Drag Lever Cap	6.30
G44-4001	Pre-Set Metal Washer	1.26
G44-4101	Pre-Set Drag Knob	73.96
G44-4102	Pre-Set Drag Knob	101.80
G44-4201	Pre-Set Metal	36.82
G44-4301	Cover Plt	12.10
G44-4401	Stand Plate	2.02
G44-4501	Drive Shaft Cap	8.79
G44-5101	Handle Nut	7.81
G44-5301	Clamp Bolt	18.71
G44-5401	Clamp Nut	5.51
G44-5601	Drag Holder Bearing Washe	4.54
G44-5701	Drag Holder Bearing	22.93
G45-5301	O Ring	0.50
G45-5402	Handle Knob	6.65
G45-5601	Bail Arm Screw	0.50
G45-5801	Drag Washer B	3.15
G45-6206	Handle Knob Cap	2.74
G45-6401	Stabilizer Bar	3.62
G46-6001	O Ring	0.50
G46-6100	OSCILLATING GEAR WASHER	0.68
G46-6103	Rotor Nut Bearing Washer	0.50
G46-6201	Ball Bearing	13.07
G46-6202	Ball Bearing	9.01

G46-6204	Ball Bearing	6.65
G46-6205	Ball Bearing	8.35
G46-6206	Ball Bearing	7.02
G46-7101	Ball Bearing	18.05
G46-7102	Ball Bearing	8.28
G46-7105	Ball Bearing (B)	6.08
G46-7106	PINION BALL BEARING (B)	6.81
G46-7107	Ball Bearing	10.52
G46-7302	Ball Bearing	15.50
G46-7305	Ball Bearing	12.03
G46-9004	Motor Gear A Ball Bearing	8.54
G46-9005	Ball Bearing (E)	8.10
G46-9007	Ball Bearing	8.22
G47-1501	Bearing Ret	1.61
G47-1601	Bail Spring Holder	1.04
G47-1602	Bail Spring Holder	0.82
G47-1701	Bail Spring	0.72
G47-1803	Bail Spring Shaft	3.09
G47-1805	Bail Spring Shaft	3.09
G47-2401	Bearing Retainer	0.72
G47-2501	Ball Bearing	18.05
G47-3401	Yoke Spring	0.50
G47-3501	R/S Plt Screw	0.50
G47-3704	Screw F	0.72
G47-5002	Counter Gear Washer	0.50
G48-1901	Ball Bearing	13.39
G48-2401	Ball Bearing	25.26
G48-5101	Pin A	0.50
G48-8801	Motor O Ring	0.60
G49-8503	Spool Ball Bearing	6.52
G49-8505	Ball Bearing B	11.12
G49-8510	Ball Bearing	8.41
G49-8511	Ball Bearing	9.95
G49-8512	Ball Bearing	8.41
G49-8513	SPOOL BALL BEARING	0.50
G50-0701	Electric Cam Pin	2.58
G50-0901	Pin	1.01
G50-1101	Ball Bearing	29.36
G50-2403	DRAG WASHER	6.81
G50-6201	L/S Plt Screw	3.34
G50-6301	Ring Plate Screw	2.52
G50-6401	Spool Gear Washer	0.76
G50-7101	Motor Holder Plate	29.20
G51-1501	Ball Bearing	12.29
G51-1503	Ball Bearing	9.01
G51-1504	Ball Bearing	5.42
G51-1506	Ball Bearing (A)	8.35

G51-1507	Ball Bearing	7.91
G51-2601	Collar A	0.79
G51-5201	Drag Lever Screw	1.76
G51-6604	Handle	208.69
G51-6606	Handle	84.83
G51-7301	Clutch Cam	0.60
G51-7401	Clutch Cam Plate	2.58
G51-7501	Clutch Trip Plt	0.82
G51-7601	Drive Shaft Ret	1.61
G51-7701	Clutch Cam Spring	1.45
G51-7801	Yoke	1.45
G51-8502	Right Set Plt	9.39
G52-0401	Drag Lever Metal Pin	1.76
G52-2101	Osc Gear Washer	0.54
G52-2103	Washer	0.76
G52-2702	Ball Bearing	6.08
G52-2705	Ball Bearing	12.76
G52-2706	Ball Bearing	6.68
G52-2802	Ball Bearing	7.21
G52-2803	Ball Bearing	12.76
G52-2901	Bearing Ret	1.20
G52-3401	Ball Bearing	2.77
G52-3403	Ball Bearing	10.49
G52-3405	Ball Bearing (F)	4.38
G52-3406	Ball Bearing	12.03
G52-4801	Bearing Ret	1.61
G52-5101	Bearing Ret	0.66
G52-6801	Clutch Cam Spring	0.57
G52-7901	Stabilizer Bar	2.21
G52-9501	SIDE RING WASHER	0.79
G52-9503	SIDE RING WASHER	1.13
G53-4101	Power Module	500.10
G53-5104	Ball Bearing A	9.67
G53-5105	Ball Bearing (C)	9.39
G53-5106	Ball Bearing	11.69
G53-6001	Ball Bearing	16.60
G53-7701	Spool Transmission Gear B	76.59
G53-8003	Ball Bearing	7.37
G53-8007	Ball Bearing (D)	10.05
G53-8503	L/S Plt	18.72
G53-8701	Idle Gear	4.60
G53-8801	Dial Holder	0.50
G53-9401	Clutch Trip Plt Washer	0.50
G53-9402	Washer	0.50
G54-5001	Gear Shaft Collar	10.84
G55-7101	Screw	0.50
G55-7111	Left Side Plate Screw	1.01

G56-1901	Spool Gear Bushing A	6.58
G56-2001	Drag Collar Washer	1.26
G56-2201	Sleeve	32.04
G56-2301	Eccentric Cam Screw	18.08
G56-2401	Drag Ring	5.80
G56-4904	Line Guide	11.97
G56-4907	Level Wind	11.50
G57-2500	PINION BEARING(B) SPRING WASHER	0.68
G57-8501	Washer	0.50
G57-8502	Spring Washer	0.50
G58-0701	Level Wind	7.65
G58-1702	SPOOL BEARING WASHER	1.42
G58-8601	Click Leaf Spring Holder	0.88
G59-1501	OSCILATING GEAR	1.83
G59-3101	Pinion Gear	7.81
G59-7101	Ball Bearing	33.70
G59-7901	Drive Gear	27.41
G60-3401	Click Button	8.16
G60-3601	Drive Shaft Ret	6.43
G60-3602	Drive Shaft Retainer	7.21
G60-3701	Yoke Plt	2.39
G60-3801	Yoke	5.92
G60-3802	Yoke	4.28
G60-3901	A/R Ratchet	2.58
G60-4001	Drag Washer B	0.50
G60-4301	Key Washer	1.98
G60-4401	Eared Washer	1.48
G60-5201	Clutch Lever Collar	0.72
G60-8901	Clutch Spring	1.80
G60-9002	R/S Plt	23.27
G60-9201	Handle Nut Plate Screw	0.50
G61-0104	OSCILLATING GEAR WASHER	0.68
G61-1501	Side Cover Plate Screw	0.50
G61-3101	Bail Trip Lever Spring	0.50
G61-3400	DRIVE BEARING (B) WASHER	2.04
G61-3403	Washer	1.01
G61-3404	Washer (G)	0.95
G62-4102	Drag Washer Collar	4.28
G62-5301	Drag Spring Washer	3.28
G62-6201	DRIVER	2.38
G62-7701	Screw	0.50
G63-0506	Rotor	3.12
G63-4603	Handle Nut	15.72
G63-7801	Motor Gear(A)Bearing	0.76
G64-3501	Spool Gear Pin	0.50
G64-4201	Washer	0.98
G64-4203	Washer	0.95

G64-4302	Osc Gear	4.35
G64-5301	O Ring	0.50
G64-5600	DRIVE BEARING (B) WASHER	1.70
G64-5603	Washer	0.57
G64-6201	Bail Spring	0.50
G65-6801	Body	67.61
G65-6901	Handle	37.88
G65-7001	Spool	57.85
G65-7201	Line Clip	2.90
G65-7301	Drag Knob	22.21
G66-8001	Handle	17.77
G67-0501	O Ring	0.79
G67-2401	Idle Gear O Ring	0.60
G67-3101	Brake Adj Knob	9.58
G67-3301	Idle Gear B	1.80
G67-3401	Gear Shaft	10.84
G67-3501	Pre-Set Drag Retainer	1.01
G67-3601	Idle Gear C	35.03
G67-3901	Idle Gear	8.32
G67-4001	Idle Gear	5.29
G67-4101	Motor Gear Hi	19.66
G67-4401	Motor Gear Low	19.66
G67-4901	Spool Shaft	6.30
G67-5001	Spool Shaft Gear	4.95
G67-5101	Spool Shaft Gear Collar	0.91
G67-5201	Spool Gear	4.50
G67-5801	Spool Transmission Gear B	57.61
G67-6001	Spool Plate	19.91
G67-6501	Motor Holder	12.16
G67-6601	Worm Shaft	17.17
G67-7101	Worm Shield	4.28
G67-7201	Level Wind Post	1.76
G67-7301	Drive Shaft	10.33
G67-7401	Frame Screw A	4.54
G67-7501	Pinion Gear Bushing	5.80
G67-7601	Pinion Gear	20.27
G67-7801	Ratchet	3.28
G67-7901	Drive Gear	10.33
G67-8001	Drive Shaft Collar	25.77
G67-8101	Handle	19.21
G67-8901	Handle Nut Plate	5.32
G67-9101	Set Plate	12.35
G68-0401	Star Drag	14.36
G68-0402	Star Drag	12.66
G68-0501	Handle	36.18
G68-2301	Handle Nut	3.21
G68-2302	Handle Nut	2.99

G68-3301	O Ring A	1.07
G68-4801	Washer	0.50
G68-5301	Bail Spring	0.50
G68-5401	Bail Spring Washer	0.50
G68-6702	Line Roller	6.17
G68-6703	Line Roller	6.11
G68-6903	Ball Bearing	11.78
G68-6904	Ball Bearing	9.01
G69-1302	Finger Guard	7.25
G69-1801	Ic Module Cover	9.07
G69-1901	Right Side Cover Screw	3.53
G69-2001	R/S Plate	32.12
G69-2002	R/S Plate	44.61
G69-2201	Right Side Cover Screw	1.45
G69-4001	Click Leaf Spring Holder	2.39
G69-4201	Washer	4.91
G69-7601	Drag Collar Shield	1.61
G70-0601	Key Washer	1.29
G70-0701	Eared Washer	1.26
G70-4801	Star Drag	9.39
G70-4802	Star Drag	10.99
G70-5101	Frame	57.97
G70-5501	Handle	15.09
G71-1001	Clutch Cam Lever Bushing	2.33
G71-2401	Washer	0.66
G71-7501	Pin	1.29
G72-0001	Worm Shaft Bushing	0.50
G73-0401	Set Plate	30.74
G73-0802	IDLE GEAR	28.33
G73-1501	Set Plate	12.60
G73-1601	Spool	63.65
G73-1901	Spool Shaft	10.11
G73-2201	Spool Shaft Gear	8.54
G73-2901	Spool Plate	26.21
G73-3501	Spacer	0.69
G73-3601	Spacer	0.76
G73-3701	Pinion Gear Bushing	2.27
G73-3801	Clutch Cam Lever	4.82
G73-3901	Clutch Cam	1.26
G73-4001	Clutch Cam Plate	3.53
G73-4101	Level Wind	9.64
G73-4301	Motor	127.12
G73-4601	Motor Holder	9.29
G73-4701	Finger Guard	8.06
G73-4801	Drive Shaft	9.07
G73-4901	Drive Gear	7.40
G73-5001	Drag Washer	10.74

G73-5101	Pinion Gear	7.73
G73-5201	Clutch Plate	1.26
G73-5501	Drag Collar	15.37
G73-5701	Ic Module Cover	8.06
G73-6201	O Ring B	1.20
G74-0402	Line Roller	7.15
G74-0405	Line Roller	4.66
G74-0501	Roller Packing	1.67
G74-0601	Roller Bearing Collar	3.84
G74-0701	Roller Collar	1.51
G74-3003	Spacing Sleeve	7.21
G74-7401	Spool Collar	0.50
G75-1001	Drive Shaft Plate	1.76
G75-1002	GEAR SHAFT PLATE	3.40
G75-2401	Set Plate Screw	0.66
G75-2601	Right Side Cover Screw	0.76
G75-2602	R/S PLATE SCREW (A)	0.99
G75-2701	Right Side Cover Screw	1.67
G75-4301	Clutch Lever Plt A	1.01
G75-4601	Clutch Lever	13.01
G75-4605	Clutch Bar	8.91
G75-4801	Clutch Cam Plt	2.58
G75-4802	Clutch Cam Plate	4.50
G75-4901	Clutch Trip Plt	1.20
G75-5001	Drive Shaft	25.74
G75-5002	Drive Shaft	22.37
G75-5101	Drive Shaft Ret	1.61
G75-5201	Washer	0.50
G75-5203	Washer	0.50
G75-5301	Clutch Cam Spring	1.23
G75-5401	Clutch Trip Plt Spring	0.60
G75-5703	Level Wind	26.43
G75-5704	Level Wind	26.11
G75-6101	Drive Gear A	7.54
G75-6201	Drive Gear B	10.25
G75-6301	Ball Bearing	5.04
G75-6802	Front Plt	11.91
G75-7002	Magnet Set Plate	41.00
G75-7401	Brake Adj Knob	8.28
G75-7402	Brake Adj Knob	5.95
G75-7701	Magnet Holder	10.58
G75-7702	Magnet Holder	17.61
G75-7801	Magnet Holder Ret	0.60
G76-0202	Cast Control Cap	6.11
G76-0302	Set Plate	25.96
G76-0501	Collar	1.13
G77-2101	Gear Spring Washer	0.50

G77-4711	Cast Control Cap	22.24
G77-4719	Cast Control Cap	28.50
G77-5114	Star Drag	16.07
G77-9001	Mechanical Brake Knob Ret	0.50
G77-9101	Handle Screw	4.91
G78-0603	Spool	63.76
G78-1401	Left Side Plate	12.94
G78-1402	L/S Plt	11.79
G78-1501	Handle	21.63
G78-1601	Frame	15.21
G78-1701	Frame	21.85
G78-1902	Frame	20.36
G78-2601	Frame	25.40
G78-5801	Set Plate Screw	0.66
G78-6102	OSILLATING SLIDER SCREW	1.70
G79-0001	Clutch Cam Plt	3.28
G79-0101	Clutch Trip Plt	1.76
G79-0209	Drive Shaft	30.46
G79-0210	Drive Shaft	31.75
G79-0401	Clutch Cam Spring	1.80
G79-0501	Clutch Trip Plt Spring	0.91
G79-0601	Pinion Gear	17.18
G79-0701	Worm Shaft	15.88
G79-0901	Clutch Wheel	16.38
G79-1201	Drive Gear	8.08
G79-1302	Eared Washer	3.59
G79-1402	Drag Washer A	6.30
G79-3301	Handle Nut	5.36
G79-3302	Handle Nut	4.91
G79-3309	Handle Nut	5.64
G79-3310	Handle Nut	6.99
G79-3312	Handle Nut	6.36
G79-3313	Handle Nut	6.36
G79-3314	Handle Nut	2.14
G79-3316	Handle Nut	5.51
G79-3317	Handle Nut	5.51
G79-3318	Handle Nut	6.02
G79-3319	Handle Nut	6.02
G79-3322	HANDLE NUT	6.13
G79-3323	HANDLE NUT	0.50
G79-3324	HANDLE NUT	0.50
G79-3325	HANDLE NUT	0.50
G79-3326	HANDLE NUT	0.50
G79-3327	HANDLE NUT	0.50
G79-4111	Plate (A)	7.69
G79-4112	Plate (A)	7.02
G79-4122	Plate (A)	7.02

G79-4123	Plate (A)	7.02
G79-5711	Plate (B)	6.46
G79-5712	Plate (B)	7.69
G79-5722	Plate (B)	7.69
G79-5723	Plate (B)	7.69
G80-0701	O-Ring	0.91
G80-1701	Clutch Cam Plt	2.58
G80-1801	Clutch Trip Plt	1.42
G80-1901	Drive Shaft Ret	2.02
G80-2001	Clutch Cam Spring	1.01
G80-2101	Pinion Gear	17.18
G80-2201	Clutch Wheel	16.38
G80-2301	Drive Gear	7.56
G80-3505	GEAR SHAFT PLATE SCREW	0.50
G80-7502	R/S Plt	25.09
G81-0402	Motor	24.44
G81-1501	Spool	120.27
G81-1505	Spool	66.56
G81-1701	Spool Shaft	11.12
G81-1801	Spool Transmission Gear	34.99
G81-1901	Motor	30.79
G81-2001	Drive Gear	10.33
G81-2102	Line Guide	8.63
G81-3601	Clutch Cam Plt A	2.58
G81-3701	Clutch Trip Plt	1.20
G81-3801	Drive Shaft Ret	1.61
G81-4101	Drive Gear B	15.07
G81-4202	Front Plt	13.01
G81-4501	Right Set Plt	28.95
G81-5201	Worm Shaft	16.03
G81-8901	Ball Bearing A	14.74
G81-8902	Ball Bearing	10.27
G81-9801	Roller Clutch	23.09
G82-3801	Washer	0.50
G82-5201	Gear Shaft Collar	8.95
G82-9001	Drag Collar	6.62
G82-9401	Frame	69.95
G82-9801	L/S Plt	38.48
G83-0001	Frame	82.57
G83-0201	Click Spring	0.76
G83-0301	Click Lever	3.87
G83-0401	Click Pawl	2.87
G83-0501	Yoke Plt	6.46
G83-0801	Drive Gear	7.91
G83-1702	Anti-Reverse Holder	5.89
G83-4701	Worm Shaft	16.35
G83-5401	Worm Shaft	27.12

G83-5501	Handle Nut Plate Screw	0.50
G83-5502	Screw	2.87
G83-5504	HANDLE LOCK PLATE SCREW	4.08
G83-6401	Anti Reverse Cam Spring	0.50
G83-7101	Screw	0.72
G83-8801	Bail Arm	1.80
G83-8826	Bail Arm	1.80
G83-9301	Click Gear	0.50
G84-0501	Drag Knob	6.14
G84-1301	Oscillating Gear	0.76
G84-1403	Main Shaft	3.91
G84-1957	Rotor	2.64
G84-1963	Rotor	4.57
G84-2104	Bail Spring Cover	0.50
G84-3501	Main Shaft	4.00
G84-4148	Rotor	3.16
G84-4150	Rotor	4.98
G84-4152	Rotor	5.43
G84-4153	Rotor	5.60
G84-4201	Bail Trip Lever	1.29
G84-4302	Cover	1.80
G84-4303	Arm Lever Cover	2.87
G84-4304	Bail Spring Cover	0.50
G84-5601	Roller Clutch	5.70
G84-6201	Brake Dial Retainer	0.69
G84-8201	Clamp Screw	6.05
G85-0301	Yoke Spring	0.57
G85-0701	Washer	0.50
G85-0702	STOPPER WASHER	0.68
G85-0901	Worm Shaft	22.40
G86-0603	Main Shaft	6.30
G86-1150	Rotor	2.32
G86-1201	Bail Trip Lever	1.07
G86-1304	Bail Spring Cover	0.50
G86-3501	Drive Shaft Washer	8.85
G86-3901	HANDLE SCREW WASHER	0.72
G86-4801	MOTOR GEAR(B) SPRING WASHER	0.68
G86-8701	Power Cord	39.06
G86-9601	O Ring	0.66
G87-0304	Drive Gear	57.77
G87-4201	Collar	0.50
G87-4301	Collar B	0.50
G87-5001	HANDLE ARM	20.22
G87-5801	Screw	3.18
G87-8201	Line Guard Spring Washer	1.39
G87-8301	Drive Shaft Washer	11.59
G88-9301	Collar	0.57

G89-2201	Bail	3.20
G89-3301	Clutch Lever	5.73
G89-6901	Motor O Ring	1.26
G89-7101	Pinion Gear	11.09
G89-7401	Pinion Gear	11.09
G89-8301	O Ring	0.66
G90-3601	Left Side Plt Screw	0.50
G90-3901	Washer	1.01
G90-3902	Spool Washer	1.13
G90-4201	Right Side Plate Screw	0.63
G90-4701	Spool	11.25
G90-5201	Spool	14.47
G90-6701	Bail	4.45
G90-8001	Ball Bearing	2.74
G90-8602	Drive Gear	2.32
G91-3306	KICK LEVER PLATE(B) SCREW WASHER	4.77
G91-5601	STOPPER	7.49
G91-9201	Handle	108.53
G92-4302	Drive Gear	5.17
G92-5101	Handle	16.44
G92-6101	Gear Shaft Collar	10.80
G92-7001	Anti Reverse lever	0.79
G93-0501	Roller Clutch	7.21
G93-1001	Pinion Shaft	1.61
G93-1101	Right Side Plate Screw	4.50
G93-1405	Frame	10.56
G93-1601	Clutch Cam	1.01
G93-1701	Clutch Cam Spring	0.50
G93-1801	Clutch Lever	0.98
G93-1802	Clutch Lever	0.76
G93-1901	Clutch Cam	3.02
G93-2001	Clutch Trip Lever	2.90
G93-2101	Clutch Cam Spring	0.50
G93-2201	Drive Gear A	0.50
G93-2401	Drive Shaft Retainer	1.51
G93-2501	Idle Gear	0.72
G93-2801	Bushing	0.50
G93-2906	Lever	17.96
G93-3101	Bushing (B)	0.50
G93-3202	Twitching Bar Plate	0.50
G93-3401	Lever Spring	0.50
G93-3501	Yoke	0.50
G93-3701	Line Guide	4.82
G93-4201	Level Wind Guard	1.01
G93-4301	Clutch Wheel	1.29
G93-4401	Drive Shaft Washer	0.50
G93-4601	Drag Washer	1.04

G93-4701	Key Washer	2.02
G93-4801	Gear Shaft Collar	3.37
G93-4802	Gear Shaft Collar	4.91
G93-5903	Front Cover	4.63
G93-6002	Left Side Plate	7.07
G93-6218	Brake Adjusting Knob	2.30
G93-6301	Bearing Retainer	0.50
G93-9301	Screw	0.50
G93-9901	Worm Shaft	14.08
G94-0401	Screw	7.62
G94-0402	Screw	0.50
G94-0403	OSCILLATING GEAR SCREW	0.68
G94-0404	Idle Gear (A) Screw	0.66
G94-0405	Screw	0.66
G94-0406	Screw	1.67
G94-0407	SCREW	4.96
G94-4501	Spring	0.50
G94-5801	Ic Module Cover Screw	1.67
G94-5806	LS PLATE SCREW(A)	5.11
G94-5813	Ic Module Cover Screw	1.67
G94-5819	RS PLATE SCREW (B)	0.50
G94-6801	Screw	1.54
G94-6802	Screw	3.56
G96-1301	Drive Shaft Collar	2.33
G96-9901	Handle Nut Plate	4.13
G96-9902	Handle Nut Plate	5.04
G97-2601	Cam	0.98
G97-4305	Frame	8.30
G97-4401	Clutch Cam (A)	0.50
G97-4501	Clutch Cam Spring (A)	0.50
G97-4601	Clutch Cam (B)	3.02
G97-4701	Clutch Cam Lever	3.59
G97-4801	Clutch Cam Spring (B)	0.50
G97-5006	Lever	16.85
G97-5101	Lever Spring	0.50
G97-5201	Pinion Yoke	0.50
G97-5503	Front Cover	3.59
G97-5829	Body	2.83
G97-5923	Side Cover	0.50
G97-7803	Rear Cover	0.76
G98-0501	Screw	0.50
G98-0701	Anti Reverse Cam	0.66
G98-0801	Pinion Gear	7.22
G98-0803	Pinion Gear	1.87
G98-0804	Pinion Gear	2.83
G98-0805	Pinion Gear	3.03
G98-1001	Anti Reverse Claw Collar	6.30

G98-1101	Anti Reverse Claw Spring	0.50
G98-1201	Anti Reverse Claw	0.63
G98-1701	Collar	3.87
G98-4126	Body	2.83
G98-4913	Side Cover	1.17
G98-4921	Side Cover	1.17
G98-5003	Rear Cover	0.76
G98-5101	Oscillating Gear	0.76
G98-6226	Body	2.99
G98-6301	Oscillating Gear	0.76
G98-6401	Pinion Gear	5.84
G98-6402	Pinion Gear	3.46
G98-6521	Side Cover	1.33
G98-6603	Rear Cover	0.76
G98-8901	Frame	57.95
G99-7001	Screw	0.50
G99-7301	Screw	0.57
G99-7503	Screw	1.23
G99-7701	Screw	0.50
G99-8401	Screw	9.89
H00-1703	Line Guide	3.91
H00-2115	Star Drag	3.06
H00-2401	Stabilizer Bar	0.76
H01-8212	Body	2.48
H01-8301	Anti-Reverse Cam	0.66
H01-8401	Anti-Reverse Lever	0.85
H01-8501	Ocillating Gear	1.42
H01-8601	Main Shaft	6.17
H01-8901	Pinion Gear	6.21
H01-9001	Anti Reverse Claw Spring	0.57
H01-9101	Anti Reverse Claw Collar	0.85
H01-9201	Anti Reverse Claw Spring	0.50
H01-9301	Anti-Reverse Pawl	0.98
H01-9401	Drive Gear	8.41
H01-9501	Bearing Retainer	0.50
H01-9612	Side Cover	1.17
H01-9701	Rear Cover	6.17
H01-9703	Rear Cover	1.01
H01-9828	Rotor	2.32
H01-9901	Bail Spring	0.60
H02-0001	Bail Trip Lever	0.98
H02-0101	Bail Arm	1.95
H02-0201	Cover	3.09
H02-0203	Bail Spring Cover	0.50
H02-0301	Bail	3.46
H02-1701	Drag Knob	3.09
H02-2001	Collar	0.85

H02-2701	Line Guard Screw	0.50
H02-2901	Pin	1.13
H02-3102	Induct Rotor	24.48
H02-3104	Induct Rotor	24.48
H02-9101	Pinion Gear	4.69
H02-9702	Magnet Holder	9.70
H02-9901	Spring	0.85
H03-3001	Drag Washer	10.11
H03-3002	Drag Washer B	5.04
H03-5503	Collar	0.57
H03-6301	O Ring	1.17
H03-6801	Pre-Set Drag Spring	1.01
H03-8301	Packing (B)	1.73
H04-1501	Ic Module	370.23
H04-7201	Retainer	0.50
H04-9901	Collar	0.82
H05-0001	Rotor Nut	2.49
H05-0101	Collar	0.54
H05-0601	Click Leaf Spring Holder	0.66
H05-7401	Ic Module	367.18
H06-9601	Right Side Plate	32.06
H07-0101	Pinion Gear	8.47
H07-0201	Drive Shaft	17.23
H07-0401	Drive Gear	10.58
H07-0501	Star Drg	10.46
H07-0901	Handle Nut	5.04
H07-0902	Handle Nut	6.11
H07-1001	Left Side Plate	14.49
H07-1501	Left Side Outer Ring	5.29
H07-1502	Left Side Outer Ring	8.16
H07-1601	Frame	30.48
H07-1701	Set Plate	28.95
H07-1901	Magnet Holder	17.01
H07-4801	Brake Adjusting Knob	4.38
H07-8001	Motor Gear Shaft O'ring	1.67
H08-4401	Brake Click Spring	0.50
H08-6201	Brake Clicking Spring	0.69
H08-6701	Ic Module	380.28
H08-6901	Spool	86.41
H08-7101	Spool Shaft	11.31
H08-7301	Motor Holder	9.89
H08-7401	Worm Shaft	42.24
H08-7601	Worm Shield	5.99
H08-7801	Finger Guard	15.18
H08-7901	Ic Module Cover	16.25
H08-8001	R/S Plate Screw A	8.63
H08-8101	R/S Plt Screw B	2.55

H08-8201	Frame Screw A	4.82
H08-8301	Frame	19.07
H08-8710	Handle Knob	15.72
H10-0001	O Ring	0.91
H10-2301	Anti-Reverse Cam Spring	1.76
H10-5602	Bail Spring Shaft	0.50
H10-5801	Bail Spring	0.85
H11-0101	Ball Bearing C	4.66
H11-2501	Idle Gear D	9.20
H11-2601	Idle Gear E	4.60
H11-2901	Spool Shaft Gear	10.33
H11-3501	Idle Gear C	37.45
H11-3601	Motor Gear Hi	22.52
H11-3701	Motor Gear Low	22.52
H11-4401	Spool Adj Cap 'O' Ring	1.13
H11-8402	DRAG WASHER	6.47
H11-8501	Washer F	0.50
H12-0301	Screw	0.50
H12-9200	OSCILLATING GEAR WASHER	1.16
H12-9201	Washer F	1.04
H12-9204	POWER LEVER WASHER	0.68
H13-4501	Handle Arm	15.62
H13-8103	Frame	6.66
H13-9303	Palming Plate	6.14
H13-9401	Finger Cover	2.99
H13-9501	Drive Shaft	2.74
H13-9502	Drive Shaft	2.74
H13-9601	Drive Gear	7.97
H13-9701	Pinion Gear	3.73
H13-9801	Clutch Lever	1.83
H14-0006	R/S Plate	3.90
H14-0201	Bearing	0.91
H14-0305	L/S Plate	6.46
H14-4301	Spool Pawl	0.50
H14-4801	A/R Ratchet	14.74
H14-6001	A/R Ratchet	23.06
H14-7101	Clutch Trip Plate	1.35
H14-7201	Drive Shaft Retainer	2.02
H14-7401	Drive Gear B	9.72
H15-6501	Plate	7.34
H15-6901	Drive Shaft O'ring	1.35
H15-7002	"O" Ring	0.91
H15-7301	Drive Collar Pin	2.33
H15-7403	Drive Collar Sp	0.50
H15-8201	Sensor Screw (B)	0.50
H15-8601	Gear Shaft	37.42
H15-9201	Washer (C)	0.54

H15-9202	CLUTCH CAM PLATE SCREW WASHER	4.77
H15-9501	Collar B	6.55
H15-9502	Collar (B)	10.71
H15-9503	Pinion Gear Bushing	17.55
H15-9601	Pinion Shaft	1.54
H16-0101	Right Side Plate Sc	1.07
H16-0102	Right Side Plate Screw B	4.35
H16-0801	Bearing Retainer	0.50
H16-0901	Click Leaf Spring B	1.32
H16-1001	Spacer	0.57
H16-1002	Zero Adjuster Washer A	1.01
H16-6601	Star Drag	21.32
H16-7801	Spool Induct Rotor	12.69
H16-8601	Line Guide Pawl	7.62
H16-8701	Line Guide Collar	0.91
H16-9001	Balancer	0.79
H17-1201	A/R Pawl Spring	0.50
H17-1301	A/R Pawl	2.68
H17-1401	Screw (C)	0.50
H17-2601	Bearing Ret (A)	1.32
H17-2703	Spacing Sleeve	26.33
H17-2802	Drive Gear	2.60
H17-2803	Drive Gear	3.71
H17-3101	A/R Spring Holder	1.01
H17-3201	A/R Pawl Collar	0.66
H17-3311	Rotor	7.18
H17-3313	Rotor	10.89
H17-3316	Rotor	10.89
H17-3401	Bail Trip Lever	1.01
H17-3502	Bail Arm	1.01
H17-3505	Bail Arm	1.01
H17-3601	Cover	3.34
H17-3603	Arm Lever Cover	1.92
H17-4201	Click Leaf Spring Holder	0.72
H17-5101	Key Washer	0.69
H17-6201	Gear	1.20
H17-6501	O Ring	1.83
H17-6801	Screw C	0.50
H17-9601	Yoke Plate Spring	1.04
H17-9701	Clutch Trip Plt Spring	0.91
H18-0501	Pinion Ball Bearing Ret	0.91
H18-0601	Bearing Retainer	0.50
H18-1803	Frame	12.51
H18-2301	Finger Cover	5.04
H18-2403	Palming Cover	4.85
H18-2501	Drive Gear	7.18
H18-2601	Pinion Gear	4.59

H18-2701	Clutch Cam Lever	1.83
H18-2806	L/S Plate	6.99
H18-2905	R/S Plate	6.46
H18-5201	Bearing	0.50
H18-6301	Pin	2.27
H19-0001	Washer	4.38
H19-1101	Collar (B)	2.36
H19-1601	Bail Assembly	10.21
H19-4501	Motor	32.41
H19-4701	Collar D	1.07
H19-7601	Washer	4.91
H21-3601	Cast Control Cap	7.94
H21-3602	Cast Control Cap	6.99
H21-3603	Front Cover	2.17
H21-8601	Bail Assembly	6.85
H22-2501	Bail Assembly	7.26
H22-3201	Bail Assembly	5.15
H22-5801	Pinion Shaft	1.54
H22-6303	Gear Shaft	39.75
H22-6501	Gear Ryoga 2020	1.54
H22-8501	Gear Ryoga 2020	1.54
H22-9401	Spool Gear Ryoga	1.54
H23-8605	Star Drag	18.90
H23-8613	Star Drag	18.16
H24-3001	Oscillating Gear B	2.55
H24-3101	Oscillating Gear A	0.69
H24-3201	Anti-Reverse Pawl	2.74
H24-3301	Collar G	0.50
H24-3701	Collar F	0.50
H24-3901	Collar	0.69
H24-4001	Clutch Cam Retainer	0.91
H24-4202	Roller Clutch Retainer	1.83
H24-4401	Spring	0.50
H24-4501	Bearing Retainer A	1.45
H24-5002	Rotor	4.04
H24-5402	Bail Arm	4.41
H24-5602	Bail Holder Nut	6.46
H24-5702	Bail	53.12
H24-6103	Line Roller	8.63
H24-7201	Drag Washer	5.23
H24-7202	Drag Washer	7.25
H24-7205	Drag Washer	7.34
H24-7601	Clutch Cam	0.69
H25-5001	O Ring	0.79
H25-7003	HANDLE LOCK PLATE SCREW	3.40
H26-4401	Bail Trip Lever Spring	0.50
H26-6601	Collar	6.58

H26-6801	Clutch Cam Plate B	8.35
H27-0401	A/R CLAW	6.39
H27-1201	Collar D	0.72
H27-2201	Screw	0.50
H27-2202	Screw	0.50
H27-8405	Handle Knob	13.51
H27-8804	Handle Knob Screw B	8.16
H28-1201	Cast Control Cap	5.10
H28-3601	Plate	5.67
H28-3605	HANDLE LOCK PLATE	5.45
H28-3607	Handle Lock Plate	6.02
H29-4101	Screw	0.50
H29-5201	Washer H	0.50
H30-2101	Handle	24.66
H30-6600	Washer B	0.50
H30-6601	WASHES B	0.50
H30-9501	Click Leaf Spring Holder	0.69
H31-6602	Drive Shaft Pin	0.91
H31-8304	Collar	5.73
H31-8501	Handle Knob Screw A	7.31
H31-8502	Handle Knob Screw A	9.73
H32-3001	Oscillating Gear B	1.67
H32-3101	Oscillating Gear A	0.79
H32-3501	Collar F	0.69
H32-3701	Click Leaf Holder	0.69
H32-4402	Rotor	23.74
H32-4701	Bail Spring Shaft	2.30
H32-4801	Plate	1.07
H32-4901	Rotor Brake Spring Cover	2.99
H32-5001	Bail Holder Nut	4.95
H32-5401	Bail Spring Cover	2.99
H32-6601	Stopper	6.39
H33-7201	Worm Shaft Assembly	19.50
H33-8401	Handle Nut	5.73
H33-9401	Anti-Reverse Pawl	2.99
H33-9602	Bail Arm	5.76
H34-3401	DRIVE GEAR WASHER	7.15
H34-5301	Bail Spring	0.50
H34-7101	Screw I	0.50
H34-9202	Drive Gear B	9.37
H35-0302	Drive Gear B	7.81
H35-1001	SPOOL SHAFT GEAR(B)SPRING WASHER	0.58
H35-2101	DRAG ADJ COLLAR	1.04
H35-2801	Washer	1.23
H35-2803	MOTOR GEAR(A) WASHER	1.02
H35-4301	Anti-Reverse Pawl	1.26
H35-4401	Collar	0.57

H35-4504	Anti-Reverse Lever	2.80
H35-4701	Collar G	0.50
H35-4801	Collar	0.50
H35-4901	Stabilizer Bar	1.42
H35-5001	Worm Shaft Retainer	0.57
H35-5201	Spacing Sleeve	4.63
H35-5301	Clutch Cam Retainer	1.42
H35-5401	Collar E	2.52
H35-5501	Bearing Retainer	1.95
H35-5601	Oscillating Slider	0.91
H35-5701	Oscillating Pawl	3.37
H35-5801	Collar I	0.50
H35-5901	Main Shaft	6.80
H35-6001	Oscillating Slider Cover	0.85
H35-6201	Anti-Reverse Pawl Spring	0.50
H35-6501	Rear Cover	3.94
H35-6502	Rear Cover	4.35
H35-6604	Rotor	6.81
H35-6612	Rotor	6.64
H35-6701	Bail Spring Holder Shaft	1.42
H35-6801	Bail Spring Holder	0.63
H35-6904	Bail Arm	3.09
H35-6907	Bail Arm	2.80
H35-6908	Bail Arm	3.09
H35-7002	Cover	3.09
H35-7101	Bail	64.23
H35-7401	Collar B	0.50
H35-7501	Line Guard	7.43
H35-7502	Line Guard	5.10
H35-7601	Handle	28.31
H35-8401	Drag Knob	5.99
H35-8801	Spool Pin	1.61
H35-9001	Drag Washer	7.59
H35-9002	Drag Washer	5.42
H35-9901	Worm Shaft	8.13
H36-5025	Ic Module	65.01
H36-5107	Ic Module	65.97
H36-5301	Bail	59.90
H36-5601	Retainer	0.50
H36-8001	Body	49.82
H36-8101	Side Cover	14.35
H36-8201	Handle	58.73
H36-8301	Spool	61.77
H36-8601	Drag Knob	10.11
H37-3601	Body	39.24
H37-3901	Pinion Gear	10.80
H37-4001	Drive Gear	9.64

H37-4201	Handle	55.68
H37-4301	Spool	60.23
H37-4601	Drag Knob	7.94
H37-4701	Spool	55.86
H37-6801	Pinion Gear	10.80
H37-6901	Drive Gear	8.10
H37-7801	Ic Module	363.08
H37-7805	Ic Module	236.32
H37-8401	Spool	75.87
H37-8701	Spool Metal	2.08
H37-8801	Bail Trip Lever	1.83
H38-4701	Clutch Ring	19.72
H39-5701	Bail	61.83
H40-1101	Screw	4.85
H40-1201	ROTOR COVER SCREW	1.36
H40-8701	Drive Gear	2.38
H40-8801	Click Pawl	1.95
H40-8901	Pinion Gear	17.61
H40-9001	Worm Shaft Gear	1.13
H41-0001	Anti-Reverse Cam	6.90
H41-0002	A/R Cam	9.01
H41-0101	Anti-Reverse Lever	5.86
H41-0103	Anti-Rev Lever	4.60
H41-0106	A/R Lever	1.61
H41-0114	A/R Lever	5.17
H41-0201	Anti-Reverse Cam Spring	0.79
H41-0401	Oscillating Gear	7.12
H41-1201	Collar G	3.56
H41-1301	Spring Washer	1.04
H41-1401	Washer C	0.50
H41-1402	Washer C	0.57
H41-1501	Bearing Retainer A	1.54
H41-2201	Bail Trip Plate	1.04
H41-2308	Side Cover	26.10
H41-2401	Washer G	0.69
H41-2501	Spacing Sleeve	10.87
H41-2602	Roller Clutch	26.08
H41-3001	O Ring A	0.79
H41-3201	Screw F	0.50
H41-3301	Packing	3.21
H41-3401	Rear Cover	4.60
H41-3601	Bail Trip Lever Spring	0.50
H41-3701	Bail Trip Lever	3.09
H41-4101	Bail Spring Shaft	0.50
H41-4201	Bail Spring	0.50
H41-4301	Bail Spring Holder	0.60
H41-4601	Cover A	2.99

H41-5701	Rotor Nut Packing	1.04
H41-5901	Spool Metal	5.51
H41-6001	Click Holder	1.04
H41-6101	Click Leaf Spring	1.07
H41-6301	Drag Collar	1.80
H41-7201	Handle Screw Cap	4.38
H41-7701	Screw B	0.50
H41-8201	Drag Knob	19.97
H41-9701	Frame	21.83
H42-0301	Click Plate	1.80
H42-0401	Click Spring	1.45
H42-0501	Click Pawl	1.80
H42-0701	Frame Plate	2.74
H42-0702	Frame Plate	3.21
H42-0704	Frame Plate	3.53
H42-0801	Spool	44.55
H42-1101	Drag Washer	19.09
H42-1201	Spool Shaft	7.59
H42-1601	Drag Click Cap	2.17
H42-1701	Right Side Plate	16.89
H42-1705	Right Side Plate	24.05
H42-1706	Right Side Plate	23.27
H42-1711	Right Side Plate	33.70
H42-1714	RIGHT SIDE PLATE	19.62
H42-1715	RIGHT SIDE PLATE	22.59
H42-1716	Right Side Plate	17.45
H42-1718	Right Side Plate	17.94
H42-1801	Drive Shaft B	42.56
H42-1901	Drive Shaft Pin B	4.82
H42-2101	Drive Shaft Screw	4.82
H42-2201	Collar B	2.74
H42-2301	Drive Gear Collar	2.30
H42-2401	Drive Gear A	54.49
H42-2501	Drive Gear Collar	2.71
H42-2601	Drive Gear B	40.02
H42-2701	Drive Shaft Nut	5.51
H42-2801	Pinion Gear B	30.05
H42-3301	Drag Plate	8.44
H42-3401	Drag Ratchet	1.83
H42-3501	A/R Pawl Retainer	2.30
H42-3801	Washer E	0.50
H42-3901	Collar A	1.39
H42-4001	Drag Lever	26.18
H42-4501	Drag Lever Pin	1.39
H42-4601	Pre-Set Cam A	6.62
H42-4701	Pre-Set Cam B	9.20
H42-4801	Pre-Set Drag Knob	10.33

H42-4802	Pre-Set Drag Knob	13.77
H42-4803	Pre-Set Drag Knob	10.33
H42-5101	Collar C	8.51
H42-5201	Handle	53.55
H42-5503	Handle Knob	20.66
H42-5901	Handle Nut	5.04
H42-6001	Handle Button	3.43
H42-6101	Handle Cap A	1.13
H42-6201	Spring C	0.50
H42-6301	Plate	2.08
H42-6401	Handle Lever	5.04
H42-6701	Handle Cap B	16.32
H42-6801	Frame	23.31
H42-7001	Spool	46.49
H42-7201	Spool Shaft	7.59
H42-7901	Pre-Set Cam	31.53
H42-8301	SPRING	0.50
H42-8701	Ball Bearing A	16.70
H42-8801	Rotor Nut	2.74
H43-1001	Screw	0.69
H43-1201	Screw D	0.91
H43-1301	Screw C	0.91
H43-1701	Main Shaft	24.19
H43-4001	Body	6.64
H43-4101	Side Cover	2.99
H43-4401	Drag Knob	11.50
H43-4601	Spool	49.57
H43-4801	Spool	35.06
H43-4901	Handle	62.28
H43-5502	Spool	48.87
H43-5701	Drive Shaft B	29.58
H43-5801	Drive Gear	54.49
H43-5901	Drive Shaft Nut	5.51
H43-6303	Handle Arm	20.16
H43-6602	Spool	48.87
H43-7201	Main Shaft	17.58
H43-9801	Idle Gear A Collar	2.05
H43-9901	Idle Gear A	3.56
H44-0201	Spacer	0.69
H44-1501	Osc Gear	8.57
H44-2101	Bail Trip Plt	1.07
H44-2201	Bearing Retainer	1.51
H44-2202	Pinion Gear Bb Plate	2.02
H44-2401	Bail Spring	0.50
H44-2903	Side Cover	24.58
H44-3001	Packing	5.04
H44-3101	Rear Cover	7.21

H44-3301	Bail Trip Lever Spring	0.50
H44-3401	Bail Trip Lever	4.35
H44-3601	Bail Spring Shaft	0.50
H44-3801	Cover A	3.34
H44-6101	Packing	1.32
H44-8401	Bearing Retainer B	0.50
H44-8402	Retainer	3.50
H44-9003	Right Side Plate	79.60
H44-9301	Spring	1.01
H44-9505	Brake Knob	28.73
H44-9601	Frame	143.77
H44-9901	Kick Rever Plate	1.01
H45-0001	Clutch Cam Spring	1.70
H45-0101	Clutch Trip Lever	9.17
H45-0201	Clutch Cam	5.32
H45-0301	Clutch Lever Plate R	1.01
H45-0401	Clutch Lever Plate L	1.01
H45-0501	Clutch Lever	6.93
H45-0601	Clutch Cam Plate A	2.99
H45-0701	Clutch Cam Plate Washer	0.50
H45-0801	Clutch Cam Plate Sc	4.69
H45-0901	Worm Drive Gear	1.29
H45-1001	Frame Post	2.68
H45-1101	Level Wind	34.58
H45-1201	Worm Shield	8.35
H45-1301	Right Side Cover Plate	6.52
H45-1307	Right Side Cover Plate	4.35
H45-1501	Worm Shaft	11.09
H45-1601	Worm Shaft Gear	1.29
H45-1701	Pillar	6.36
H45-1801	Clutch Plate	0.66
H45-1901	Ratchet	5.80
H45-1902	Ratchet	3.69
H45-2001	Washer	5.51
H45-2101	Washer	0.66
H45-2601	Drag Washer	8.28
H45-2602	Drag Washer	8.22
H45-2701	Collar	26.74
H45-2801	O Ring	0.91
H45-3101	Handle Assembly	88.74
H45-3401	Side Plate Assembly	56.99
H45-3601	Side Ring	21.75
H45-3701	Ring	1.67
H45-3801	Washer	1.67
H45-3901	Dial	35.09
H45-4101	Mag Dial Plate	1.01
H45-4205	Left Side Cover	14.78

H45-4301	Mag Holder	22.40
H45-4501	Ring	1.01
H45-4901	Spool Collar	0.72
H45-5301	Left Side Plate O-Ring	1.01
H45-5401	Screw	0.50
H45-5402	Screw	0.50
H45-5406	Screw	0.66
H45-5407	Screw	0.66
H45-5408	Motor Cover Screw (A)	1.01
H45-5601	Ring	0.50
H45-8301	Clamp Bolt	5.04
H45-8302	Clamp Bolt	7.31
H45-8901	Oscillating Gear	7.12
H45-8902	Oscillating Gear	8.91
H45-9401	Collar G	3.43
H45-9901	Ring	0.69
H46-0106	Side Cover	26.96
H46-0601	Cover A	3.37
H46-1201	Packing	1.39
H46-3101	Anti-Reverse Cam	0.57
H46-3203	Anti-Reverse Lever	0.50
H46-3301	Anti Reverse Cam Spring	0.50
H46-3401	Screw K	0.50
H46-3701	Stabilizer Bar	1.04
H46-3901	Bearing Retainer A	0.50
H46-4001	Roller Clutch Retainer	1.26
H46-4301	Rear Cover	2.30
H46-4408	Rotor	2.09
H46-4503	Bail Arm	1.76
H46-9613	RIGHT SIDE PLATE	70.81
H46-9614	Right Side Plate	82.64
H47-0001	Left Side Plate (A)Collar	2.33
H47-0201	Worm Shaft	11.03
H47-0301	Worm Shaft Gear	1.20
H47-0401	Level Wind Post Sc	4.35
H47-0801	Drag Washer	7.69
H47-0901	Drag Disc Washer	4.00
H47-0902	Drag Disc Washer	2.33
H47-1001	Drag Lip Washer	2.33
H47-1002	Drag Key Washer	1.67
H47-1102	Drive Collar	26.08
H47-1702	Left Side Ring	23.06
H47-1801	Left Side Plate Ring	2.33
H47-1901	Left Side Gear (A) Collar	2.33
H47-2001	Left Side Gear (A)	1.29
H47-2101	Left Side Gear B	1.29
H47-2201	Left Side Gear (A) Sc	1.01

H47-2202	Left Side Plate Gear Scre	1.01
H47-2601	Packing	3.91
H47-2701	Rear Cover	4.60
H47-2702	Rear Cover	9.58
H47-3301	Clutch Cam Spring	1.70
H47-3401	Clutch Trip Lever	7.40
H47-4402	Handle Knob Cap	20.38
H47-5201	Handle	84.46
H47-6301	HANDLE KNOB CAP	5.65
H47-7202	LEFT SIDE PLATE GEAR SCREW B	1.01
H47-7501	Handle Screw	4.38
H47-7502	Handle Screw	5.17
H48-1901	Drag Lever Plate	5.04
H48-2001	Pinion Gear A	26.08
H48-2101	Metal	18.14
H48-2201	Drag Metal	15.12
H48-2301	Drag Plate	24.79
H48-4801	Drag Knob Spring	0.50
H48-5901	Click Button	4.35
H49-0501	Handle	11.95
H49-0701	Drive Gear	28.82
H49-0801	Pinion Gear	8.06
H49-0901	Drag Lever	6.90
H49-1001	Handle	48.85
H49-1101	Handle Screw	5.86
H49-2801	Drive Shaft Spring	0.50
H49-4808	Rotor	2.99
H49-5901	Rotor Nut	1.51
H49-6501	Collar A	0.50
H49-6802	Cover A	2.80
H49-6902	Cover B	2.80
H49-7401	Main Shaft	5.36
H49-9002	Frame	44.67
H49-9201	Spool	45.22
H49-9203	Spool	36.18
H49-9401	Spool Shaft	8.44
H50-0603	Body	63.12
H50-0802	Oscilating Pinion Gear	23.94
H50-1001	O Ring	0.50
H50-1101	Body Cover B	31.55
H50-1201	Osc Gear	6.08
H50-1301	Main Shaft Assembly	24.48
H50-1601	Collar	3.56
H50-1801	Collar	1.26
H50-1901	Bearing Retainer	3.81
H50-2002	Body Cover	33.23
H50-2006	Side Cover	34.81

H50-2007	Side Cover	37.21
H50-2101	Packing	3.81
H50-2200	ONEWAY CLUCH WASHER	0.68
H50-2203	Washer	0.57
H50-2301	Clutch Ring	21.01
H50-2601	O Ring	1.04
H50-2902	Nut	21.91
H50-2904	Infinite Cover	25.89
H50-3001	Packing	3.56
H50-3101	Rear Cover	69.93
H50-3102	Rear Cover	61.74
H50-3201	Rotor	30.44
H50-3202	Rotor	24.23
H50-3301	Shaft	2.80
H50-3401	Bail Spring A	0.50
H50-3501	Collar	1.04
H50-3603	Arm Lever	24.73
H50-3604	Arm Lever	23.85
H50-3605	Arm Lever	32.41
H50-3606	Bail Arm	23.22
H50-3701	Screw	0.79
H50-3702	Screw (D)	2.80
H50-3801	Cover A	4.60
H50-3901	Screw	0.79
H50-3902	Screw (E)	3.47
H50-4001	Bail	116.50
H50-4501	Line Roller	5.86
H50-4701	Screw	1.51
H50-4703	Screw	3.43
H50-4801	Nut	3.56
H50-4901	Collar	3.34
H50-5001	Packing	2.30
H50-5101	Collar	7.40
H50-5201	Screw	0.66
H50-5401	Packing	3.24
H50-5502	Handle	142.99
H50-5902	Handle Knob	32.49
H50-6101	Screw	14.30
H50-6201	Handle Screw Cap	14.81
H50-6801	Drag Knob	19.74
H50-9802	Cover A	2.80
H51-0102	Cover B	2.80
H51-2401	Screw I	0.50
H51-2501	Spring A	0.50
H51-3101	Drag Spring Washer	1.39
H51-3201	HANDLE KNOB WASHER(A)	3.37
H51-7701	Motor Gear B	48.61

H51-7801	Motor Gear Shaft	36.76
H51-8301	Motor Gear Hi	45.11
H51-8302	Motor Gear (Low)	22.98
H51-9301	Cover	8.91
H52-0101	Drag Plate	42.84
H52-8401	Drive Shaft Spring	0.50
H53-0801	Pin A	1.13
H53-0901	Spring B	0.50
H53-1504	Motor Holder Pckng Screw	0.66
H53-1507	Screw	4.00
H53-1508	Front Plate Screw	2.21
H53-1511	FRONT COVER SCREW	0.50
H53-2401	Name Plate	8.91
H53-2501	Body Cover A	31.55
H53-2602	Magnet Holder	8.32
H53-5301	Magnet Assembly	10.71
H53-7101	Handle Knob	28.31
H53-7301	Spool Spring	1.01
H53-7901	Spool	16.85
H53-8201	Spool	17.04
H53-8501	Body	3.85
H54-2001	Drive Gear	4.12
H54-5301	Oscillating Gear	3.62
H54-5401	Washer E	0.69
H54-5402	Washer D	0.85
H54-5701	ARM LEVER SPRING	0.50
H54-7801	Click Spring B	0.50
H55-7401	Oscillating Gear	5.64
H55-7601	Spool	178.58
H55-7801	Spool	178.76
H55-8101	Frame	154.65
H55-8602	Click Pawl	4.03
H55-8701	Click Spring B	1.07
H55-8801	Spool	44.55
H55-8901	Drag Washer	23.44
H55-9001	Spool Shaft	7.81
H55-9201	Cap	2.90
H55-9301	Spring A	0.50
H55-9401	Drag Plate	23.03
H55-9601	Packing	2.27
H55-9801	Drag Washer Cover	15.12
H55-9907	Right Side Plate	182.12
H55-9908	Right Side Plate	194.24
H55-9909	Right Side Plate	161.89
H55-9910	Right Side Plate	202.52
H55-9911	Right Side Plate	282.90
H55-9912	Right Side Plate	248.81

H56-0001	Drive Shaft	23.31
H56-0101	Pinion Gear B	15.09
H56-0201	Drag Lever	63.72
H56-0501	Drag Lever Plate	3.78
H56-0601	Pre-Set Cam	25.15
H56-0701	Ring	0.50
H56-0801	Pre-Set Drag Knob	12.63
H56-1001	Collar	72.58
H56-1101	Handle	41.10
H56-1503	Handle Knob	15.88
H56-1505	Handle Knob	15.97
H56-1901	Push Button	6.43
H56-2101	Handle Cap	27.72
H56-2201	Frame	144.65
H56-2501	Spool	36.61
H56-2601	Spool Shaft	7.34
H56-2801	Drag Plate	23.69
H56-3001	Frame	177.88
H56-3301	Spool	46.49
H56-3401	Spool Shaft	8.16
H56-4202	Spool	12.77
H56-4401	Spool Shaft Gear	4.85
H56-5001	Motor	158.14
H56-5201	Motor Transmission Gear	20.25
H56-5701	Side Cover	3.65
H56-5801	Spool Shaft	6.65
H56-7301	R/S Plt Screw B	2.99
H56-7401	R/S Plt Screw C	2.74
H57-1101	Drive Shaft B	33.26
H57-1201	Pinion Gear Holder	21.42
H57-1401	Handle	31.39
H57-1701	Plate	4.79
H57-2001	Bail Spring Shaft	0.50
H57-4001	FRAME ASSY	116.11
H57-4101	Frame	58.59
H57-5301	Left Side Plt Screw	2.80
H57-6101	Bail Spring Plate	3.59
H58-2001	Pinion Yoke Spring	0.50
H58-3301	Washer E	0.50
H58-4401	Gear Shaft Collar	5.36
H58-5401	Screw A	0.50
H58-6301	Right Side Plate	37.58
H58-6601	Cast Control Cap	5.36
H58-6701	Set Plate	33.55
H58-6801	Bearing Collar	1.26
H58-7001	Left Side Plate	12.71
H58-7201	Brake Adjusting Knob	35.60

H58-7601	Frame	44.36
H59-5401	Anti-Reverse Lever	0.82
H59-5501	Anti-Reverse Cam	1.51
H59-5701	Washer E	0.50
H59-5801	Osc Gear	6.43
H59-6001	Main Shaft	7.40
H59-6301	Stabilizer Bar	0.79
H59-6401	Collar E	1.51
H59-6501	Screw H	0.60
H59-6502	Screw F	0.57
H59-8102	Rear Cover	3.56
H59-8201	Screw J	0.50
H60-0601	Rod Clamp	22.32
H60-0602	CLAMP PLATE	35.40
H60-0701	Clamp Bolt	6.14
H60-0702	Clamp Bolt	3.91
H60-0801	Clamp Nut	7.94
H60-1301	Spool Metal	3.81
H60-7901	Washer E	0.50
H60-7902	Washer D	0.57
H60-9201	Collar	2.52
H60-9601	Key Washer	0.82
H61-3101	Brake Click Spring	4.91
H61-3303	Handle Screw	1.95
H61-3304	HANDLE SCREW	4.77
H61-3901	Oscillating Gear	4.63
H61-4301	Stabilizer Bar	0.82
H61-5003	Spool Metal	12.38
H61-5402	Rear Cover	3.84
H61-5601	Drive Shaft	5.64
H61-5602	Drive Shaft	5.64
H61-6701	Washer	2.30
H61-6802	Body	46.84
H61-7101	Name Plate	8.03
H61-7201	Body Cover	30.57
H61-7301	Washer	0.79
H61-7401	Oscillating Gear	5.36
H61-7501	Oscillating Gear Pinion	17.36
H61-7601	Ring	0.79
H61-7701	Main Shaft Assembly	25.01
H61-8001	Collar	3.56
H61-8601	Anti Reverse Claw	3.09
H61-8802	Body Cover	23.74
H61-8805	Body Cover	38.07
H61-8901	Packing	4.06
H61-9001	Body Cover	29.73
H61-9101	Clutch Ring	17.36

H61-9201	Washer	2.30
H61-9301	Magnet	9.70
H61-9701	Cover	31.37
H61-9702	Infinite Cover	35.24
H61-9801	Ring	2.30
H61-9901	Packing	3.56
H62-0001	Rear Cover	69.93
H62-0002	Rear Cap	49.11
H62-0101	O Ring	1.04
H62-0201	Rotor	30.07
H62-0202	Rotor	16.28
H62-0203	ROTOR	29.62
H62-0301	Shaft	2.80
H62-0401	Spring	0.79
H62-0501	Bail Spring Holder	1.04
H62-0603	Arm Lever	12.51
H62-0605	ARM LEVER	12.32
H62-0701	Cover A	4.60
H62-0801	Bail	41.18
H62-1201	Line Roller	6.90
H62-1301	Collar	3.09
H62-1401	Nut	4.60
H62-1501	Packing	1.04
H62-1601	Collar	7.40
H62-1701	Spool Metal	5.36
H62-1801	O Ring	0.50
H62-2001	Packing	1.04
H62-3001	Handle Cap	18.36
H62-4201	Drag Knob	14.30
H62-4501	Clutch Cam	1.04
H62-4702	Spacing Sleeve	7.21
H62-4801	Collar A	0.50
H62-4901	Screw I	0.50
H62-5201	Drive Gear	53.30
H62-9101	Osc Gear	6.43
H62-9201	Main Shaft	7.40
H62-9701	Ring	0.79
H63-0201	Star Drag	3.34
H63-0202	Star Drag	3.56
H63-0301	Handle	9.47
H63-0701	Roller Clutch Gear	12.76
H63-0901	Right Side Plate	8.22
H63-0902	RIGHT SIDE PLATE	14.00
H63-1401	Spool	207.11
H63-1601	Spool	192.15
H63-2401	Roller Clutch Gear	15.94
H63-6501	Handle Collar	2.74

H63-6801	Pinion Gear	5.78
H63-6901	Pinion Gear	4.82
H63-8401	Lock Screw	2.55
H63-9001	Anti-Reverse Cam	2.80
H63-9301	Stabilizer Bar	0.50
H63-9601	Spacing Sleeve	11.21
H64-0301	Collar G	1.26
H64-0401	Bail Trip Lever	2.80
H64-0601	Bail Spring Shaft	0.57
H64-0701	Bail Spring	0.50
H64-1501	Spool Metal	2.30
H64-1802	Handle Screw	2.80
H64-1803	Handle Screw	1.61
H64-1804	HANDLE SCREW	3.06
H65-5301	Stopper	6.39
H65-6102	Screw D	0.85
H65-9001	Clutch Cam Spring	0.50
H65-9101	Clutch Cam Plate	4.69
H65-9103	KICK LEVER PLATE(B)	14.64
H66-0901	Clutch Wheel	2.99
H66-1001	Drive Shaft Washer B	5.86
H66-1101	Drive Shaft Washer A	0.50
H66-1701	Handle Collar	1.58
H66-2402	Front Plate	4.60
H66-3401	Brake Click Spring	0.66
H66-4901	R/S Plate	13.00
H66-5301	Spool Pin Holder	2.39
H66-6001	Set Plate Screw	1.04
H66-6002	Set Plate Screw	0.66
H66-6505	Right Side Plt	12.77
H66-6506	Right Side Plt	12.77
H66-8102	Push Button	3.34
H67-0501	Cluth Cam Spring	0.50
H68-0001	DRAG DISC COLLAR	15.66
H68-1004	HANDLE CAP	1.17
H68-2201	Body	53.81
H68-2401	Name Plate	6.11
H68-2501	Body Cover B	38.05
H68-2502	Drive Bearing Cover	38.05
H68-2601	Oscillating Gear	6.49
H68-2701	Main Shaft Assembly	29.61
H68-3001	Collar	3.56
H68-3101	Pinion Gear	17.12
H68-3201	Drive Gear	101.82
H68-3501	Collar	1.26
H68-3601	Anti-Reverse Pawl	4.85
H68-3804	Side Cover	23.25

H68-3810	Side Cover	33.62
H68-3811	Side Cover	28.06
H68-3814	BODY COVER	33.35
H68-3901	Packing	6.11
H68-4001	Washer	0.50
H68-4102	Infinite A/R Cover Nut	25.79
H68-4301	Packing	3.81
H68-4401	Rear Cover	66.34
H68-4402	Rear Cap	67.63
H68-4403	Rear Cover	72.83
H68-4404	Rear Cover	75.54
H68-4501	Rotor	43.85
H68-4502	Rotor	52.62
H68-4503	Rotor	50.53
H68-4504	Rotor	53.30
H68-4601	Shaft	3.81
H68-4701	Bail Spring Holder	7.65
H68-4801	Cover A	4.85
H68-4901	Bail	80.54
H68-5301	Plate A	1.04
H68-5402	Rotor Nut	5.17
H68-5501	Collar	3.34
H68-5601	Packing	1.04
H68-5701	Collar	7.65
H68-5801	Packing	1.70
H68-5901	Handle	139.52
H68-6301	Handle Screw Cap	16.60
H68-6302	Handle Cap	16.66
H68-6303	Handle Screw Cap	27.03
H68-6401	Spool	253.11
H68-7201	Washer	2.80
H68-7401	Pinion Yoke	5.36
H68-8601	Clutch Ring	32.16
H68-9203	Cast Control Cap	9.57
H69-0201	Clutch Cam Retainer	1.04
H69-1901	Click Leaf Spring Holder	7.02
H69-2301	Motor	31.55
H69-5501	Drive Gear	14.66
H69-7701	Screw E	0.50
H70-4101	Stabilizer Bar Retainer	0.50
H71-1901	Rotor Nut	1.83
H71-4001	Key Washer	1.26
H71-4501	Jog Power Lever O'ring	1.01
H71-7101	FINGER COVER SCREW	0.50
H71-7401	Oscillating Gear	5.45
H71-7701	Spool Metal	3.94
H71-9301	Spool Metal	6.46

H71-9401	Cover	37.52
H71-9802	Frame Assembly	101.13
H72-2002	Handle Screw Cap	3.34
H72-3001	Drive Gear	9.64
H72-3701	Handle Nut	1.39
H72-3702	Handle Nut	1.39
H72-4201	LEVELWIND POST COLLAR	3.40
H72-6802	Ball Bearing B	4.91
H72-7201	Spool	7.95
H72-7501	Spool	7.69
H72-7901	Oscillating Gear	6.43
H72-8202	Bail Assembly	20.66
H72-8903	Bail Arm	4.60
H72-8909	Bail Arm	6.77
H72-8912	Bail Arm	2.58
H72-8920	Bail Arm	8.00
H72-8927	Bail Arm	2.99
H72-8933	ARM LEVER	0.50
H73-0801	Packing (B)	1.86
H73-2301	Body	3.44
H73-2401	Side Cover	3.28
H73-2701	Main Shaft	7.65
H73-5001	Ball Bearing B	6.11
H73-5002	Ball Bearing (B)	8.00
H73-6301	Spring	0.50
H73-7101	Leaf Spring	0.79
H73-7801	Bail Trip Plt	0.85
H73-8201	Anti-Reverse Cam	8.03
H73-8301	Oscillating Gear	5.73
H73-8401	Main Shaft	12.63
H73-8701	Stabilizer Bar	2.02
H73-8801	Collar F	2.58
H73-8901	Ball Bearing E	9.20
H73-8902	Ball Bearing	6.68
H73-9101	Bearing Retainer B	1.39
H73-9102	Bearing Retainer	4.60
H73-9701	DRIVE BALL BEARING (B)	8.68
H73-9702	Ball Bearing	8.25
H73-9703	Ball Bearing	5.45
H74-0001	Screw M	0.85
H74-0002	Screw (N)	1.32
H74-0102	Side Cover	14.94
H74-0107	Side Cover	17.06
H74-0108	Side Cover	22.84
H74-0201	Screw J	1.45
H74-0301	Screw L	1.13
H74-0302	Screw	1.01

H74-0501	Spacing Sleeve	8.03
H74-0601	Cover C	26.71
H74-0901	Magnet	10.33
H74-1401	O Ring A	0.85
H74-1501	Rear Cover	6.90
H74-1502	Rear Cover	6.87
H74-1701	Screw H	1.13
H74-1702	Screw C	1.13
H74-1802	Rotor	27.47
H74-1807	Rotor	26.30
H74-1901	Bail Trip Lever	5.45
H74-2101	Bail Spring Shaft	4.03
H74-2202	Bail Arm	13.20
H74-2207	Bail Arm	13.73
H74-2301	Collar B	2.30
H74-2501	Cover A	5.73
H74-2701	Bail	71.75
H74-3301	Cover B	5.73
H74-3401	Magnet Collar	9.77
H74-3701	Collar D	4.32
H74-3801	Line Roller	6.62
H74-3901	Collar C	2.87
H74-4001	Magnet Collar	10.90
H74-4201	Screw E	1.45
H74-4801	Motor Gear A Spring Washe	0.57
H74-4901	Handle Knob	2.74
H74-5101	Handle Screw Cap	6.02
H75-0201	Star Drag	4.06
H75-3001	Pin	0.50
H75-3301	Screw H	1.13
H75-3302	Screw	0.95
H75-3310	Jog Power Lever (B) Screw	1.32
H75-3311	Side Plate Screw	1.32
H75-3312	Side Cover (B) Screw	1.67
H75-3313	FINGER COVER SCREW	1.36
H75-3601	Osc Post	1.83
H75-4301	Bail Trip Plt	0.91
H75-4403	Side Cover	16.11
H75-4405	Body Cover	22.63
H75-4501	Rear Cover	7.34
H75-4604	Rotor	25.83
H75-4701	Bail Trip Lever	5.83
H75-4901	Bail Spring Shaft	3.37
H75-5001	Cover	6.11
H75-5101	Bail Assembly	75.93
H75-5501	Cover	6.11
H75-7202	Rear Cover	2.30

H76-1101	Drag Washer	0.50
H76-1405	R/S Plt	10.29
H76-1505	L/S Plt	10.64
H76-5401	Yoke Spring	1.26
H76-5501	Pinion Gear	16.44
H76-5601	Drive Gear	13.82
H76-8401	Oscillating Gear	4.16
H76-8501	Main Shaft	8.03
H77-0601	O Ring A	0.60
H77-0901	Packing	1.54
H77-2101	Handle Screw Cap	5.45
H77-3301	Main Shaft	5.36
H77-3602	Rear Cover	2.58
H77-3702	Bail Assembly	19.95
H77-5701	Collar G	0.79
H77-8401	Main Shaft	12.63
H77-8701	Stabilizer Bar	2.02
H77-8801	Collar F	2.58
H77-9502	Side Cover	16.26
H77-9504	Side Cover	17.06
H77-9505	Side Cover	24.50
H77-9601	Rear Cover	7.75
H77-9602	Rear Cover	7.62
H77-9702	Rotor	29.15
H77-9705	Rotor	27.74
H77-9801	Bail Trip Lever	5.45
H78-0001	Bail Spring Shaft	3.43
H78-0101	Cover A	5.73
H78-0201	Bail	71.75
H78-0601	Cover B	5.73
H78-1001	Handle Knob	2.84
H78-2302	Spacing Sleeve	12.03
H78-2801	Spring	0.79
H78-8901	Osc Gear	7.65
H79-0602	Handle Knob Cap	1.48
H79-4603	Line Roller	6.02
H79-8701	Pinion Yoke Spring	0.50
H80-1501	Pinion Gear	17.18
H80-1701	Spool Holder Spring	0.66
H80-3602	Handle	113.04
H80-5801	Rotor Nut	4.88
H80-6201	Rotor Nut	6.43
H80-6301	Washer A	0.85
H80-6401	Drag Washer	0.91
H80-6501	Drag Washer	0.57
H80-6503	Drag Washer	1.01
H80-6701	Drag Washer	0.57

H80-6703	Drag Washer	1.01
H80-9101	Bail Spring	0.50
H80-9201	Anti-Reverse Cam Spring	0.85
H81-0502	Frame Assembly	101.56
H81-0601	Pinion Gear	17.18
H81-0701	Drive Gear	21.32
H81-4900	PINION BEARING(B) SPRING WASHER	1.36
H81-4901	Spring Washer	1.13
H81-4902	PINION SPRING WASHER	1.15
H81-6401	SET PLATE"O"RING	2.38
H82-0001	Star Drag	14.76
H82-0002	Star Drag	20.62
H83-4504	Handle Nut Plate	3.43
H83-4505	Handle Nut Plate	3.69
H83-4506	Handle Nut Plate	4.16
H83-4507	Handle Nut Plate	5.36
H83-4508	Handle Nut Plate	6.68
H83-4510	Handle Nut Plate	6.68
H83-4512	Handle Nut Plate	2.55
H83-6703	Rear Cover	10.71
H83-6801	Screw (I)	0.50
H83-9801	Body	39.61
H83-9901	Bearing Retainer	25.83
H84-0001	Handle Assembly	58.86
H84-0401	Spool Assembly	107.07
H84-0801	Drag Knob	22.68
H84-0901	Body	40.36
H84-1001	Bearing Retainer D	30.43
H84-1101	Handle Assembly	64.66
H84-1401	Spool Assembly	150.04
H84-2801	Screw	2.55
H84-2803	Screw	0.66
H84-2805	Screw	3.69
H84-2807	MAGSEALED PLATE SCREW	66.90
H85-0401	HANDLE KNOB COLLAR	2.31
H85-0703	Rear Cover	8.95
H85-0801	Screw	0.50
H85-4701	Collar	2.74
H85-4801	Collar A	3.43
H85-4901	Collar A	3.43
H86-1001	Body	20.17
H86-1401	Spool Assembly	32.90
H86-2301	SPOOL HOLDER SPRING	1.02
H86-2704	Rotor	2.62
H86-2713	Rotor	3.83
H86-2904	Rotor	3.55
H86-2913	Rotor	4.14

H86-3101	Brake Click Spring	1.01
H86-6201	Packing B	2.58
H86-7601	PINION GEAR	9.63
H86-9101	Frame	24.25
H86-9601	IDLE GEAR (B) COLLAR	4.08
H87-0201	Bail Assembly	3.73
H87-1201	R/S Plt	83.33
H87-1301	Frame	88.01
H87-4601	Handle Assembly	56.81
H87-4801	Left Side Plate	9.96
H87-5201	Handle Assembly	49.04
H87-5601	L/S Plate	65.37
H87-5701	Frame	91.27
H87-5801	R/S Plt	10.17
H87-6701	Body	49.32
H87-7101	Handle	170.93
H87-7301	Spool Assembly	195.71
H87-7501	Drag Knob	21.92
H87-9601	Spacing Sleeve	2.39
H88-0801	HANDLE ASSY	34.56
H89-0201	Handle Assembly	63.94
H89-1401	Rear Cover	7.34
H90-6201	Bail Trip Plate	1.01
H91-0202	Frame	18.94
H91-0203	Frame	18.10
H91-0208	Frame	16.75
H91-0216	Frame	42.41
H91-0225	Frame	33.93
H91-0228	Frame	16.75
H91-0304	Right Side Plate	9.98
H91-0305	Right Side Plate	9.98
H91-0306	Right Side Plate	10.13
H91-0307	Right Side Plate	10.13
H91-0308	Right Side Plate	10.13
H91-0313	R/S Plt	8.53
H91-0314	R/S Plate	9.08
H91-0325	R/S Plate	19.58
H91-0335	Right Side Plate	20.01
H91-0336	Right Side Plate	10.13
H91-0337	Right Side Plate	10.13
H91-0342	Right Side Plate	8.53
H91-0343	Right Side Plate	8.53
H91-0501	Worm Gear	1.80
H91-0601	Collar	1.54
H91-0801	Level Wind Guard	1.86
H91-1601	Drive Shaft	14.71
H91-1602	Drive Shaft	14.71

H91-1701	Worm Shaft	8.60
H91-1702	Worm Shaft	7.40
H91-1901	Star Drag	5.07
H91-2001	Nut	4.19
H91-2002	Nut	3.37
H91-2101	Stabilizer Bar	1.20
H91-2301	Plate A	1.54
H91-2401	Clutch Lever	1.76
H91-2701	Drive Shaft Gear	1.73
H91-3102	Drive Gear	17.06
H91-3201	Key Washer	2.68
H91-3901	Pinion Gear	7.18
H91-5501	Brake Dial Retainer	0.50
H91-5601	Clutch Lever Plt	1.54
H91-5701	Clutch Lever Plt	1.54
H92-8701	Clutch Cam Plt	7.15
H92-8801	Spring B	0.50
H92-8901	Drive Shaft Plate	1.39
H92-9001	Clutch Plate	3.50
H92-9401	A/R Ratchet	4.57
H92-9501	Washer F	4.98
H92-9601	Handle 90Mm	25.05
H93-0002	Front Plate	5.10
H93-0003	Front Plate	5.10
H93-0005	Front Plate	5.51
H93-0113	Left Side Plate	9.84
H93-0114	Left Side Plate	15.66
H93-0116	L/S PLATE	9.57
H93-0121	Left Side Plate	21.75
H93-0126	Left Side Plate	18.70
H93-0132	Left Side Plate	9.57
H93-0206	Brake Adj Knob	4.85
H93-0207	Brake Adj Knob	4.85
H93-0208	Brake Adj Knob	6.65
H93-0209	Brake Adj Knob	6.65
H93-0210	Brake Adj Knob	6.65
H93-0211	Brake Adj Knob	5.29
H93-0212	Brake Adj Knob	6.68
H93-0213	Brake Adj Knob	5.29
H93-0214	Brake Adj Knob	6.68
H93-0217	Brake Adj Knob	5.17
H93-0218	Brake Adj Knob	5.17
H93-0219	Brake Adj Knob	5.29
H93-0220	Brake Adj Knob	5.17
H93-0221	Brake Adj Knob	5.29
H93-0222	Brake Adj Knob	5.17
H93-0223	Brake Adj Knob	5.29

H93-0227	Brake Adj Knob	7.69
H93-0228	Brake Adj Knob	7.34
H93-0233	Brake Adj Knob	4.85
H93-0234	Brake Adj Knob	4.85
H93-0401	Set Plt Screw	2.55
H93-0502	Magnet Holder	7.02
H93-0701	Spool Holder	10.68
H93-1701	Spring Washer	0.72
H93-3201	Click Leaf Spring	1.32
H93-3509	STAR DRAG	14.64
H93-4901	Pinion Gear	16.52
H94-3803	Left Side Plate	12.30
H94-3804	Left Side Plate	12.30
H94-3805	Left Side Plate	12.30
H94-3806	Left Side Plate	12.30
H94-3811	L/S Plate	9.08
H94-3812	L/S Plate	9.47
H94-3823	L/S Plate	20.01
H94-3834	LEFT SIDE PLATE	7.87
H94-3837	Left Side Plate	9.57
H94-3838	LS PLATE	9.84
H94-3902	Frame	18.43
H94-3903	Frame	18.27
H94-3916	Frame	44.38
H94-3918	Frame	32.96
H94-3925	Frame	18.27
H94-3928	Frame	16.75
H94-4001	Clutch Cam Plate	5.80
H94-4301	Plate	1.54
H94-4401	Pinion Yoke	3.47
H94-4601	Level Wind Guard	1.86
H94-4701	Pinion Gear	7.87
H94-4802	Drive Gear	20.21
H94-4903	Right Side Plate	8.96
H94-4905	R/S Plate	10.05
H94-4913	Right Side Plate	8.96
H94-4914	RIGHT SIDE PLATE	22.17
H94-4921	Right Side Plate	22.43
H94-4926	Right Side Plate	20.23
H94-4932	Right Side Plate	8.53
H94-5201	Drag Plate	0.57
H94-5501	Collar (B)	1.04
H95-6901	Clutch Trip Plt	1.80
H95-7001	Drive Shaft Ret	3.34
H95-7101	Yoke	5.70
H95-7502	Pinion Gear	16.52
H95-9601	Ball Bearing (D)	8.88

H95-9602	Ball Bearing	10.84
H96-0010	Rotor	6.05
H96-0016	Rotor	16.20
H96-0017	Rotor	7.34
H96-0038	Rotor	11.01
H96-0042	Rotor	20.89
H96-0046	Rotor	15.01
H96-0052	ROTOR	27.69
H96-0059	ROTOR	0.50
H96-0102	Arm Lever	6.46
H96-0104	Bail Arm	15.31
H96-0107	Bail Arm Lever	8.03
H96-0119	Arm Lever	7.34
H96-0121	Arm Lever	14.71
H96-0128	ARM LEVER	10.55
H96-0201	Cover (A)	2.30
H96-0203	Bail Spring Cover	2.24
H96-0204	ARM LEVER SPRING COVER	2.38
H96-0301	Bail Assembly	25.46
H96-0701	Collar (G)	0.98
H96-0801	Collar (F)	0.69
H96-0901	Collar (E)	0.95
H96-1001	Collar (D)	0.63
H96-1101	Rotor Nut	0.66
H96-1201	Packing (A)	1.39
H96-1501	Handle Screw Cap	2.74
H96-2401	Collar (A)	0.50
H97-4309	Rotor	6.87
H97-4313	Rotor	7.18
H97-4314	Rotor	18.47
H97-4319	Rotor	9.87
H97-4324	Rotor	14.15
H97-4329	ROTOR	33.02
H97-4334	ROTOR	0.50
H97-4401	Cover (A)	2.30
H97-4402	Bail Spring Cover	2.36
H97-4501	Bail Assembly	25.46
H97-7301	Cast Control Cap	10.36
H97-9201	Washer	0.76
H97-9307	R/S Plt	47.85
H97-9308	R/S Plate	47.85
H97-9404	Frame	107.87
H97-9501	Drive Shaft	17.70
H97-9502	Drive Shaft	17.70
H97-9802	Front Plt	16.07
H98-0307	L/S Plate	49.38
H98-0404	Frame	102.87

H98-0502	Front Plate	21.07
H98-1301	Yoke	4.35
H98-1602	Pinion Gear	14.62
H98-2801	Bail Assembly	13.86
H98-3201	Bail Assembly	13.00
H98-3601	Bail Assembly	14.04
H98-4401	Bail Assembly	7.34
H98-4701	Bail Assembly	7.34
H98-4702	Bail Assembly	11.39
H98-5001	Bail Assembly	7.34
H98-5002	Bail Assembly	11.39
H98-5301	Bail Assembly	7.34
H98-5302	Bail Assembly	11.39
H98-6308	Rotor	7.18
H98-6313	Rotor	7.34
H98-6315	Rotor	10.66
H98-6317	Rotor	16.61
H98-6323	Rotor	13.10
H98-6327	Rotor	37.41
H98-6401	Cover (A)	2.30
H98-6402	Bail Spring Cover	2.55
H98-6403	ARM LEVER SPRING COVER	2.38
H98-6501	Bail Assembly	26.51
H98-6901	Packing (A)	1.39
H99-1801	Handle	10.25
H99-2201	Pinion Gear	5.64
H99-2301	Drive Gear	12.44
H99-2801	R/S Plate	21.83
H99-2901	Roller Clutch	8.85
H99-4201	Screw (L)	4.60
H99-4304	Rotor	8.75
H99-4308	Rotor	7.67
H99-4324	Rotor	12.72
H99-4329	Rotor	38.93
H99-4331	Rotor	10.68
H99-4401	Bail Trip Lever	3.31
H99-4601	Cover (A)	2.30
H99-4602	Bail Spring Cover	2.55
H99-4604	ARM LEVER SPRING COVER	2.38
H99-4704	Bail Assembly	47.62
H99-5101	Rotor Nut	5.29
H99-5201	Packing (A)	1.39
H99-5501	Handle Screw Cap	2.55
HB-1	Daiwa Reel Oiler	3.50
HB-2	Daiwa Reel Lube	3.59
I100021	HANDLE CAP	0.01
I100022	HANDLE CAP	0.01

J00-0001	Body	15.93
J00-0701	Main Shaft	5.17
J00-0702	Main Shaft	10.21
J00-0901	Screw	0.50
J00-1101	Bail Trip Plate	0.50
J00-1201	Side Cover	3.20
J00-1401	Spacing Sleeve	3.21
J00-1402	Spacing Sleeve	7.09
J00-1403	Roller Clutch Sleeve	9.70
J00-1501	R/C Cover	0.80
J00-1601	Screw	0.50
J00-1602	Screw	0.63
J00-1801	Screw	0.50
J00-1901	Rotor Nut	1.23
J00-2001	Handle Assembly	14.51
J00-2201	Spool Assembly	16.91
J00-4002	Drive Gear	11.69
J00-4101	Drive Gear	13.28
J00-4102	Drive Gear	11.30
J00-4201	Pinion Gear	7.87
J00-4301	Pinion Gear	5.64
J00-4701	Cast Control Cap	7.69
J00-4702	Cast Control Cap	7.84
J00-4704	Cast Control Cap	4.60
J00-4707	Brake Knob	10.02
J00-9401	Drive Shaft	11.75
J00-9402	Drive Shaft	16.38
J00-9801	Pinion Gear	14.15
J00-9902	Drive Gear	11.69
J01-0201	Pinion Gear	20.01
J01-0901	Pinion Gear	16.52
J01-1301	Pinion Gear	10.13
J01-1401	Drive Gear	12.79
J01-1402	Drive Gear	11.52
J01-1501	Main Shaft	3.84
J01-1701	Yoke	1.07
J01-1901	Spring C	0.50
J01-2301	Body	19.72
J01-2802	Main Shaft	12.44
J01-3201	Side Cover	3.36
J01-3401	R/C Cover	1.27
J01-3601	Handle Assembly	13.86
J01-4001	Spool	18.02
J01-4401	Rod Clamp	22.20
J01-4402	Rod Clamp	42.85
J01-5701	Roller Clutch	17.70
J01-9301	Ball Bearing (Ms)	34.05

J01-9303	Pinion Ball Bearing	34.15
J01-9304	Ball Bearing (D) (Ms)	36.10
J02-0001	Body	22.32
J02-0501	Anti-Reverse Cam	2.93
J02-0601	Main Shaft	6.36
J02-0602	Main Shaft	15.62
J02-0801	Bearing Retainer	1.23
J02-1001	Bail Trip Plate	0.69
J02-1101	Side Cover	3.20
J02-1301	Spacing Sleeve	4.47
J02-1303	Spacing Sleeve	7.34
J02-1304	CLUTCH RING	12.25
J02-1401	R/C Cover	2.56
J02-1501	Rear Cover	4.41
J02-1601	Rotor Nut	1.73
J02-1701	Handle Assembly	14.51
J02-1901	Spool Assembly	19.95
J02-2401	Main Shaft	5.73
J02-2402	Main Shaft	12.44
J02-2601	Bail Trip Plate	0.50
J02-2701	R/C Cover	2.21
J02-2801	Handle Assembly	12.12
J02-3001	Spool Assembly	13.08
J02-4701	Spool Assembly	13.08
J02-8001	Spool Pin	2.02
J03-0302	BALL BEARING (MS)	29.60
J03-0303	Ball Bearing	34.58
J03-1901	Worm Shaft Ryoga	10.68
J03-5801	POWER LEVER PLATE CLICK SPRING	1.36
J03-6202	CLUTCH LEVER	7.15
J03-6407	FINGER COVER	9.19
J03-6601	IC MODULE	270.78
J03-7201	POWER LEVER HOLDER(R)	2.04
J03-7301	POWER LEVER HOLDER(L)	2.04
J03-7501	MOTOR GEAR BELT	0.50
J03-7601	POWER LEVER O RING	0.50
J03-8001	SETPLATE	34.38
J03-8501	Bail Trip Lever	2.55
J04-0001	Ball Bearing (Ms)	37.80
J04-2401	Ball Bearing (Ms)	32.84
J04-2402	BALL BEARING (MS)	58.63
J04-2501	O-Ring	0.76
J04-2801	Collar	1.73
J04-2901	Line Roller	5.17
J04-2902	Line Roller	7.15
J04-4502	Plate (B)	4.13
J04-4503	Plate (B)	5.76

J04-4505	Plate (B)	4.41
J04-4506	Plate (B)	4.13
J04-4606	Frame	16.89
J04-4607	Frame	40.24
J04-5201	Front Plate	5.64
J04-5203	Front Plate	10.05
J04-5701	Magnet Holder	28.04
J04-6802	Drive Ball Bearing	43.28
J04-8501	Clutch Trip Plt Spring	1.26
J04-8601	"O" Ring (J)	0.76
J04-8702	Ball Bearing (H)(Ms)	32.84
J04-8802	Bearing Ret (A)	62.53
J04-9001	BODY ASSY 14SALTIGA 8000	47.56
J04-9701	LEVEL WIND	9.53
J05-0001	WORM SHIELD	8.85
J05-0101	WORM SHAFT	17.70
J05-0902	CLUTCH LEVER PLATE(R)	1.02
J05-1102	CLUTCH LEVER PLATE(L)	1.02
J05-1301	CLUTCH CAM PLATE	6.47
J05-1401	WORM SHAFT GEAR	1.70
J05-1501	LEVELWIND POST	2.38
J05-1901	MOTOR GEAR(B)	12.93
J05-2101	SPOOL	72.16
J05-2401	SPOOL SHAFT	9.87
J05-2701	SPOOL SHAFT GEAR(A)	7.83
J05-3001	SPOOL SHAFT GEAR(B)	12.25
J05-3201	SPOOL GEAR	30.29
J05-3901	SPOOL PLATE	16.00
J05-4301	IDLE GEAR (A)	1.70
J05-4401	IDLE GEAR (B)	1.70
J05-5201	Pin	1.13
J05-5301	Yoke Spring	0.72
J05-5501	POWER LEVER PLATE	1.70
J05-5708	L/S PLATE	50.02
J05-5801	GEAR SHAFT	22.12
J05-6301	PINION	27.91
J05-6401	CLUTCH CAM LEVER	14.30
J05-6901	Mechanical Brake Washer	1.01
J05-7502	HANDLE	48.21
J05-8201	Spool Assembly	19.62
J05-8901	Frame	121.79
J05-8902	Frame	121.79
J05-9001	Clutch Sp	0.66
J05-9501	Star Drag	23.06
J05-9601	Handle	96.78
J05-9801	Left Side Plate	68.94
J06-1606	Frame	18.16

J06-1607	Frame	41.74
J06-3302	STAR DRAG	41.53
J06-7402	Drag Knob	15.58
J06-7501	CLUTCH CAM HOLD PLATE	1.02
J07-2301	Bail Trip Lever	2.52
J07-3501	Washer (B)	0.66
J07-5301	Pinion Gear	32.84
J07-5401	Drive Gear	18.72
J07-5402	Drive Gear	16.28
J07-5802	Drive Gear	16.22
J07-6202	Drive Gear	15.44
J07-6501	Pinion Gear	25.67
J07-6601	Drive Gear	22.39
J07-6602	Drive Gear	17.14
J07-7002	Drive Gear	16.05
J08-4801	Stabilizer Bar	0.50
J08-4802	Stabilizer Bar	0.50
J08-4803	Stabilizer Bar	0.50
J08-4804	Osc Post	2.33
J08-4805	Osc Post	0.79
J08-4806	Osc Post	5.01
J08-4808	OSCILLATING POST	2.04
J08-5101	Drive Shaft Washer (A)	0.66
J08-5201	Eared Washer	3.34
J08-9301	Bail Spring	0.50
J08-9401	Bail Spring Holder	0.50
J08-9901	Line Roller	5.45
J08-9902	Line Roller	6.43
J08-9903	Line Roller	2.05
J09-0311	HANDLE NUT	0.50
J09-0312	HANDLE NUT	0.50
J09-0401	Spool	22.92
J09-1101	Pinion Gear	15.81
J09-1201	Handle 100Mm	25.54
J09-1501	Spool Assembly	26.32
J09-1901	Pinion Gear	19.39
J09-2001	Pinion Gear	11.56
J09-2101	Pinion Gear	11.56
J09-3301	Body	28.70
J09-3701	Handle Assembly	27.51
J09-3901	Spool Assembly	31.53
J09-4101	Drag Knob	9.89
J09-4401	Bail Assembly	14.86
J09-4601	Handle Assembly	31.22
J09-5001	Drag Knob	11.25
J09-5501	Handle Assembly	31.08
J09-5701	Spool Assembly	34.05

J09-6301	Handle Assembly	48.85
J09-6501	Spool Assembly	36.12
J09-6701	Drag Knob	14.93
J09-7401	Brake Knob	33.07
J09-7403	Cast Control Cap	38.93
J09-7405	SPOOL ADJ CAP	24.63
J09-7901	Star Drag	8.00
J09-7902	Star Drag	8.35
J09-8001	L/S Plt	11.13
J09-8301	Drive Gear	16.32
J09-8401	Pinion Gear	18.70
J09-8501	R/S Plate	13.71
J09-8601	Drive Gear	20.01
J09-8701	Pinion Gear	22.61
J10-0201	Packing (B)	2.52
J10-0301	Cover (B)	1.95
J10-0501	Cover	1.95
J10-1301	Handle Washer B	4.35
J10-1302	HANDLE WAHSER	0.50
J10-1601	Clutch Lever	19.53
J10-2203	Star Drag	14.10
J10-2208	STAR DRAG	18.05
J10-2211	STAR DRAG	18.05
J10-2301	Star Drag But	7.02
J10-2302	Star Drag Nut	7.02
J10-2303	DRAG NUT	21.10
J10-2304	DRAG NUT	21.10
J10-2801	Handle Washer	0.66
J10-3601	Ic Module	248.42
J10-7203	Spool Assembly	51.56
J10-7205	Spool Assembly	26.32
J10-8301	IDLE GEAR (B) COLLAR	4.42
J11-0601	Body	14.84
J11-0801	Side Cover	3.03
J11-0901	Handle Assembly	15.15
J11-1001	Spool Assembly	13.22
J11-1301	Drag Knob	4.16
J11-1401	Spool Assembly	13.22
J11-1701	Handle Assembly	20.05
J11-1801	Spool Assembly	21.91
J11-2101	Drag Knob	5.76
J11-2201	Body	15.48
J11-2501	Side Cover	3.36
J11-2601	Handle Assembly	18.78
J11-2701	Spool Assembly	18.16
J11-3001	Body	16.56
J11-3201	Side Cover	3.36

J11-3301	Handle Assembly	15.15
J11-3401	Spool Assembly	19.62
J11-3701	Drag Knob	4.13
J11-3801	Spool Assembly	20.11
J12-9301	Body	12.77
J12-9401	Rotor	10.05
J12-9501	Handle Assembly	33.80
J12-9601	Spool Assembly	31.26
J12-9801	Drag Knob	4.82
J13-0001	Spool Assembly	31.10
J13-0201	Packing (B)	1.76
J13-6101	OSCILLATING GEAR	6.59
J13-9701	R/S Plt	26.49
J14-0001	Star Drag	8.19
J14-0004	Star Drag	14.36
J14-0005	STAR DRAG	13.62
J14-0101	Handle	24.83
J14-0501	L/S Plt	39.03
J14-0602	MAIN SHAFT	12.93
J14-0701	Main Shaft	5.17
J14-0702	MAIN SHAFT	8.85
J14-0801	Main Shaft	8.35
J14-0803	MAIN SHAFT	15.66
J14-0805	MAIN SHAFT	15.66
J14-0901	Main Shaft	6.36
J14-1001	Nut	6.36
J14-1002	Nut	5.99
J14-1101	L/S Plt	28.56
J14-1201	R/S Plt	27.74
J14-2301	Drag Knob	2.74
J14-2401	Drag Knob	2.99
J14-2701	R/S Plt	41.04
J14-2801	Handle	27.45
J14-3001	L/S Plt	39.03
J14-3201	R/S Plt	27.96
J14-3601	R/S Plt	26.49
J15-4103	Body	39.38
J15-4502	Bearing Retainer	37.74
J15-4701	Handle Assembly	61.71
J15-4801	Spool Assembly	159.12
J15-5301	Drag Knob	23.43
J15-5909	Body	40.65
J15-6302	Bearing Retainer	38.46
J15-7601	Drag Knob	23.29
J15-9501	Spool Assembly	110.99
J15-9804	Body	40.65
J16-0202	Bearing Retainer	38.46

J16-1301	Spool Assembly	157.21
J16-4101	Handle	55.82
J16-4201	Handle	59.80
J16-4501	R/S PLATE SCREW (B)	0.68
J16-6401	DRAG WASHER	0.99
J17-3001	Cover	22.81
J17-4005	Body	69.74
J17-4105	Body Cover (B)R	22.76
J17-4106	Body Cover (B)R	22.76
J17-4205	Body Cover (A)L	22.76
J17-4206	Body Cover (A)L	22.76
J17-4301	Handle Assembly	259.24
J17-4901	Handle Screw Cap	50.68
J17-5402	Drag Knob	26.10
J17-5801	Spool Assembly	224.23
J17-6601	T-Level Wind	48.85
J17-6602	T-Line Guide	39.05
J17-7901	Spool Assembly	224.23
J17-8201	Main Shaft	32.84
J17-8701	ROLLER COLLAR(C)	1.43
J17-9801	Main Shaft	15.15
J18-0001	Main Shaft	21.04
J18-0201	Main Shaft	12.25
J18-0601	Main Shaft	13.45
J18-0801	Spool Metal Nut	3.18
J18-1101	KICKLEVER SPRING	1.02
J18-1401	Spool Metal	5.86
J18-1501	Set Plate Gear (B)	37.77
J18-1701	Set Plate Gear (A)	24.07
J18-1801	Motor	124.62
J18-2201	Motor Holder	54.59
J18-2301	Spool Assembly	428.18
J18-2701	Line Guide	159.94
J18-3001	Pillar	11.69
J18-3101	Ic Module	585.74
J18-3201	Power Module	429.09
J18-3301	Receptacle	40.88
J18-3701	Drive Shaft	20.89
J18-3801	Pin	4.00
J18-4001	Power Lever	67.42
J18-4201	Connector Cap	6.36
J18-4401	Ball Bearing(Ms)	34.69
J18-5304	Body	117.65
J18-5401	O-Ring	1.01
J18-5503	Ball Bearing Ret (B)	30.46
J18-5601	Oscilating Pinion Gear	27.39
J18-5701	O-Ring	1.01

J18-5801	O-Ring	1.01
J18-5901	Main Shaft	31.32
J18-6303	BALL BEARING RET (A)	28.12
J18-6501	Bearing	2.68
J18-6601	Line Roller	9.70
J18-6701	Handle Assembly	175.30
J18-7301	Handle Cap	47.62
J18-7802	Drag Knob	16.95
J18-8401	Spool Assembly	207.91
J18-8703	Body	112.65
J18-8804	Body Cover (A)	32.41
J18-8901	Main Shaft	27.90
J18-9001	Receptacle Holder	20.03
J18-9101	Infinite Cover	46.31
J18-9201	Handle Assembly	262.93
J18-9601	Handle Cap	51.99
J19-0101	Spool Assembly	264.47
J19-0301	SPOOL HOLDER COLLAR	1.70
J19-2901	Collar	2.02
J19-4801	Clutch Cam Assembly	6.36
J19-5001	Clutch Lever Plate (R)	1.01
J19-5101	Clutch Lever Plate L	1.01
J19-5201	Clutch Lever	8.03
J19-5415	Right Side Cover Plate	4.57
J19-6101	Stopper Pin	6.02
J19-7401	MECHANICAL BRAKE KNOB SPRING WASHER	4.42
J19-7501	STOPPER PIN	2.04
J19-8801	Pinion Shaft	2.68
J19-9501	Clutch Cam Assembly	7.02
J21-2107	Right Side Plate	10.13
J21-2108	Right Side Plate	10.13
J21-2109	Right Side Plate	9.98
J21-2110	Right Side Plate	9.98
J21-2111	Right Side Plate	9.98
J21-2112	Right Side Plate	10.13
J21-2113	Right Side Plate	10.13
J21-2135	Right Side Plate	12.61
J21-2136	Right Side Plate	12.61
J21-2137	Right Side Plate	12.61
J21-2501	"O" Ring	0.91
J21-3101	Spacer (F)	2.02
J21-3501	Handle Cap	5.01
J21-3502	Handle Nut Plate	3.02
J21-3603	Front Cover	11.03
J21-3701	Brake Adj Knob	4.76
J21-3704	Brake Dial	1.35
J21-4407	Left Side Plate	12.30

J21-4408	Left Side Plate	12.30
J21-4409	Left Side Plate	12.30
J21-4410	Left Side Plate	12.30
J21-4411	Left Side Plate	12.30
J21-4430	Left Side Plate	14.58
J21-4431	Left Side Plate	14.58
J21-4432	Left Side Plate	14.58
J21-4450	Left Side Plate	8.49
J21-4451	Left Side Plate	8.49
J21-4452	Left Side Plate	8.49
J21-5101	Bail Assy	41.10
J21-6001	Body Cover (A)	19.78
J21-6201	Cover (B)	54.34
J21-6301	Handle Assembly	177.71
J21-6501	Spool Assembly	257.32
J21-6701	Drag Knob	17.94
J21-6801	Spool Assembly	257.32
J21-7201	Body	58.55
J21-7801	Drag Knob	36.12
J21-8801	Spool Assembly	116.46
J21-9201	Handle Assembly	67.90
J21-9601	CLUTCH CAM ASSY	6.47
J21-9801	CLUTCH LEVER	8.17
J22-1401	Clutch Trip Lever	15.31
J22-1501	Clutch Trip Lever	15.31
J23-0101	Drag Washer A	1.92
J23-0103	Drag Washer	8.03
J23-3501	Body	57.79
J23-4601	Body	56.89
J23-4701	Body Cover (A)	18.47
J23-4901	Handle Assembly	58.55
J23-5101	Spool Assembly	104.43
J23-5401	Drag Knob	36.53
J23-6101	Body	59.37
J23-6201	Body Cover	18.47
J23-6701	Handle Assembly	67.90
J23-6801	Spool Assembly	172.73
J23-8701	MAIN SHAFT	8.88
J23-8801	Washer	1.32
J23-8901	MOTOR GEAR(A)	30.29
J24-0301	DRIVE GEAR	38.12
J24-2001	R/S Plt	27.96
J24-2201	"O" Ring	0.76
J24-2301	Cast Control Cap	5.10
J24-2303	Cast Control Cap	5.10
J24-2601	Clutch Cam Plt	5.89
J24-2801	Plate A	1.29

J24-2901	Clutch Lever	19.53
J24-3101	Drive Shaft	11.75
J24-3102	Drive Shaft	11.75
J24-3201	Clutch Cam Spring	1.54
J24-3301	T-Line Guide	147.25
J24-3303	T-Line Guide	49.82
J24-3601	Worm Shaft	12.69
J24-3602	Worm Shaft	8.03
J24-3701	Level Wind Guard	2.36
J24-3801	Handle	45.67
J24-4001	Front Plate	5.64
J24-4002	Front Plate	5.10
J24-4006	Front Plate	5.10
J24-4009	Front Plate	11.69
J24-4013	Front Plate	3.06
J24-4101	Stabilizer Bar	1.01
J24-4201	L/S Plt	28.56
J24-4401	Magnet Holder	28.04
J24-4801	Frame	16.89
J24-6901	L/S Plt	9.47
J24-7001	Frame	18.61
J24-7201	Clutch Cam Plate	4.60
J24-7401	Plate (A)	1.29
J24-7501	Clutch Cam Spring	1.54
J24-7601	Level Wind Guard	2.36
J24-7701	R/S Plt	27.74
J24-7901	R/S Plt	90.49
J24-8001	Handle Assembly	30.98
J24-8101	Drive Shaft	20.41
J24-8102	Drive Shaft	20.41
J24-8201	Drive Gear (B)	21.91
J24-8301	L/S Plt	6.81
J24-8601	R/S Plt	90.49
J24-8701	Drive Gear	22.76
J24-8901	L/S Plt	72.37
J24-9101	Drive Gear	21.91
J24-9201	R/S Plt	8.92
J24-9401	L/S Plt	72.37
J24-9501	Drive Gear (B)	22.76
J24-9601	Frame Assembly	132.66
J25-1601	Frame Assembly	131.59
J25-2003	Body Cover (A)	13.04
J25-2301	Spool Pin	3.02
J25-2401	Body	56.11
J25-2501	Main Shaft	31.96
J25-3001	Rotor Nut	6.02
J25-3101	Collar	4.35

J25-3201	Ball Bearing	14.71
J25-3202	Ball Bearing	14.05
J25-4001	Handle Assembly	61.13
J25-4301	Rotor	40.45
J25-4307	ROTOR	37.88
J25-4401	Bail Trip Lever	8.00
J25-4601	Shaft	5.01
J25-4701	Bail Spring Holder	1.32
J25-4801	Bail Arm	16.73
J25-4807	ARM LEVER	12.25
J25-4901	Collar	1.32
J25-5001	Bail Arm Screw	1.01
J25-5101	Side Cover (A)	5.86
J25-5103	Cover	8.03
J25-5201	Bail Spring Cover Screw	1.01
J25-5301	Spring	1.01
J25-5401	Bail Assembly	47.19
J25-5901	Side Cover (B)	5.86
J25-5903	Cover	8.03
J25-6001	Magnetic Washer	19.72
J25-6201	Collar	4.35
J25-6301	Collar	2.36
J25-6401	Collar	5.70
J25-6501	Line Roller	9.39
J25-6502	Line Roller	9.01
J25-6601	Collar	4.66
J25-6701	Ball Bearing	12.35
J25-6702	Ball Bearing	10.36
J25-6801	Magnetic Washer	21.07
J25-7001	Screw	7.02
J25-7101	Line Guard Ring	1.01
J26-1201	Spool Transmission Gear C	150.72
J26-2601	Shaft	1.32
J26-2701	Bail Spring Holder	1.32
J26-3201	Bail Assembly	45.06
J26-5001	R/S Plate	49.82
J26-5201	Handle Assembly	75.03
J26-5301	L/S Plate	52.42
J26-5801	L/S Plate	50.02
J26-5901	R/S Plate	54.16
J26-6601	Frame	145.71
J26-6901	Jog Power Lever Ring	8.35
J26-7001	Motor Transmission Gear A	55.45
J26-7401	Motor Plate	16.03
J26-7501	Line Guard Post	3.34
J26-7502	Line Guard Post	4.00
J26-7601	Motor Assembly	66.54

J26-7901	Motor Holder	27.41
J26-8001	Motor Holder Packing	3.69
J26-8101	Drive Shaft	21.74
J26-8201	Clutch Lever Washer	1.01
J26-8301	Spool Assembly	208.14
J26-8701	Spool Shaft	7.34
J26-8801	Spool Shaft Gear (A)	9.01
J26-8901	Spool Transmission Gear	96.35
J26-9501	Spool Cover Plate	59.16
J26-9601	Motor Gear (B)	9.57
J26-9701	Set Plate	47.28
J27-0001	Motor Gear Shaft	17.70
J27-0101	Idle Gear (E)	50.45
J27-0301	Set Plate (B)	30.08
J27-0401	Level Wind Assembly	11.69
J27-0701	Worm Shaft Guard	8.35
J27-0801	Worm Shaft Assembly	46.10
J27-1201	Osc Pawl	7.69
J27-1301	Level Wind Post Collar	2.33
J27-1401	Level Wind Post	2.68
J27-1402	Level Wind Post	3.34
J27-1502	Ic Module	453.46
J27-1601	Ic Module Post	3.34
J27-1602	Ic Module Post	4.00
J27-1701	Jog Power Lever (A)	40.76
J27-2101	Jog Power Lever (B)	8.03
J27-2201	Push Button	2.02
J27-2301	Shift Switch Button	2.02
J27-2502	Ic Module Cover	51.79
J27-2603	Ic Module Cover Plate	9.01
J27-3501	Yoke Plate	10.02
J27-3701	Pinion Yoke	2.99
J27-3801	Pinion Gear	36.10
J27-3901	Ratchet	7.34
J27-4101	Ratchet Washer	1.32
J27-4201	Drive Gear Washer	8.03
J27-4301	Drive Gear	19.15
J27-4401	Drag Packing	2.99
J27-4501	Drag Collar	14.05
J27-4601	Right Side Cover (A)	91.78
J27-4602	Right Side Cover A	37.93
J27-4801	Motor Holder Plate	15.37
J27-4901	Right Side Cover (B)	25.44
J27-4902	R/S Plate	25.44
J27-5001	Clutch Lever	45.45
J27-5301	Clutch Cam Spring	0.66
J27-5401	Front Cover	35.75

J27-5501	Motor Guard Plate	14.36
J27-5601	Star Drag	36.10
J27-5801	Handle	90.92
J27-6203	Body Cover (B)	13.69
J27-8101	Spool Metal Nut	4.66
J27-8301	Gear Shaft	18.71
J27-8302	Gear Shaft	18.71
J27-9501	Pinion Shaft	1.92
J27-9601	Cast Control Cap	9.76
J27-9602	Cast Control Cap	10.43
J27-9701	O'ring	1.01
J28-0001	Clutch Lever Plate (R)	0.95
J28-0101	Clutch Lever Plate (L)	0.95
J28-0401	Clutch Cam Plate	5.10
J28-0501	Kick Lever Plate (A)	5.10
J28-0701	Clutch Lever	10.84
J28-0801	Kick Lever	12.76
J28-0901	Drive Shaft	24.70
J28-0902	Drive Shaft	24.70
J28-1001	Worm Gear	1.67
J28-1101	Gear Shaft Plate (B)	7.02
J28-1201	Gear Shaft Plate (A)	0.95
J28-1401	Worm Shaft Gear	1.67
J28-1501	Worm Shield	1.92
J28-1601	Worm Shaft Plate	0.95
J28-1801	Front Plate	14.05
J28-1802	Front Plate	12.03
J28-1901	Stabilizer Bar	7.97
J28-1902	Stabilizer Bar	3.34
J28-2602	Brake Adj Knob	12.76
J28-2603	Brake Adj Knob	13.70
J28-2801	Handle Assembly	57.20
J28-3101	Body	60.21
J28-3201	Main Shaft	19.47
J28-3501	Rotor	40.28
J28-3601	Bail Trip Lever	7.02
J28-3701	Side Cover (A)	5.82
J28-3901	Side Cover (B)	5.82
J28-4001	Line Guard Ring	1.32
J28-5901	Pinion Gear Ring	0.95
J28-6001	Lever Plate (A)	4.79
J28-6101	Lever Plate (B)	1.67
J28-6301	Lever Plate Pin	2.33
J28-6701	Rotor	35.01
J28-6707	ROTOR	36.33
J28-7001	Bail Spring Cover (A)	9.01
J28-7003	Cover	5.73

J28-7301	Bail Spring Cover (B)	9.01
J28-7303	Cover	5.73
J28-7401	Cover	2.02
J28-8201	Cast Control Cap	9.57
J28-8202	Cast Control Cap	9.57
J28-8203	Cast Control Cap	9.57
J28-8601	Handle Assembly	41.31
J28-9301	Magnet Holder	17.04
J29-0601	Drag Knob	17.86
J29-1801	Jog Power Lever Holder R	2.99
J29-1901	Jog Power Lever Holder L	2.99
J29-3801	Spool Assembly	66.85
J29-5401	Star Drag	21.59
J29-5403	STAR DRAG	30.29
J29-5501	Handle Screw	16.73
J29-5502	Handle Screw	12.38
J29-5801	Right Side Plate	138.48
J29-6001	Clutch Cam	17.04
J29-6301	Handle	111.58
J29-6501	Left Side Plate	22.22
J29-6601	Magnet Set Plate	55.84
J29-6701	Magnet Holder	36.04
J29-8001	Body	32.41
J29-8301	Handle Assembly	54.39
J29-8401	Spool Assembly	21.98
J29-8601	Handle Assembly	55.25
J29-8701	Spool Assembly	28.06
J29-8901	Body	33.50
J29-9201	Handle Assembly	53.71
J29-9301	Spool Assembly	30.44
J29-9801	Handle Assembly	66.34
J29-9901	Spool Assembly	35.44
J30-0101	Body	80.13
J30-0301	Body Set Plate	28.66
J30-0303	Body Set Plate	43.07
J30-0401	O Ring	0.95
J30-0501	Oscilating Gear Pinion	25.95
J30-0601	Main Shaft	20.89
J30-1301	Collar	2.87
J30-1402	Body Cover (A) R	15.99
J30-1502	Body Cover Monocoque	54.37
J30-1701	Magsealed Cover	21.04
J30-1702	Magsealed Cap	14.05
J30-1801	Magseal Cover Nut	20.03
J30-1901	Packing	4.79
J30-2001	Rear Cover	10.21
J30-2101	Rotor	39.24

J30-2201	Side Cover (A)	3.03
J30-2301	Line Guard Ring	2.24
J30-2401	Rotor Nut	7.34
J30-2501	Collar	7.02
J30-2801	Spool Metal	14.36
J30-2901	Handle Assembly	89.07
J30-3301	Handle Screw Cap	9.26
J30-3401	Spool Assembly	85.75
J30-4201	Osc Gear	6.71
J30-4701	Kick Lever	7.69
J30-4801	Spring	1.01
J30-4901	Bail Assembly	47.62
J30-5201	Nut	13.39
J30-5301	Collar	4.66
J30-6501	R/S Plt	27.96
J30-6901	L/S Plt	9.47
J30-7001	Body	20.64
J30-7601	Osc Gear	8.60
J30-7701	Main Shaft	14.36
J30-8001	Stabilizer Bar	1.92
J30-8101	Collar (F)	1.26
J30-8401	Bearing Retainer (A)	1.58
J30-8501	O-Ring (A)	1.04
J30-8601	Spring	0.63
J30-8701	Side Cover	12.32
J30-8901	Rear Cover	7.34
J30-8902	Rear Cover	9.36
J30-8904	REAR CAP	7.49
J30-9001	Spacing Sleeve	7.65
J30-9002	CLUTCH RING	10.89
J30-9101	Roller Clutch	11.01
J30-9201	Cover (B)	3.50
J30-9301	Washer (F)	1.26
J30-9401	Rotor	17.08
J30-9501	Bail Spring Shaft (B)	2.55
J30-9601	Washer (E)	0.50
J30-9703	Bail Arm	5.10
J30-9801	Cover (A)	2.24
J30-9802	Bail Spring Cover	3.12
J30-9803	ARM LEVER SPRING COVER	2.04
J30-9901	Bail Assembly	11.96
J31-0401	Collar (D)	1.26
J31-0501	Rotor Nut	4.13
J31-0601	Collar (A)	1.58
J31-1602	HANDLE SCREW	3.40
J31-1701	Spool Assembly	44.19
J31-2101	Drag Knob	14.05

J31-3601	Drag Washer	7.65
J31-3701	R/S Plate	70.68
J31-3702	R/S Plate	70.68
J31-3801	Handle Assembly	68.51
J31-3901	Yoke Spring	0.66
J31-4801	Line Stopper Spring	0.66
J31-4901	Spool Assembly	75.91
J31-5504	Handle Knob	6.02
J31-5701	Magnet Holder Ret	0.95
J31-5801	HANDLE KNOB CAP	8.17
J31-5802	Handle Knob Cap	2.74
J31-5901	L/S Plate	68.06
J31-5902	Left Side Plate	68.06
J31-6501	Rotor Nut Plt	1.58
J31-6701	Handle Nut Plate Screw	1.32
J31-7301	Body	58.28
J31-7401	Main Shaft	34.81
J31-8002	Body Cover	14.15
J31-8101	Handle Assembly	65.03
J31-8201	Spool Assembly	61.46
J31-9201	Handle Nut Plate	7.34
J31-9202	Handle Nut Plate	7.34
J31-9204	HANDLE LOCK PLATE	7.83
J31-9401	Right Side Plate	138.48
J31-9801	Body	19.67
J32-0401	Osc Gear	6.71
J32-0501	Main Shaft	13.10
J32-0801	Stabilizer Bar	1.92
J32-0901	Collar (F)	1.26
J32-1201	O-Ring	0.95
J32-1301	Side Cover	11.78
J32-1501	Rear Cover	7.34
J32-1503	Rear Cover	7.02
J32-1506	REAR CAP	7.83
J32-1601	Rotor	15.56
J32-1701	Bail Spring Shaft (B)	2.36
J32-1801	Washer (E)	0.50
J32-1901	Bail Spring (B)	0.50
J32-2001	Bail Spring Holder	1.26
J32-2101	Cover (A)	2.36
J32-2103	Bail Spring Cover	2.65
J32-2104	ARM LEVER SPRING COVER	2.04
J32-2401	Rotor Nut	4.13
J32-2501	Line Guard Plate	1.26
J32-2801	Spool Assembly	31.12
J32-3301	Bail Assembly	12.34
J32-3801	Power Cord	103.60

J32-3901	Cover (B)	2.36
J32-6101	Jog Power Lever Screw	1.32
J32-6601	Side Cover (A) O'ring	2.68
J32-7701	Clutch Ring	13.70
J33-2201	Spool Assembly	89.89
J33-2801	Left Side Plate	135.51
J33-3001	Clutch Cam	12.35
J33-3501	Clutch Cam Plate	1.67
J33-3601	Kick Lever Plate (A)	1.67
J33-3701	Kick Lever	12.76
J33-3801	Worm Shield	1.92
J33-4101	Right Side Plate	18.27
J33-4301	Magnet Set Plate	55.84
J33-4501	Lever Plate (A)	4.79
J33-4701	Left Side Plate	135.51
J33-5001	Clutch Lever	1.54
J33-7901	Frame	29.90
J33-7903	Frame	18.94
J33-7908	Frame	35.67
J33-7914	FRAME	29.62
J33-8001	Frame	18.27
J33-8003	Frame	18.43
J33-8008	Frame	37.41
J33-8014	FRAME	29.62
J33-8601	Spool Assembly	46.14
J33-9501	Washer (Thickness 0.05)	1.32
J33-9502	Washer (Thickness 0.1)	1.01
J34-2201	Drive Shaft	11.75
J34-2202	Drive Shaft	11.75
J34-4801	Spool Assembly	31.12
J35-4401	Magnet Assembly	14.05
J35-4801	O-Ring	1.01
J35-4901	Body	18.15
J35-5501	Side Cover	12.53
J35-5701	Rear Cover	7.97
J35-5702	Rear Cover	10.68
J35-5705	REAR CAP	8.17
J35-6101	Spool Assembly	24.53
J35-6501	Drag Washer	4.66
J35-6601	Drag Knob	10.21
J36-1401	Body	19.99
J36-1901	Side Cover	11.99
J36-2101	Rear Cover	7.97
J36-2104	Rear Cover	10.68
J36-2106	REAR CAP	7.49
J36-2601	Spool Assembly	26.58
J36-2901	Drag Knob	10.21

J36-3001	Body	19.34
J36-3501	Side Cover	13.51
J36-3701	Rear Cover	7.97
J36-3705	Rear Cover	10.68
J36-3708	REAR CAP	9.53
J36-3901	Spool Assembly	25.61
J36-4301	Spool Assembly	19.77
J36-4601	Spool Assembly	26.58
J36-4901	Spool Assembly	20.21
J36-6701	MOTOR GEAR(B) BEARING WASHER	1.36
J37-4301	FRAME COVER SHEET	2.04
J37-4401	Frame	86.98
J37-4501	Frame	132.66
J37-4601	Cover	12.03
J37-5101	Bail Assembly	11.39
J37-5201	Drag Knob	10.21
J37-7801	Drive Shaft Collar	10.05
J38-7701	Pinion Gear Collar	3.34
J38-8401	Roller Clutch	22.71
J38-8501	Sealed Cap	2.99
J38-8901	Rear Cover	3.56
J38-8902	Rear Cover	1.32
J38-9001	Rear Cover Screw	1.32
J38-9201	Handle Assembly	31.22
J38-9701	Handle Cap	2.74
J38-9702	Handle Cap	1.67
J38-9801	Body Cover Screw	1.32
J39-3001	Spacing Sleeve	7.06
J39-3201	Infinite Cover	4.35
J39-3301	Sealed Cap	2.27
J39-3602	Bail Assy	69.72
J39-4101	Rotor Nut	2.43
J39-4902	Handle Screw Cap	1.58
J39-6001	Packing	1.89
J39-7201	Packing	4.00
J39-7301	Spacing Sleeve	11.03
J39-7803	Handle Screw Cap	2.02
J39-8201	Atd-Drag Washer Kit	6.87
J39-8301	Atd-Drag Washer Kit	7.84
J39-8501	Atd-Drag Washer Kit	8.51
J39-8801	Atd-Drag Washer Kit	41.17
J39-8901	Atd-Drag Washer Kit	64.70
J40-1401	Collar	4.79
J40-3001	Left Side Cover	91.12
J40-3201	Drag Washer A	12.35
J40-4701	Drag Knob	35.67
J40-6701	Sealed Cap	2.99

J40-6801	Rear Cover	3.56
J40-6802	Rear Cover	1.32
J40-6901	Handle Assembly	31.22
J40-7701	Kick Lever Plt Spring	1.67
J40-7801	Kick Lever Plate Spring	1.67
J40-7901	MOTOR CASE PLATE(A)	26.55
J41-0801	Pin Spring	0.50
J41-0901	Pin	1.32
J41-5501	Drag Knob	22.22
J41-5801	Clamp Screw Nut (Short)	6.68
J41-5802	Clamp Screw Nut (Long)	7.34
J41-6001	Collar (C)	8.95
J41-6101	Handle Assembly	53.28
J41-6501	Handle Assembly	22.15
J41-7201	Body	60.45
J41-7501	Body Cover	45.45
J41-8101	Handle Screw Cap	1.92
J41-8102	HANDLE CAP	6.81
J41-8601	Handle Assembly	62.20
J41-8801	Spool Assembly	60.62
J41-9001	Body	55.02
J41-9301	Body Cover	40.02
J41-9302	BODY COVER	36.34
J41-9401	Bail Assy	54.16
J41-9601	Spool Assembly	64.37
J41-9801	Body	54.37
J42-0001	Body Cover	38.27
J42-0101	Bail Assembly	54.16
J42-0301	Handle Assembly	52.85
J42-0701	Spool Assembly	68.72
J42-0901	Body	52.19
J42-1201	Main Shaft	6.36
J42-1401	Body Cover	15.03
J42-1501	Line Roller	9.04
J42-1601	Handle Assembly	61.52
J42-1801	Spool Assembly	84.60
J42-2001	Spool Assembly	32.92
J42-2201	Body Assembly	41.10
J42-2501	Main Shaft	18.40
J42-2701	Body Cover	15.03
J42-2801	Handle Assembly	61.52
J42-3001	Packing	1.39
J42-3101	Spool Assembly	138.97
J42-3301	Spool Assembly	120.83
J42-3501	Washer (J)	0.95
J42-3601	Bail Assembly	62.75
J42-4001	Frame	198.13

J42-4301	Motor Transmission Gear	56.11
J42-4601	Spool Assembly	206.68
J42-4801	Spool Shaft	15.72
J42-4901	Worm Shaft Guard	49.36
J42-5001	Worm Shaft Assembly	49.36
J42-5201	Ic Module	461.29
J42-5401	Front Cover	50.12
J42-5501	Motor Guard Plate	18.40
J42-5601	Jog Power Lever (A)	45.77
J42-5901	Ic Module Cover	65.84
J42-6003	Ic Module Cover Plate	10.68
J42-6101	Left Side Plate	100.92
J42-8101	Pinion Gear Collar	3.34
J42-8801	Magsealed Cap	3.09
J42-8901	Magsealed Plate	14.05
J42-9301	Sealed Plt Screw	1.32
J42-9401	Rear Cover	3.62
J42-9901	Handle Cap	2.74
J43-0801	Spool Assembly	80.54
J43-1101	Spool Assembly	80.03
J43-1401	Spool Assembly	79.52
J43-1601	Roller Clutch Washer	1.01
J43-1802	Cover	14.36
J43-2001	Packing	1.89
J43-2501	SPOOL HOLDER	12.93
J43-2601	Rotor Nut	2.87
J43-2701	Level Wind Guard	2.02
J43-2801	Worm Shaft Guard	2.99
J43-3901	Handle Assembly	27.51
J43-5101	Bail Trip Lever Spring	1.32
J43-5201	Bail Trip Lever Spring	1.32
J43-7001	Stabilizer Bar	5.36
J44-1201	Handle Assembly	23.02
J44-1301	Handle Assembly	23.12
J44-1401	Handle Assembly	25.61
J44-1601	Right Side Plate	95.47
J44-1602	Right Side Plate	95.47
J44-1901	Frame	102.21
J44-2101	Clutch Lever Plate (R)	1.01
J44-2201	Clutch Lever Plate (L)	1.01
J44-2301	Clutch Lever	9.36
J44-2401	Drive Shaft	20.66
J44-2402	Drive Shaft	20.66
J44-2501	T-Line Guide	66.54
J44-3001	Key Washer	23.06
J44-3101	Magnet Set Plate	47.19
J44-3301	Lever Plate (A)	5.01

J44-3801	Left Side Plate	95.47
J44-3802	Left Side Plate	95.47
J44-4001	Frame	102.19
J44-4501	Right Side Plate	18.92
J44-4701	Magnet Set Plate	47.19
J44-4901	Lever Plate (A)	5.01
J44-5901	Sealed Cap	2.68
J45-4701	Body / Sabayj3500h-4000	70.46
J45-5001	Drive Bearing Cover	20.23
J45-5103	Body Cover	44.36
J45-5201	Bail Assy / Sabayj35-40	107.87
J45-5501	Handle Assembly	114.62
J45-6101	Spool Assy / Sabayj3500h	174.64
J45-7101	Spool Assy / Sabayj4000	179.44
J45-8101	O'ring	1.01
J45-8201	Handle	22.61
J45-8301	Left Side Plate	18.92
J45-8401	Drag Knob	22.18
J46-1501	HANDLE ASSEMBLY	44.35
J46-1902	BODY	34.29
J47-2101	Level Wind	5.67
J47-2201	Handle Assembly	24.78
J47-2301	Cast Control Cap	18.22
J47-2302	Cast Control Cap	20.87
J47-2303	Cast Control Cap	20.87
J49-2601	REAR CAP	6.13
J49-5301	REAR CAP	6.13
J49-6901	Osc Gear Washer	1.32
J49-7001	Spool Holder Washer A	0.50
J49-8701	Level Wind	58.08
J49-9001	Worm Shield	13.04
J49-9101	Level Wind Post Retainer	3.69
J49-9201	Drive Collar	26.08
J51-0101	RS COVER PLATE SCREW	1.70
J51-7101	Drag Washer	14.36
J51-9701	Bail Arm	17.70
J52-4901	Rear Cover	3.56
J52-4902	Rear Cover	1.32
J52-6101	Osc Support Post	0.79
J52-7501	LEVEL WIND POST	4.42
J53-0401	ROLLER COLLAR (A)	3.06
J53-0501	ROLLER COLLAR (B)	4.77
J53-5801	Oscillating Gear	4.16
J53-6101	Roller Clutch Slv Collar	6.02
J53-6102	CLUTCH RING	11.23
J53-6201	Roller Clutch Sleeve	2.33
J53-6202	Collar	5.01

J53-6204	CLUTCH RING COLLAR	0.50
J53-6301	Handle Assembly	27.51
J53-6801	Rotor	31.53
J53-6802	ROTOR	30.35
J53-6901	Bail Trip Lever	6.02
J53-7101	Cover	8.03
J53-7102	ARM LEVER SPRING COVER	8.17
J53-7701	Cover	8.03
J53-7702	BAIL HOLDER COVER	8.17
J53-7801	Roller Magnet Assembly B	16.38
J53-8001	Mag Roller Collar	6.36
J53-8101	Line Guard Ring	2.02
J53-8401	Roller Magnet Assembly A	16.38
J54-0401	Roller Clutch	23.09
J54-1701	WORM SHIELD	12.93
J54-1901	Clutch Cam Plate	1.32
J54-4601	Osc Gear	6.43
J54-4803	Main Shaft	7.40
J54-4804	MAIN SHAFT	8.85
J54-5301	Rotor	14.15
J54-5306	ROTOR	33.02
J54-5313	ROTOR	0.50
J54-5401	Kick Lever	4.35
J54-5601	Bail Arm Lever Shaft	0.50
J54-5701	Arm Lever Sp Cover	2.30
J54-5702	Arm Lever Sp Cover	2.68
J54-5801	Bail Assembly	37.62
J54-6201	Click Leaf Spring Holder	2.02
J54-6300	Spool Washer	1.01
J54-6301	SPOOL WASHER (A)	0.68
J54-6701	Drag Collar	3.69
J54-6801	DRAG WASHER	2.00
J54-6901	Drag Key Washer	1.42
J54-6902	Drag Key Washer	4.69
J54-7001	Drag Disc Washer	0.50
J54-7101	Drag Retainer	0.50
J54-7201	Drag Knob	9.89
J54-7202	Drag Knob	17.70
J54-9001	Drag Disc Washer	2.46
J54-9002	Drag Disc Washer	2.36
J54-9101	Body	28.70
J54-9301	Body Cover	11.07
J54-9501	Spool Metal	3.81
J55-0808	Body	286.20
J55-1201	Body Set Plate	32.19
J55-1301	O'ring	1.01
J55-1401	Gear Washer	0.66

J55-1501	Oscillating Gear	7.02
J55-1701	Main Shaft	21.75
J55-2001	Collar	2.68
J55-2101	Bearing Plate	6.36
J55-2102	PINION BEARING PLATE	3.74
J55-2201	Screw	3.69
J55-2202	PINION BEARING PLATE SCREW	0.68
J55-2701	Drive Gear Ring	1.01
J55-2802	Side Cover	17.06
J55-2907	Body Cover	39.59
J55-2908	Body Cover	39.59
J55-3001	O'ring B	3.34
J55-3101	Oscillating Post	5.01
J55-3102	Pillar	5.36
J55-3201	Packing	7.02
J55-3301	Rear Cover	20.07
J55-3501	Collar	1.67
J55-3601	Screw	4.35
J55-3603	REAR CAP SCREW (A)	4.42
J55-3701	Packing	3.34
J55-3802	MAGSEALED PLATE	38.46
J55-3803	Magsealed Cap	22.40
J55-4101	Washer	1.32
J55-4501	Stopper Cover	27.41
J55-4701	Screw	6.68
J55-4801	Spacing Sleeve	13.70
J55-4901	Packing	2.68
J55-5102	Handle Assembly	81.77
J55-5103	Handle Assembly	83.07
J55-5501	Washer	0.66
J55-5901	Handle Screw Cap	7.69
J55-6001	Spool Assembl	144.21
J55-6301	O'ring	1.01
J55-6501	Key Washer	2.68
J55-6601	Drag Ratchet	8.69
J55-6701	Drag Retainer	0.50
J55-6801	Drag Knob	40.67
J55-8001	Line Stopper	0.66
J55-8101	Line Stopper Plate	0.66
J55-8201	Spool Metal Screw	0.50
J55-8202	Spool Metal Screw	0.50
J55-8301	Hanlde Assembly	31.22
J55-8801	Osc Gear	6.43
J55-8901	Main Shaft	30.87
J55-8902	MAIN SHAFT	8.85
J55-9101	Bail Assembly	38.07
J55-9501	Body	28.70

J55-9701	Main Shaft	7.40
J55-9702	MAIN SHAFT	11.23
J56-0001	Body Cover	11.07
J56-0101	Bail Assembly	37.62
J56-0501	Drag Knob	9.89
J56-0502	Drag Knob	17.70
J56-0802	IC MODULE	403.55
J56-0901	MAGSHIELD CAP	2.86
J56-1201	Eared Washer	2.68
J56-1801	ATD DRAG WASHER ASS(3pcs pack)	13.46
J56-1901	DRAG WASHER	16.61
J56-2001	DRAG WASHER	8.03
J56-3601	Line Stopper Plate	0.66
J56-3701	Drag Disc Washer (A)	2.33
J56-3801	Drag Disc Washer	13.36
J56-4101	Spool Metal	3.81
J56-6101	ROLLER COLLAR (A)	1.36
J56-6201	Drive Collar Pin	2.02
J56-6301	A/R Claw	2.33
J56-6501	Body	28.70
J56-6701	Osc Gear	6.43
J56-6901	Main Shaft	30.87
J56-6902	Main Shaft	30.87
J56-6903	MAIN SHAFT	8.85
J56-7401	Body Cover	26.32
J56-7501	Rotor	17.18
J56-7504	Rotor	15.17
J56-7508	ROTOR	19.95
J56-7510	ROTOR	22.59
J56-7517	ROTOR	0.50
J56-7601	Kick Lever Assembly	2.68
J56-7801	Arm Lever Sp Cover	2.36
J56-7802	Arm Lever Sp Cover	2.99
J56-7901	Bail Assembly	38.07
J56-8601	Line Stopper Plate	0.66
J56-9301	Bail Assembly	38.07
J57-0107	Body	281.22
J57-0301	Body Set Plate	35.24
J57-0401	Oscillating Gear	7.34
J57-0601	Main Shaft	21.75
J57-1302	Side Cover	17.06
J57-1406	Body Cover	17.06
J57-1501	O'ring	2.93
J57-1601	Packing	8.03
J57-1701	Rear Cap	20.07
J57-1801	Collar	1.67
J57-1901	Rotor	46.54

J57-1903	ROTOR	37.88
J57-2001	Bail Trip Lever	6.36
J57-2201	Cover	9.36
J57-2202	ARM LEVER SPRING COVER	9.53
J57-2701	Cover	9.36
J57-2702	BAIL HOLDER COVER	9.53
J57-3401	Drag Knob	41.76
J57-5701	Body	29.01
J57-5901	Osc Gear	6.46
J57-6101	Main Shaft	30.87
J57-6301	Body Cover	28.93
J57-6401	Bail Assembly	38.13
J57-6601	Spool Metal	3.87
J57-6700	Spool Washer	1.10
J57-6801	Handle Assembly	39.81
J57-7301	Drag Key Washer	4.00
J57-7401	Drag Disc Washer	2.99
J57-7501	Drag Disc Washer	4.35
J57-9901	Drag Knob	11.03
J58-1201	Motor Washer	2.68
J58-1601	Motor O'ring (B)	4.00
J58-2502	Body Cover	19.35
J58-4602	Body Cover	24.15
J58-6602	Body Cover	23.27
J58-7101	Spool Metal Collar	0.50
J58-7901	Body Set Plate	33.70
J58-8201	Collar	3.56
J58-8801	O'ring	2.99
J58-8901	O'ring	3.02
J58-9001	Packing	8.03
J58-9101	Rear Cover	20.07
J59-0701	Handle Assembly	81.55
J59-3401	CLUTCH LEVER PLATE (R)	8.17
J59-3501	CLUTCH LEVER PLATE (L)	8.17
J59-3601	CLUTCH CAM BEARING	5.11
J59-3701	CLUTCH LEVER (A)	10.55
J59-3901	CLUTCH CAM	1.70
J59-4001	CLUTCH CAM PLATE	10.21
J59-4101	LEVEL WIND	9.53
J59-4301	WORM SHIELD	13.62
J59-4501	WORM SHAFT	13.96
J59-4601	WORM SHAFT COLLAR (A)	2.38
J59-4701	WORM SHAFT GEAR	16.68
J59-4801	LEVEL WIND POST	6.47
J59-4901	MOTOR GEAR COLLAR	10.55
J59-5301	MOTOR GEAR METAL	176.53
J59-5601	MOTOR GEAR (A)	26.21

J59-5901	MOTOR GEAR (B)	19.40
J59-6001	CLUTCH LEVER (B) COLLAR	4.08
J59-6101	CLUTCH LEVER (B) STOPPER SPRING	1.70
J59-6201	CLUTCH LEVER (B) STOPPER	3.40
J59-6301	CLUTCH LEVER (B)	6.81
J59-6401	SPOOL	14.43
J59-6601	SPOOL GEAR (A)	1.70
J59-6701	SPOOL SHAFT	6.13
J59-6801	SPOOL SHAFT GEAR (A)	9.53
J59-6901	SPOOL GEAR BEARING COLLAR	4.08
J59-7001	SPOOL SHAFT GEAR (B)	19.06
J59-7101	SPOOL GEAR (B)	44.42
J59-7301	SPOOL PLATE COLLAR	3.40
J59-7401	SPOOL PLATE	17.02
J59-7601	IDLE GEAR (A)	30.29
J59-7801	IDLE GEAR (B)	1.70
J59-7901	IDLE GEAR (C)	1.70
J59-8001	SET PLATE	71.82
J59-8101	IDLE GEAR (D) PLATE	16.00
J59-8201	IDLE GEAR (D)	64.92
J59-8501	IC MODULE POST	7.15
J59-8601	JOG POWER LEVER (A)	22.97
J59-9001	JOG POWER LEVER HOLDER (R)	3.40
J59-9101	JOG POWER LEVER HOLDER (L)	3.06
J59-9201	JOG POWER LEVER (B)	8.17
J59-9301	IC MODULE COVER	26.00
J59-9401	L/S PLATE	106.11
J59-9901	GEAR SHAFT	21.78
J60-0001	CLUTCH CAM SPRING	2.04
J60-0101	RATCHET	6.47
J60-0201	DRIVE GEAR WASHER	7.15
J60-0301	DRIVE GEAR	27.33
J60-0501	DRAG COLLAR	13.27
J60-0601	PINION GEAR	22.21
J60-0901	CLUTCH LEVER (C)	6.81
J60-1101	R/S COVER PLATE	7.02
J60-1701	Oscillating Gear	7.02
J60-1901	Main Shaft	20.89
J60-2101	Click Holder Washer	1.10
J60-2201	Click Leaf Spng Hold Wash	1.01
J60-2501	FRAME	173.87
J60-2602	IC MODULE COVER PLATE	9.53
J60-2901	Handle Assembly	39.16
J60-3701	Handle Assembly	50.02
J60-4501	Handle Assembly	61.99
J60-8901	Oscillating Gear	5.36
J60-9102	Screw	9.70

J60-9104	Screw	9.01
J60-9105	Screw	11.37
J61-4001	Main Shaft	20.44
J61-5301	Drag Knob	38.70
J61-5601	Handle Assembly	43.71
J61-8201	SPOOL HOLDER	14.98
J61-8501	OSCILLATING GEAR	7.49
J61-8701	Body	28.70
J62-2901	Clutch Trip Lever	15.31
J62-3201	RS PLATE	134.90
J62-3401	Zero Adjuster	15.37
J62-3701	Clutch Lever Plate (L)	1.01
J62-3801	Worm Shield Plate	3.69
J62-3901	RS PLATE SCREW (A)	6.81
J62-4301	HANDLE	105.66
J62-4601	LS PLATE	81.07
J62-4801	Lever Plate	4.69
J62-4901	Mag Dial Collar	1.01
J62-5002	Mag Dial	6.36
J62-5101	Mag Dial Plate	4.35
J62-5201	Left Side Cover	34.58
J62-5202	Right Side Cover	34.58
J62-5401	Handle Cap	1.67
J62-6401	MAIN SHAFT	35.89
J62-8301	INFINITE COVER "O"RING	1.36
J62-9201	Handle Assembly	64.31
J63-1901	Lever Plate Spring	0.50
J63-2102	SPOOL ASSEMBLY(2-8)	56.27
J63-2302	Handle Cap Screw	4.00
J63-2303	Right Side Plate Screw C	0.66
J63-2401	Mag Holder	24.73
J63-3001	Clutch Lever Plate R	1.01
J63-3601	Lever Plate	3.69
J63-3801	FINGER COVER	33.70
J63-3901	LINE GUARD	16.00
J63-5101	Lever Plate Collar	4.00
J63-8601	KICK LEVER	5.15
J63-9900	Roller Clutch Washer	0.66
J63-9901	WASHER	0.57
J64-2001	BAIL ASSY	21.07
J64-2701	CLUTCH LEVER (B)SPRING	60.69
J64-2801	Bail Lever Shaft Spring	0.50
J64-4701	Osc Gear Washer	0.66
J64-4901	STOPPER PIN	1.70
J64-5101	MEGATWIN LEVER PLATE	1.36
J64-7201	BAIL ASSY	21.29
J64-9501	Body	45.24

J64-9601	Body	46.33
J64-9701	Body	46.33
J64-9801	Body	52.85
J65-3001	Worm Shaft	11.69
J65-3101	Handle	104.61
J65-3201	Handle Knob	6.02
J65-3502	XXXXXXXXXXXXXXXXXXXX	0.01
J66-6601	Right Side Plate Screw A	6.68
J66-7001	Handle Assembly	42.85
J66-7103	Right Side Plate	128.60
J66-7401	Left Side Plate	132.68
J66-8201	Spool Assembly	31.53
J66-8401	Spool Assembly	24.09
J66-8901	Spool Assembly	24.09
J66-9401	Spool Assembly	31.53
J66-9501	Spool Assembly	32.92
J66-9701	Spool Assembly	35.18
J67-0101	Spool Assy	32.92
J67-0401	Spool Assembly	35.18
J67-0501	Spool Assembly	35.18
J67-0901	SPOOL ASSY	58.28
J67-1101	Spool Assembly	35.18
J67-1401	Spool Assembly	61.77
J67-1701	Spool Assembly	33.01
J67-2101	HANDLE KNOB ASSY	13.27
J67-2901	Right Side Plate	132.68
J67-3101	Frame	154.41
J67-3301	Frame	154.41
J67-3401	Left Side Plate	79.60
J67-3501	Right Side Plate	79.60
J67-3902	Star Drag	20.87
J67-5001	FRAME	76.07
J67-5201	Magsealed Plate	14.05
J67-5301	Sealed Plate	3.34
J67-8801	Atd Drag Washer (3Pcs)	7.69
J67-8901	Drag Washer	5.67
J67-9001	Atd Drag Washer (3Pcs)	7.02
J67-9101	Atd-Drag Washer Kit	6.02
J68-3001	Pinion Gear Bb Sprng Wash	0.66
J68-3101	Handle Knob Cap	8.03
J68-8201	Magsealed Plate	11.69
J69-0101	Collar	7.02
J69-0201	Collar	6.36
J69-2001	ZERO ADJUSTE WASHER (A)	1.36
J69-2201	Right Side Plate	9.98
J69-2202	Right Side Plate	9.98
J69-2203	RS PLATE	10.13

J69-2207	RS PLATE	27.91
J69-2208	RS PLATE	27.91
J69-2209	RS PLATE	27.91
J69-2502	Cast Control Cap	14.71
J69-2601	Frame	26.58
J69-2603	FRAME	0.01
J69-2605	FRAME	28.66
J69-2606	FRAME	52.08
J69-2701	Clutch Lever Plate (R)	1.54
J69-2801	Clutch Lever Plate (L)	1.54
J69-2901	Clutch Cam	18.02
J69-3201	Plate A	1.29
J69-3301	Clutch Lever	1.54
J69-3401	Collar	1.54
J69-3501	Drive Shaft	11.75
J69-3502	GEAR SHAFT	0.01
J69-3601	Drive Shaft Gear	1.73
J69-3701	Gear Shaft Plate	1.39
J69-3901	Worm Shaft	12.69
J69-4001	Level Wind Guard	2.36
J69-4202	Pinion Gear	11.08
J69-4302	Drive Gear	15.28
J69-4401	Key Washer	2.68
J69-4602	FRONT PLATE	10.58
J69-4605	FRONT COVER	8.85
J69-4606	FRONT COVER	11.91
J69-4702	LEFT SIDE PLATE	18.45
J69-4704	LEFT SIDE PLATE	21.93
J69-4901	Brake Adj Kno B	4.85
J69-4902	BRAKE DIAL	0.01
J69-5001	Magnet Holder	7.02
J69-5402	Pinion Gear	7.87
J69-5502	Drive Gear	11.69
J69-5602	Pinion Gear	24.07
J69-5702	DRIVE GEAR	25.05
J69-7001	DRAG KNOB	20.08
J69-7601	DRAG KNOB	20.42
J69-8701	Drag Knob	20.73
J69-8702	Drag Knob	17.64
J70-3101	CLICK HOLDER WASHER	1.70
J70-5801	GEAR SHAFT PLATE	6.47
J70-9901	Pinion Gear	10.00
J71-5101	LS PLATE	9.84
J71-5102	LS PLATE	9.84
J71-5107	LS PLATE	0.50
J71-5108	LS PLATE	0.50
J71-5109	LS PLATE	0.50

J71-5301	FRAME	18.10
J71-5303	FRAME	0.01
J71-5305	FRAME	28.09
J71-5306	FRAME	0.50
J71-5401	CLUTCH CAM	0.01
J71-5701	KICK LEVER PLATE (A)	0.01
J71-5801	WORM SHIELD	0.01
J71-5902	PINION GEAR	7.87
J71-6002	DRIVE GEAR	25.05
J71-6101	RIGHT SIDE PLATE	10.13
J71-6102	RIGHT SIDE PLATE	30.33
J71-6104	RIGHT SIDE PLATE	35.40
J71-6301	Break Dail Screw	4.00
J71-6402	PINION GEAR	7.87
J71-6502	DRIVE GEAR	25.05
J71-8501	Washer	0.66
J71-8601	O'ring	1.01
J72-4001	Retainer	8.35
J72-4601	PINION BALL BEARIG COLLAR	17.70
J72-8402	Mag Dial	6.36
J72-8801	Handle Assembly	37.66
J72-9101	Rotor Nut Packing	4.00
J72-9201	WORM SHAFT	11.57
J73-1201	Lever Plate Pin	2.33
J73-1301	Lever Plate Spring	0.66
J73-1701	O'ring	1.01
J73-3501	JOG POWER LEVER COLLAR	1.36
J73-3701	Body Assembly	248.89
J73-3801	Body Cover	42.41
J73-3901	Spool	147.89
J73-4201	Spool Assembly	150.72
J73-6201	ROLLER COLLAR PACKING	2.38
J73-6801	Spool Assembly	159.12
J73-7001	Spool Assembly	159.12
J73-7401	Spool Assembly	158.12
J73-7801	RS PLATE	151.29
J73-8101	MECHANICAL BRAKE KNOB	0.50
J73-8201	FRAME	134.02
J73-8401	CLUTCH LEVER PLATE(R)	1.02
J73-8501	CLUTCH LEVER PLATE(L)	1.02
J73-8601	RS PLATE COVER	2.38
J73-8701	CLUTCH CAM	12.25
J73-9001	CLUTCH CAM PLATE	3.06
J73-9101	KICK LEVER PLATE (A)	3.06
J73-9201	CLUTCH LEVER	9.53
J73-9401	GEAR SHAFT	33.02
J73-9402	GEAR SHAFT	33.02

J73-9501	LEVEL WIND	0.50
J73-9504	LEVEL WIND	61.58
J73-9901	WORM SHAFT	14.30
J74-0001	WORM SHIELD	2.38
J74-0101	PAWL	8.85
J74-0201	LEVEL WIND PIN	2.38
J74-0501	DRIVE COLLAR	23.49
J74-0601	HANDLE ASSEMBLY	71.33
J74-0901	FRONT COVER	0.50
J74-0904	FRONT COVER	12.59
J74-1001	OSCILLATING POST	8.51
J74-1101	LS PLATE	25.87
J74-1301	SET PLATE	44.97
J74-1601	LEVER PLATE (A)	3.06
J74-1703	LEVER PLATE (C)	2.38
J74-1801	BRAKE DIAL	11.91
J74-1803	BRAKE DIAL	11.91
J74-1901	MAGNET HOLDER	27.23
J74-2201	MAGNET HOLDER RING	2.38
J74-2601	LEVER PLATE (B)	1.36
J75-7501	Drag Disc Washer	5.67
J76-3501	RS PLATE	150.63
J76-4501	PINION BEARING COLLAR	8.17
J76-4801	LS PLATE	141.99
J76-5001	FRAME	134.02
J76-5003	FRAME	0.50
J76-5201	LS PLATE COVER	1.02
J76-5301	CLUTCH CAM	12.25
J76-5601	CLUTCH CAM PLATE	1.02
J76-5701	KICK LEVER PLATE (A)	1.02
J76-5801	WORM SHIELD	2.38
J76-6001	RS PLATE	25.87
J76-6201	SET PLATE	44.97
J76-6401	LEVER PLATE (A)	3.06
J77-3302	BODY ASSY	52.96
J77-3601	MAIN SHAFT	18.04
J77-4102	ENGINE PLATE(R)	30.63
J77-4205	ENGINE PLATE(L)	36.42
J77-4301	OSCILLATING POST	5.11
J77-4401	REAR CAP PACKING	7.15
J77-4501	REAR CAP	10.55
J77-4601	REAR CAP SCREW (B)	0.68
J77-4701	MAGSEALED CAP	8.85
J77-4801	CLUCH RING	7.15
J77-4901	SPOOL ASSY	78.20
J77-5201	DRAG KNOB ASSY	31.01
J77-5301	HANDLE ASSY	49.35

J77-5901	BODY	0.50
J77-6001	SET PLATE	7.83
J77-6101	ONEWAY CLUTCH	18.04
J77-7001	DRIVE BEARING (A) COVER	16.00
J77-7109	ENGINEPLATE	46.63
J77-7202	REAR CAP SCREW	8.51
J77-7203	REAR CAP SCREW	5.11
J77-7301	REAR CAP PACKING	3.40
J77-7401	REAR CAP	7.49
J77-7601	MAGSEALED PLATE	11.91
J77-7802	MAGSEALED PLATE COLLAR	5.45
J77-7901	MAGSEALED CAP	6.81
J77-8101	HANDLE CAP	4.08
J77-8201	PINION BALLBEARING PLATE	2.38
J78-0301	LS PLATE	141.77
J78-2101	MAGSEALED CAP SCREW	5.45
J78-2301	BAIL ASSEMBLY	32.78
J78-2701	SPOOL ASSEMBLY	41.18
J78-3002	BODY ASSY	87.13
J78-3301	MAIN SHAFT	19.06
J78-3702	ENGINE PLATE(R)	22.81
J78-3803	ENGINE PLATE(L)	38.46
J78-3804	ENGINE PLATE(L)	46.63
J78-3901	REAR CAP PACKING	8.17
J78-4001	REAR CAP	10.55
J78-4101	SPOOL ASSY	85.61
J78-4401	DRAG KNOB ASSY	33.01
J78-4501	HANDLE ASSEMBLY	64.17
J79-0301	MEGATWIN LEVER PLATE SCREW(B)	1.02
J79-1001	MAGSEALED PLATE"O"RING	3.06
J79-1201	BDY ASSY	12.43
J79-1501	BODY COVER	18.61
J79-1601	HANDLE ASSY	28.66
J79-1801	SPOOL ASSY (2-5)	18.26
J79-1901	DRAG KNOB ASSY	5.11
J79-2001	BDY ASSY	14.59
J79-2301	BODY COVER	19.71
J79-2501	SPOOL ASSY	29.04
J79-2601	BDY ASSY	13.62
J79-2901	BODY COVER	17.94
J79-3001	HANDLE ASSY	15.78
J79-3201	SPOOL ASSY (2-5)	16.42
J79-3301	DRAG KNOB ASSY	5.11
J79-3401	BDY ASSY	15.67
J79-3701	BODY COVER	23.04
J79-3801	HANDLE ASSY	18.91
J79-3901	SPOOL ASSY (2-5)	18.69

J79-4101	DRAG KNOB ASSY	7.15
J79-4201	SPOOL ASSY (2-5)	20.85
J79-4401	BDY ASSY	18.05
J79-4701	BODY COVER	19.94
J79-4801	HANDLE ASSY	18.26
J79-4901	SPOOL ASSY (2-5)	27.01
J80-0102	BODY ASSY	91.11
J80-0401	OSCILLATING POST	4.42
J80-0501	MAIN SHAFT	19.40
J80-0902	ENGINE PLATE(R)	36.08
J80-1004	ENGINE PLATE(L)	38.46
J80-1101	ENGINE PLATE PACKING)	2.38
J80-1201	REAR CAP PACKING	5.79
J80-1301	REAR CAP	10.55
J80-1401	BAIL ASSY	31.32
J80-2101	HANDLE CAP	7.49
J80-2201	REAR CAP SCREW (A)	4.77
J80-2301	HANDLE ASSY	57.32
J80-2801	OSCILLATING GEAR	5.79
J80-2901	PINION BEARING(B) COLLAR	2.38
J80-8501	Collar	6.02
J80-8601	FRAME	236.64
J80-9001	POWER LEVER	52.50
J80-9201	IC MODULE COVER	22.46
J80-9301	R/S PLATE	57.86
J81-1301	BODY ASSY	34.90
J81-1501	BODY COVER ASSY	23.26
J81-1701	HANDLE ASSY	25.61
J81-2101	DRAG KNOB	27.23
J81-2401	BODY ASSY	35.55
J81-2501	MAIN SHAFT	13.27
J81-2801	HANDLE ASSY	26.26
J81-3201	BODY ASSY	36.74
J81-3401	BODY COVER ASSY	27.69
J81-3501	HANDLE ASSY	26.26
J81-3701	DRAG KNOB	27.23
J81-5301	BODY ASSY	36.74
J81-5401	HANDLE ASSY	25.61
J81-5501	DRAG KNOB	28.25
J81-5601	BODY ASSY	34.90
J81-5801	BODY COVER ASSY	28.80
J81-5901	HANDLE ASSY	25.07
J81-6301	SPOOL ASSY (2-5)	26.47
J81-7601	PINION GEAR	12.93
J81-7701	DRIVE GEAR	12.34
J83-2701	MAIN SHAFT	18.04
J83-6801	SPOOL ASSY	21.29

J83-6901	SPOOL ASSY	21.29
J83-7001	SPOOL ASSY	25.07
J83-7101	SPOOL ASSY	24.64
J83-7201	SPOOL ASSY	25.18
J83-7301	SPOOL ASSY	27.34
J83-7491	Parts-Procyon Lt 1000D-XH Spool	35.09
J83-7591	Parts-Procyon Lt 2000D-XH Spool	35.09
J83-7691	Parts-Procyon Lt 2500D-XH Spool	39.44
J83-7891	Parts-Procyon Lt 3000D-CXH Spool	40.10
J83-7991	Parts-Procyon Lt 4000D-CXH Spool	40.45
J83-8001	OSCILLATING GEAR	13.96
J84-3301	BRAKE DIAL RETAINER(B)	0.68
J85-2402	BODY	52.73
J85-2501	MAIN SHAFT	0.50
J85-3105	ENGINEPLATE	46.63
J85-3201	REAR CAP	8.51
J86-3601	SPOOL ASSY	78.78
J87-6201	R/S PLATE	0.01
J87-6202	R/S PLATE	0.01
J87-6203	R/S PLATE	20.50
J87-6204	R/S PLATE	20.50
J87-6205	R/S PLATE	20.50
J87-6206	R/S PLATE	20.50
J87-6207	R/S PLATE	20.50
J87-6701	DRIVE GEAR	0.01
J87-6901	L/S PLATE	0.01
J87-7301	L/S PLATE	0.01
J87-7302	L/S PLATE	18.60
J87-7303	L/S PLATE	18.60
J87-7304	L/S PLATE	18.60
J87-7305	L/S PLATE	18.98
J87-7306	L/S PLATE	18.98
J87-7501	DRIVE GEAR	0.01
J87-7601	R/S PLATE	0.01
J87-7701	HANDLE ASSY	0.01
J87-8301	CLAMP SCREW (Short)	2.04
J87-8401	CLAMP PLATE NUT	5.11
J87-8701	MAIN SHAFT	18.04
J87-8801	SPOOL ASSY	79.60
J87-9401	SPOOL ASSY	76.50
J88-0201	SPOOL ASSY	78.77
J88-2401	R/S PLATE	53.53
J88-6201	BRAKE DIAL LEAF SPRING	1.36
J88-7901	DRIVE GEAR	0.01
J89-0601	BAIL ASSY	155.62
J89-0701	BAIL ASSY	40.81
J89-1101	BAIL ASSY	28.33

J89-3107	BODY	0.01
J89-3108	BODY	0.01
J89-3109	BODY	88.82
J89-3601	OSCILLATING GEAR WASHER	1.02
J89-3701	OSCILLATING GEAR	8.85
J89-3801	IDLE GEAR	34.04
J89-3901	DRIVE BEARING(A)WASHER	0.68
J89-4001	DRIVE BEARING(A) COVER	39.87
J89-4101	DRIVE BEARING(A) COVER"O"RING	1.70
J89-4201	MAIN SHAFT	36.08
J89-4401	OSCILLATING POST COLLAR	3.06
J89-4601	OSCILLATING POST	6.47
J89-4602	OSCILLATING POST	6.47
J89-4701	REAR CAP PACKING	4.77
J89-4801	REAR CAP	40.50
J89-4901	REAR CAP SCREW(A)	1.36
J89-5001	REAR CAP SCREW(B)	6.81
J89-5002	REAR CAP SCREW(B)	7.15
J89-5101	PINION BEARING(B) COLLAR	4.08
J89-5601	STOPPER SPRING	0.50
J89-5701	PINION BEARING(A) COLLAR	2.04
J89-5801	PINION BEARING(A) PLATE	6.13
J89-5904	ENGINE PLATE	0.50
J89-5905	ENGINEPLATE	0.50
J89-6001	CLUCTH RING	30.97
J89-6101	INFINITE COVER	33.70
J89-6201	ROTOR	49.81
J89-6301	ROTOR BRAKE SHAFT	5.11
J89-6401	ROTOR BRAKE SPRING	0.68
J89-6601	ARM LEVER PLATR	2.38
J89-6701	HOLDER SCREW	1.02
J89-6801	ARM LEVER COVER	8.51
J89-6901	BAIL	0.01
J89-7401	BAIL HOLDER PLATE	2.38
J89-7501	ROLLER MAG COLLAR(A)	13.96
J89-7801	LINE ROLLER	10.55
J89-7901	ROLLER MAG COLLAR(B)	11.23
J89-8001	ROTOR NUT COLLAR	6.13
J89-8101	ROTOR NUT PACKING	4.08
J89-8201	ROTOR COVER	4.08
J89-8301	SPOOL PLATE	7.49
J89-8401	SPOOL PLATE PACKING(B)	4.08
J89-8501	SPOOL PLATE PACKING(A)	4.77
J89-8600	SPOOL WASHER	0.50
J89-8701	SPOOL ASSY	126.10
J89-9301	SPOOL BALLBEARING(B)	11.23
J89-9401	DRAG WASHER	7.83

J89-9501	DRAG DISC WASHER	1.36
J89-9601	DRAG LIP WASHER	1.36
J89-9701	SPOOL BALLBEARING(A) COLLAR	9.87
J89-9801	SPOOL BALLBEARING(A)	41.19
J89-9901	SPOOL BALLBEARING(A)RING	0.50
J90-0201	CLICK GEAR	6.13
J90-0301	CLICK GEAR PLATE	4.42
J90-0501	DRAG KNOB	49.92
J90-2002	HANDLE CAP	25.87
J90-2801	DRIVE BEARING(A) COVER PIN	2.38
J90-3401	BAIL ASSY	31.32
J90-3801	BODY	55.32
J90-3901	SET PLATE	0.50
J90-4001	MAIN SHAFT	31.01
J90-4701	DRIVE BEARING (A) COVER	0.50
J90-4804	ENGINEPLATE	46.63
J90-4901	REAR CAP PACKING	1.02
J90-5001	REAR CAP	13.27
J90-8801	BAIL ASSY	40.81
J90-9701	ZERO ADJUSTE KNOB	11.30
J90-9801	GEAR SHAFT	20.08
J90-9802	GEAR SHAFT	20.08
J90-9901	DRAG COLLAR	36.76
J91-0001	L/S PLATE	20.50
J91-0101	R/S PLATE	20.69
J91-4001	SPOOL HOLDER	13.62
J91-5301	KICK LEVER PLATE SPRING	2.38
J91-5901	HANDLE ASSY	32.27
J91-6001	ARM LEVER SHAFT PLATE	1.36
J91-6101	ARM LEVER SHAFT COLLAR	1.70
J91-6201	ROLLER MAG COLLAR"O"RING	1.36
J91-6301	ROLLER COLLAR	5.45
J91-6401	ROTOR NUT WASHER	1.02
J91-6501	CLICK GEAR PIN	4.08
J91-9501	ROTOR BRAKE WASHER	1.02
J91-9604	BODY	98.22
J91-9701	BODY	96.82
J92-0101	OSCILLATING GEAR WASHER	1.02
J92-0201	OSCILLATING GEAR	8.85
J92-0301	IDLE GEAR	31.65
J92-0401	DRIVE BEARING(A)WASHER	1.02
J92-0501	DRIVE BEARING(A) COVER	39.43
J92-0601	DRIVE BEARING(A) COVER"O"RING	3.40
J92-0701	MAIN SHAFT	39.48
J92-1101	REAR CAP PACKING	6.13
J92-1201	REAR CAP	40.50
J92-1301	PINION BEARING(B) COLLAR	3.40

J92-1401	PINION BEARING(B) SP WASHER	1.36
J92-2001	STOPPER SPRING	0.50
J92-2101	PINION BEARING(A) COLLAR	2.38
J92-2203	ENGINEPLATE	70.22
J92-2401	SPOOL PLATE	6.47
J92-2501	SPOOL PLATE PACKING(B)	3.40
J92-2601	SPOOL ASSY	144.79
J92-3201	SPOOL BALLBEARING(B)	11.23
J92-3301	DRAG DISC WASHER	1.36
J92-3401	SPOOL BALLBEARING(A) COLLAR	12.25
J92-3501	HANDLE	101.14
J92-3801	HANDLE CAP	22.12
J92-3802	HANDLE CAP	23.15
J92-4201	HANDLE ASSY	60.92
J92-5001	BODY ASSY	30.04
J92-5101	HANDLE ASSY	51.06
J92-5201	SPOOL ASSY	43.09
J92-5301	SPOOL ASSY	49.92
J92-5401	HANDLE ASSY	53.34
J92-5501	SPOOL ASSY	51.06
J92-6701	HANDLE ASSY	37.20
J92-9301	ROTOR	51.54
J92-9401	ROTOR BRAKE SHAFT	5.11
J92-9501	ROTOR BRAKE SPRING	0.68
J92-9601	ARM LEVER COVER	8.51
J92-9701	BAIL	62.91
J93-0101	ROTOR NUT WASHER	1.02
J93-0201	ROTOR NUT COLLAR	6.13
J93-0301	ROTOR NUT PACKING	4.08
J93-0401	ROTOR COVER	4.42
J93-2301	ZERO ADJUSTE KNOB	0.50
J93-2401	FRAME	0.50
J93-2501	CLUTCH LEVER PLATE (R)	0.50
J93-2601	CLUTCH LEVER PLATE (L)	0.50
J93-2901	KICK LEVER PLATE (B)	0.50
J93-3001	KICK LEVER PLATE (A)	0.50
J93-3101	CLUTCH LEVER	0.50
J93-3201	KICK LEVER	0.50
J93-3301	GEAR SHAFT	0.50
J93-3302	GEAR SHAFT	0.50
J93-3401	GEAR SHAFT COLLAR	0.50
J93-3501	WORM GEAR	0.50
J93-3601	KICK LEVER SPRING	0.50
J93-4101	WORM SHAFT	0.50
J93-4201	WORM SHAFT GEAR	0.50
J93-4301	WORM SHIELD	0.50
J93-4401	RATCHET	0.50

J93-4701	DRAG WASHER	0.50
J93-4801	DRAG DISC WASHER (A)	0.50
J93-4901	DRAG LIP WASHER	0.50
J93-5001	DRAG DISC WASHER (C)	0.50
J93-5101	DRAG NUT	0.50
J93-5102	DRAG NUT	0.50
J93-5501	FRONT COVER	0.50
J93-5601	OSCILLATING POST	0.50
J93-5801	BRAKE DIAL	0.50
J93-5802	BRAKE DIAL	0.50
J93-5901	BRAKE DIAL LEAF SPRING	0.50
J93-7301	INFINITE COVER	39.82
J93-7401	SPOOL WASHER	1.02
J94-5801	MAIN SHAFT	24.37
J94-6501	CLUTCH CAM BEARING COLLAR	0.50
J94-6701	STOPPER PIN	0.50
J94-6901	BRAKE DIAL RETAINER(B)	0.50
J95-2801	BAIL ASSY	28.80
J95-3001	PINION BALL BEARING COLLAR	0.50
J95-3201	CLICK LEAF SPRING	1.36
J95-8501	HANDLE ASSY	57.59
J96-2001	GEAR SHAFT	0.50
J96-2002	GEAR SHAFT	0.50
J96-5301	SPOOL ASSY	122.43
J96-6401	SPOOL ASSY	122.43
J97-3609	RS PLATE	0.50
J97-3610	RS PLATE	0.50
J97-3611	RS PLATE	0.50
J97-3701	CLUTCH CAM PLATE	0.50
J97-3801	LEVEL WIND ASSY	0.50
J97-4301	DRAG DISC WASHER (B)	0.50
J97-4501	MAGNET HOLDER	0.50
J97-4601	SPOOL	0.50
J97-4801	HANDLE ASSY	0.50
J97-4901	HANDLE ASSY	0.50
J97-5001	STAR DRAG	0.50
J97-5101	LEFT SIDE PLATE	0.50
J97-7201	SPOOL ASSY (2-12)	42.53
J97-7401	SPOOL ASSY (2-12)	42.53
J97-7701	CLUTCH SPRING	0.50
J97-7901	SPOOL ASSY	142.42
J98-1401	SPOOL ASSY (2-12)	51.17
J98-2201	SPOOL ASSY (2-12)	48.73
J98-3101	HANDLE ASSY	59.14
J98-3501	SPOOL ASSY (2-12)	53.16
J98-3801	MAIN SHAFT	0.50
J98-8301	HANDLE KNOB	0.50

J98-9506	LS PLATE	0.50
J98-9507	LS PLATE	0.50
J98-9508	LS PLATE	0.50
J98-9801	FRAME	0.50
J98-9901	CLUTCH CAM PLATE	0.50
J99-0201	KICK LEVER PLATE (A)	0.50
J99-0301	KICK LEVER	0.50
J99-0401	KICK LEVER SPRING	0.50
J99-0601	WORM SHIELD	0.50
J99-0901	RIGHT SIDE PLATE	0.50
J99-2201	HANDLE KNOB CAP	0.50
K30-0801	Washer	5.67
K30-2201	Drag Lever Retainer	1.01
K30-2501	Drag Pin	2.05
K30-9201	Rod Clamp	28.48
KH5990042	DRAG KNOB	9.32
KH6272041	DRAG KNOB	8.88
KH6424021	DRAG KNOB	14.90
KJ0336080	SPOOL ASSY	42.19
KJ0340080	SPOOL ASSY	42.09
KJ0344081	SPOOL ASSY	43.73
KJ5254081	SPOOL ASSY	42.19
L00-1801	A/R Pawl Screw	0.50
M00-9501	REAR CAP SCREW	15.69
M01-8801	HANDLE	88.39
M02-1401	CLICK HOLDER	0.01
M02-1501	CLICK HOLDER	2.08
M03-0301	STOPPER	3.06
M03-0401	STOPPER	3.06
M03-0501	ARM LEVER	40.20
M03-3201	hANDLE	88.17
M03-7401	SPOOL BB WASHER (A)	0.50
M04-0001	GEAR SHAFT PLATE	0.50
M04-0101	REAR CAP COVER	0.50
M04-2301	CLICK GEAR PLATE SCREW	23.83
M05-0901	HOLDER SCREW WASHER	0.68
M05-8301	BODY ASSY	0.01
M05-8302	BODY ASSY	0.01
M05-8303	BODY ASSY	0.01
M05-8501	BODY COVER ASSY	0.50
M05-8701	HANDLE ASSY	0.50
M05-8901	SPOOL ASSY	0.50
M05-9101	HANDLE ASSY	0.50
M05-9301	SPOOL ASSY	0.50
M05-9501	BODY ASSY	0.01
M05-9502	BODY ASSY	0.01
M05-9701	BODY COVER ASSY	0.50

M05-9801	HANDLE ASSY	0.50
M06-0001	SPOOL ASSY	0.50
M06-0201	HANDLE ASSY	0.50
M06-0401	SPOOL ASSY	0.50
M06-7801	OSCILLATING POST COLLAR SCREW	0.68
M10-5701	CLUTCH PLATE	0.50
M10-6001	CLUTCH PLATE	0.50
M12-3101	PINION GEAR	0.50
M12-3201	DRIVE GEAR	0.50
M12-3301	PINION GEAR	0.50
M12-3401	DRIVE GEAR	0.50
M12-3501	PINION GEAR	0.50
M12-3601	DRIVE GEAR	0.50
M12-3901	PINION GEAR	0.50
M12-4001	DRIVE GEAR	0.50
M12-4101	PINION GEAR	0.50
M12-4201	DRIVE GEAR	0.50
M12-4501	PINION GEAR	0.50
M12-4601	DRIVE GEAR	0.50
Q02-0101	Handle Screw	4.95
Q02-0102	Handle Screw	4.69
Q02-0104	Handle Screw	2.17
Q02-0201	Handle Screw	4.95
Q02-0202	Handle Screw	4.66
Q02-0203	Handle Screw	2.17
Q02-0501	Handle Screw	4.35
Q02-0503	Handle Screw	2.05
Q03-6704	Anti Reverse Cam Lever	1.54
Q03-7001	Worm Shaft Gera	1.04
Q03-7101	Pinion Gear	3.96
Q03-7201	Drive Gear	2.64
Q03-7502	Rear Cover	3.34
Q03-7604	Rotor	4.00
Q03-7701	Bail Trip Lever	1.51
Q03-8001	Bail Spring Holder	0.50
Q03-8101	Bail Spring Shaft	0.57
Q03-8204	Bail Arm	1.54
Q03-8802	Line Guard	5.36
Q04-4002	Cover A	2.55
Q04-4102	Cover B	2.55
Q04-7501	Body	3.49
Q04-7601	Side Cover	2.64
Q04-7701	Bail	38.87
Q04-7901	Handle	13.28
Q04-8101	Spool	16.81
Q04-8202	Extra Spool	18.90
Q04-8301	Drag Knob	5.10

Q04-8801	Bail Trip Lever Spring	0.50
Q04-9001	Spool	15.76
Q04-9102	Extra Spool	20.16
Q05-5301	Handle	4.33
Q05-5401	Spool	3.83
Q05-5701	Drag Knob	3.81
Q05-6201	Drag Knob	4.63
Q05-6501	Spool	6.48
Q05-6801	Handle	8.06
Q05-6901	Handle	8.36
Q05-8801	Handle Assembly	8.61
Q05-8901	Bail Spring	0.50
Q05-9001	Anti-Reverse Cam Spring	0.50
Q05-9101	Collar E	0.50
Q05-9201	Washer (C)	3.15
Q06-5301	Drag Washer	1.23
Q06-5701	Drag Knob	2.30
Q06-8713	Body	4.00
Q06-8801	Main Shaft	4.32
Q06-9413	Side Cover	1.50
Q06-9601	Rear Cover	2.58
Q07-1512	Body	3.16
Q07-1912	Side Cover	1.66
Q07-2001	Rear Cover	3.43
Q07-2501	Bail Assembly	3.92
Q07-3601	Anti-Reverse Cam Spring	0.50
Q07-4001	Bail Assembly	3.92
Q07-4412	Body	4.14
Q07-4601	Main Shaft	4.88
Q07-4801	Oscillating Gear	1.45
Q07-5112	Side Cover	1.50
Q07-5201	Rear Cover	2.58
Q07-7601	Handle Assembly	6.79
Q07-7701	Spool Assy	5.04
Q07-7901	Spool Assy	5.64
Q07-8101	Body	4.31
Q07-8201	Side Cover	2.42
Q07-8301	Handle Assembly	8.96
Q07-8401	Spool Assembly	6.36
Q07-8601	Spool Assembly	6.72
Q07-9301	Body	3.55
Q07-9401	Side Cover	2.62
Q07-9601	Spool Assembly	10.27
Q07-9901	Handle Assembly	7.38
Q08-0001	Spool Assembly	6.17
Q08-4801	Pinion Gear	2.05
Q08-4901	Drive Gear	1.68

Q08-5001	Pinion Gear	3.18
Q08-5102	Pinion Gear	2.62
Q08-5201	Handle Assembly	6.36
Q08-5601	Body	4.67
Q08-5701	Side Cover	2.23
Q08-5801	Handle Assembly	10.97
Q08-5901	Spool Assembly	6.31
Q09-6801	Rotor Nut	0.50
Q09-6901	Main Shaft	5.45
Q09-7601	Clutch Cam Retainer	1.73
Q09-9001	Clutch Cam Retainer	0.85
Q09-9201	Spool Assembly	4.82
Q09-9601	Spool Assembly	3.81
Q10-1901	Handle Assembly	3.65
Q10-2001	Spool Assembly	4.67
Q10-2201	Drag Knob	1.80
Q10-4401	Handle Assembly	4.10
Q10-4501	Spool Assembly	6.21
Q10-9201	Handle Assembly	4.10
Q10-9401	Handle Assembly	4.10
Q11-2901	PINION GEAR	6.13
Q11-8001	A/R Lever	0.50
Q11-8101	A/R Cam	0.50
Q11-8401	Osc Gear	0.60
Q11-9101	Stabilizer Bar (A)	1.54
Q11-9102	Stabilizer Bar (A)	1.54
Q11-9103	Stabilizer Bar (A)	1.54
Q11-9104	Oscillating Support Post	2.68
Q12-0101	Rear Cover (A)	0.95
Q12-0301	Rear Cover (B)	2.17
Q12-0302	Rear Cover	2.46
Q12-0503	Rotor	4.78
Q12-0510	ROTOR	6.70
Q12-0513	Rotor	13.92
Q12-0515	Rotor	8.96
Q12-0516	ROTOR	6.13
Q12-0518	ROTOR	8.17
Q12-0519	ROTOR	6.64
Q12-0701	Bail Trip Lever	2.17
Q12-1201	Bail Spring Shaft	0.95
Q12-1501	Bail Spring Holder	0.50
Q12-1603	Bail Arm	1.61
Q12-1604	ARMLEVER	2.04
Q12-1606	ARM LEVER	0.57
Q12-1607	Bail Arm Lever	2.02
Q12-1609	Bail Arm Lever	2.33
Q12-1613	Bail Arm	2.36

Q12-1701	Collar (B)	0.50
Q12-1801	Cover (A)	1.54
Q12-1802	ARMLEVER SPRING COVER	1.50
Q12-1901	Bail Assembly	22.61
Q12-2401	Rotor Nut	1.86
Q12-2402	Rotor Nut	0.50
Q12-6101	Screw (A)	0.50
Q12-6201	Screw (B)	0.50
Q12-6301	Stabilizer Bar (B)	1.54
Q12-6302	Stabilizer Bar (B)	1.54
Q12-6303	Stabilizer Bar (B)	1.86
Q12-8201	Osc Gear	9.58
Q12-9001	Rear Cover (A)	1.26
Q12-9101	Rear Cover (B)	19.97
Q12-9102	Rear Cover	2.46
Q12-9203	Rotor	5.43
Q12-9214	ROTOR	6.13
Q12-9301	Bail Trip Lever	2.17
Q12-9501	Bail Spring Shaft	0.95
Q12-9601	Cover (A)	1.54
Q12-9602	Arm Lever Spring Cover	1.86
Q13-1709	Rotor	3.34
Q13-2201	Drive Gear	2.34
Q13-2401	Handle Screw	3.31
Q13-2402	Handle Screw	2.46
Q13-2406	HANDLE SCREW	0.50
Q13-3401	A/R Cam	0.50
Q13-3501	Osc Gear	0.91
Q13-4301	Rear Cover (A)	1.26
Q13-4401	Rear Cover (B)	5.29
Q13-4503	Rotor	6.11
Q13-4601	Bail Trip Lever	2.17
Q13-4801	Bail Spring Shaft	0.95
Q13-4901	Cover (A)	2.17
Q13-5201	Rotor Nut	1.54
Q13-6101	Handle Screw	2.39
Q13-9001	Osc Gear	0.91
Q13-9401	Sealed Plate	0.79
Q13-9503	Rotor	5.00
Q13-9510	Rotor	4.57
Q13-9515	Rotor	7.69
Q13-9517	ROTOR	6.13
Q13-9520	ROTOR	6.64
Q13-9601	Bail Trip Lever	2.17
Q13-9801	Bail Spring Shaft	0.63
Q13-9901	Bail Assembly	21.98
Q14-6501	Cover (A)	1.51

Q14-6502	Arm Lever Spring Cover	3.37
Q15-2601	Roller Clutch	9.20
Q16-1102	Body	16.52
Q16-1201	Osc Gear	2.02
Q16-1401	Main Shaft	5.01
Q16-1701	Collar (A)	0.50
Q16-1801	Collar (B)	0.50
Q16-1901	Collar (C)	0.50
Q16-2001	Spring	0.63
Q16-2101	A/R Pawl	0.63
Q16-2201	Drive Gear	3.46
Q16-2302	Side Cover	2.17
Q16-2401	Rear Cover	3.02
Q16-2402	Rear Cover	2.87
Q16-2501	Handle Assembly	8.71
Q16-2801	Spool Assembly	8.26
Q16-4801	Body	12.61
Q16-4901	Side Cover	5.86
Q16-5001	Handle Assembly	28.06
Q16-5101	Spool Assembly	8.18
Q16-5301	Drag Knob	6.36
Q16-5401	Body	12.83
Q16-5501	Pinion Gear	2.73
Q16-5601	Handle Assembly	28.50
Q16-5701	Spool Assembly	9.20
Q16-5901	Drag Knob	6.36
Q16-6001	Body	18.49
Q16-6101	Side Cover	4.35
Q16-6201	Spool Assembly	10.09
Q16-6501	Body	14.35
Q16-6601	Side Cover	6.54
Q16-6701	Handle Assembly	28.93
Q16-6801	Spool Assembly	10.95
Q16-7001	Drag Knob	8.00
Q16-7101	Pinion Gear	2.73
Q16-7201	Drive Gear	2.79
Q16-7401	Drive Gear	2.79
Q16-7501	Bail Assembly	6.48
Q16-7801	Bail Assembly	6.48
Q16-7901	Bail Assembly	6.68
Q16-8001	Bail Assembly	5.33
Q16-8401	Main Shaft	4.82
Q16-8501	Main Shaft	5.13
Q16-8601	Main Shaft	5.13
Q16-8701	Main Shaft	5.45
Q16-8801	Handle Assembly	26.10
Q17-0801	A/R Pawl Collar	1.67

Q17-2801	Spool Assembly	7.83
Q17-3301	Body	4.57
Q17-3401	Osc Gear	0.95
Q17-3501	Main Shaft	5.32
Q17-3801	Side Cover	1.97
Q17-3901	Rear Cover	3.02
Q17-3902	Rear Cover	2.87
Q17-4001	Handle Assembly	8.49
Q17-4701	Body	4.78
Q17-4801	Osc Gear	0.95
Q17-4901	Main Shaft	6.02
Q17-5201	Collar (A)	0.50
Q17-5301	Drive Gear	3.46
Q17-5401	Bearing	0.50
Q17-5501	Side Cover	11.32
Q17-5601	Rear Cover	15.69
Q17-5602	Rear Cover	2.87
Q17-5701	Handle Assembly	9.57
Q17-5901	Spool Assembly	14.15
Q17-6301	Spool Assembly	10.00
Q17-6601	Screw (A)	0.63
Q17-7001	Rotor Nut	4.35
Q18-5201	BAIL ASSY	9.94
Q18-5901	BAIL ASSY	10.08
Q18-7901	Body	19.78
Q18-8001	Osc Gear	2.02
Q18-8201	Screw (A)	0.66
Q18-8301	Main Shaft	10.05
Q18-8501	Collar (A)	0.50
Q18-8601	Pinion Gear	3.71
Q18-8901	Side Cover	3.92
Q18-9001	Rear Cover	3.02
Q18-9003	Rear Cover	4.35
Q18-9101	Handle Assembly	8.71
Q18-9301	Handle Screw	3.69
Q18-9501	Spool Assembly	14.15
Q18-9801	Spool Assembly	13.92
Q19-2701	Spacing Sleeve	3.34
Q19-3001	Drag Knob	7.69
Q19-5101	Body	4.98
Q19-5401	Osc Gear	1.32
Q19-5501	Screw	0.50
Q19-5601	Pinion Bearing Plt	2.24
Q19-5701	Screw	0.50
Q19-5901	Body Cover	4.16
Q19-6101	Spacing Sleeve	5.10
Q19-6201	Sealed Cap	0.95

Q19-6301	Handle Assembly	18.06
Q19-6401	Spool Assembly	11.09
Q20-2201	Body	6.03
Q20-2501	Osc Gear	1.32
Q20-2601	Body Cover	4.16
Q20-2801	Rotor	4.57
Q20-2804	Rotor	3.65
Q20-2901	Handle Assembly	17.65
Q20-3001	Spool Assembly	9.14
Q20-3301	Rotor	4.98
Q20-3304	Rotor	4.98
Q20-3401	Collar (A)	0.50
Q20-5301	Body	7.05
Q20-5601	Osc Gear	1.32
Q20-5701	Main Shaft	6.39
Q20-5901	Pinion Bearing Plt	2.55
Q20-6101	Body Cover	4.98
Q20-6301	Spacing Sleeve	10.21
Q20-6401	Sealed Cap	0.95
Q20-6501	Handle Assembly	20.21
Q20-6601	Spool Assembly	12.87
Q20-8701	PINION GEAR	5.13
Q21-0901	DRIVE GEAR BALL BEARING (A)	0.50
Q21-5301	Body	7.83
Q21-5701	A/R Cam	0.63
Q21-5801	Osc Gear	2.24
Q21-5901	O Ring	0.63
Q21-6101	Bearing Retainer (A)	1.92
Q21-6301	Collar	1.67
Q21-6401	Side Cover	4.78
Q21-6601	Spacing Sleeve	4.66
Q21-6701	Sealed Cap	0.95
Q21-6801	Handle Assembly	23.25
Q21-6901	Spool Assembly	18.49
Q21-9501	Screw (F)	0.50
Q21-9601	Spool Assembly	11.09
Q22-8401	Main Shaft	5.01
Q22-8501	Pinion Gear	5.19
Q22-8502	Pinion Gear	5.19
Q23-0701	Pinion Gear	6.23
Q24-3501	Pinion Gear	5.19
Q24-5001	Pinion Gear	4.78
Q24-5701	Bail Assembly	10.21
Q24-6101	Line Roller	0.50
Q25-6801	Drag Knob	6.14
Q26-6601	Sealed Cap	1.01
Q26-6701	A/R Lever	0.66

Q27-0701	Main Shaft	10.05
Q27-3601	Cover	2.99
Q27-3602	Arm Lever Cover	2.87
Q27-3701	COVER (A)	1.80
Q27-3702	Arm Lever Cover	2.87
Q27-6627	Rotor	3.92
Q28-1001	Bail Assy	29.36
Q28-1601	Bail Assy	28.27
Q28-2401	Bail Assy	28.70
Q28-5701	Body	7.83
Q28-5901	Handle Assy	29.58
Q28-6001	Spool Assembly	11.75
Q28-6201	Drag Knob	7.34
Q28-6401	Handle Assy	34.58
Q28-6501	Spool Assy	8.59
Q28-6701	Drag Knob	5.67
Q28-7001	Handle Assy	27.61
Q28-7101	Spool Assembly	12.61
Q29-0801	Pinion Gear	3.92
Q30-3201	Handle Assembly	18.06
Q30-3301	Spool Assembly	8.26
Q30-3901	Handle Assembly	18.06
Q30-4001	Spool Assembly	11.09
Q30-4301	Spool Assembly	12.18
Q30-4601	Handle Assembly	20.21
Q30-4701	Spool Assembly	5.23
Q30-5001	Handle Assembly	23.25
Q30-5101	Spool Assembly	18.49
Q30-5801	Drag Knob	7.69
Q30-8301	Roller Clutch	6.33
Q31-0001	Body	4.78
Q31-0101	Body Cover	4.16
Q31-0201	Body	4.98
Q31-0301	Body Cover	4.16
Q31-0401	Body	7.05
Q31-0501	Body Cover	4.98
Q31-0601	Body	7.83
Q31-0701	Side Cover	4.78
Q34-1501	Main Shaft	6.36
Q34-1701	Pinion Gear	5.43
Q34-1801	Drive Gear	8.26
Q34-1901	Drive Gear	7.18
Q34-2601	Body Cover Screw	0.66
Q34-2701	Body Cover Screw (A)	0.50
Q34-2801	Rear Cover	2.68
Q34-2802	REAR COVER	2.72
Q34-2901	Screw	0.50

Q34-3002	Rotor	13.28
Q34-3003	Rotor	7.69
Q34-3004	ROTOR	8.17
Q34-3006	ROTOR	7.49
Q34-3007	ROTOR	6.46
Q34-3101	Kick Lever	2.17
Q34-3301	Arm Lever Shaft	1.32
Q34-3401	Bail Arm Screw	0.66
Q34-3501	Arm Lever Spring Cover	2.33
Q34-3502	ARMLEVER SPRING COVER	2.38
Q34-3601	Bail Assembly	13.16
Q34-4001	Click Leaf Washer	1.67
Q34-4801	HANDLE KNOB	1.70
Q34-5002	HANDLE KNOB CAP	1.70
Q34-5101	Handle Cap	3.21
Q34-6001	Washer	0.66
Q34-6101	Drag Retainer	0.50
Q34-6201	Drag Knob	4.16
Q34-8401	BAIL TRIP LEVER	1.07
Q34-8502	Spool Washer (D)	0.66
Q34-8801	Bail Trip Lever	1.01
Q35-0901	Oscillating Gear	0.60
Q35-1001	Main Shaft	6.36
Q35-1201	Pinion Gear	3.92
Q35-1301	Drive Gear	7.18
Q35-1401	Drive Gear	7.18
Q35-1701	Rear Cover	3.34
Q35-1802	Rotor	5.23
Q35-1803	Rotor	7.18
Q35-1805	ROTOR	8.17
Q35-1806	ROTOR	6.64
Q35-1901	Bail Kick Lever	3.31
Q35-2101	Bail Spring Cover	2.99
Q35-2201	Bail Assembly	27.41
Q35-2901	Drag Knob	4.13
Q36-0301	Pinion Gear	4.14
Q36-0401	Drive Gear	7.18
Q36-0501	Drive Gear	7.18
Q36-1701	HANDLE KNOB	2.72
Q36-1902	HANDLE KNOB CAP	2.04
Q36-7701	DRIVE GEAR	2.98
Q37-5201	Oscillating Gear	4.16
Q37-5301	Main Shaft	5.73
Q37-5701	Pinion Gear	5.23
Q37-5801	Drive Gear	8.06
Q37-5901	Drive Gear	7.18
Q37-6201	Rear Cover	2.68

Q37-6202	REAR COVER	2.72
Q37-6801	Drag Knob	4.16
Q38-2401	Body	10.62
Q38-2601	Body Cover	5.00
Q38-2701	Spool Washer (A)	0.50
Q38-2801	Spool Assembly	32.84
Q38-3001	Handle Assembly	18.45
Q38-3201	Spool Assembly	40.67
Q38-3401	Body	33.50
Q38-3501	Spool Assembly	35.44
Q38-3701	Handle Assembly	53.71
Q38-5201	Body	15.48
Q38-5401	Side Cover	4.78
Q38-5501	Spool Assembly	18.16
Q38-5801	Handle Assembly	18.78
Q38-6001	Spool Assembly	18.16
Q38-6601	Body	15.48
Q38-6701	Spool Assembly	18.16
Q38-6901	Handle Assembly	18.78
Q38-7601	Body	14.15
Q38-7701	Side Cover	6.31
Q38-7801	Spool Assembly	13.08
Q38-8001	Handle Assembly	14.58
Q38-8201	Spool Assembly	13.08
Q38-8901	Body	19.72
Q38-9001	Spool Assembly	18.02
Q38-9801	Handle Assembly	13.86
Q39-2801	Body	22.32
Q39-2901	Side Cover	5.66
Q39-3001	Spool Assembly	19.95
Q39-3601	Handle Assembly	14.51
Q39-3701	Body	16.56
Q39-3901	Side Cover	5.43
Q39-4001	Spool Assembly	19.62
Q39-4701	Handle Assembly	15.15
Q39-5201	Body	33.50
Q39-5401	Body Cover	5.66
Q39-5501	Spool Assembly	35.44
Q39-6701	Handle Assembly	27.71
Q40-1201	Body	15.93
Q40-1301	Side Cover	5.00
Q40-1401	Spool Assembly	13.08
Q40-1701	Handle Assembly	12.12
Q40-1901	Body	32.41
Q40-2101	Body Cover	4.57
Q40-2201	Spool Assembly	25.67
Q40-2501	Handle Assembly	18.45

Q40-2701	Body	14.84
Q40-2901	Side Cover	5.00
Q40-3001	Spool Assy / Lglt1000d	32.84
Q40-3301	Handle Assy / Lglt1000d	15.01
Q41-9201	PINION COLLAR	0.01
Q41-9301	PINION GEAR	4.74
Q41-9901	REAR CAP	0.01
Q42-3501	BODY	10.41
Q42-3701	MAIN SHAFT	8.51
Q42-3801	BODY COVER	7.49
Q42-3901	BAIL ASSY	12.93
Q42-4201	SPOOL ASSY (2-6)	21.18
Q42-4401	DRAG KNOB	13.13
Q42-4501	HANDLE ASSY	12.10
Q42-4601	SPOOL ASSY (2-6)	21.18
Q42-6901	BODY	10.41
Q42-7001	SPOOL ASSY (2-6)	22.15
Q42-7201	HANDLE ASSY	12.32
Q42-7301	SPOOL ASSY (2-6)	22.15
Q42-7501	BODY	10.19
Q42-7701	MAIN SHAFT	8.51
Q42-7801	BODY COVER	7.15
Q42-7901	SPOOL ASSY	16.10
Q42-8101	DRAG KNOB	15.32
Q42-8201	SPOOL ASSY (2-5)	16.64
Q42-8501	HANDLE ASSY	12.21
Q45-7201	PINION GEAR	4.74
Q45-7401	PINION GEAR	4.74
Q45-7501	BAIL ASSEMBLY	7.40
Q45-7601	CLICK HOLDER	1.70
Q45-7701	CLICK LEAF SPRING	0.01
Q46-1401	MAIN SHAFT	0.01
Q46-1501	MAIN SHAFT	8.51
Q46-3501	PINION GEAR	5.13
Q46-3502	PINION GEAR	0.50
Q46-3801	BAIL ASSEMBLY	7.40
Q47-7601	BODY	7.22
Q47-7701	BODY COVER	4.55
Q47-7801	HANDLE ASSEMBLY	11.95
Q47-7901	SPOOL ASSEMBLY(2-6)	22.41
Q47-8101	BODY	7.59
Q47-8201	BODY COVER	4.74
Q47-8301	SPOOL ASSEMBLY (2 - 6)	17.47
Q47-8601	HANDLE ASSEMBLY	12.34
Q47-9001	SPOOL ASSEMBLY (2 - 6)	18.04
Q47-9501	BODY	7.22
Q47-9601	HANDLE ASSEMBLY	12.53

Q47-9701	SPOOL ASSEMBLY (2-6)	26.57
Q48-0201	BODY	12.93
Q48-0301	BODY COVER	4.74
Q48-0401	HANDLE ASSEMBLY	13.28
Q48-0501	SPOOL ASSEMBLY (2 - 6)	23.35
Q48-2401	SPOOL ASSEMBLY	26.38
Q48-2601	SPOOL ASSEMBLY (2 - 6)	26.57
Q48-2801	SPOOL ASSEMBLY (2 - 6)	23.35
Q48-4401	PINION GEAR	4.74
Q50-1101	BODY	0.01
Q50-1301	OSCILLATE GEAR	0.50
Q50-1401	DRAG KNOB	0.50
Q50-1501	STOPPER LEVER	0.50
Q50-1601	CLICK GEAR RETAINER	0.50
Q50-1701	BRAKE METAL	0.50
Q50-1801	CLUTCH CAM (A)	0.50
Q50-1902	CLUTCH LEVER (R)	0.50
Q50-2101	CLUTCH CAM SPRING (A)	0.50
Q50-2201	CLUTCH P L A T E (A)	0.50
Q50-2301	CLUTCH P L A T E SPRING	0.50
Q50-2401	CLUTCH PLATE COLLAR	0.50
Q50-2501	OSILLATING SLIDER	0.50
Q50-2601	MAIN SHAFT	0.50
Q50-2602	MAIN SHAFT	0.50
Q50-2603	MAIN SHAFT	0.50
Q50-2701	OSILLATING SLIDER RETAINER	0.50
Q50-2901	DRIVE GEAR	0.01
Q50-3002	BODY COVER	0.01
Q50-3101	CLUTCH CAM SPRING (B)	0.50
Q50-3201	CLUTCH CAM (B)	0.50
Q50-3301	CLUTCH PLATE (B)	0.50
Q50-3402	CLUTCH LEVER (L)	0.50
Q50-3501	CLUTCH LEVER (R) SCREW (B)	0.50
Q50-3701	SPOOL	0.01
Q50-4001	HANDLE	0.01
Q51-8701	BAIL	11.58
Q51-8801	BODY	6.81
Q51-8802	BODY	0.01
Q51-8901	MAIN SHAFT	5.79
Q51-9201	BODY COVER	3.06
Q51-9202	BODY COVER	0.50
Q51-9301	ONEWAY CLUTCH PLATE	1.70
Q51-9401	REAR CAP	3.06
Q51-9501	ROTOR	6.13
Q51-9502	ROTOR	0.50
Q51-9601	BAIL	0.01
Q52-0101	DRAG KNOB	6.81

Q52-0401	HANDLE ASSY	5.73
Q52-0801	OSCILLATE GEAR COLLAR	1.36
Q52-1301	CLICK SPRING	0.50
Q52-1701	BODY	5.79
Q52-1702	BODY	0.01
Q52-1801	MAIN SHAFT	7.83
Q52-2201	BODY COVER	3.40
Q52-2202	BODY COVER	0.50
Q52-3601	REAR CAP	3.06
Q52-3701	ROTOR	7.49
Q52-3702	ROTOR	0.50
Q52-3801	KICK LEVER	0.68
Q52-3901	ARM LEVER SPRING COVER	3.06
Q52-4001	BAIL	0.01
Q52-4401	DRAG KNOB	6.81
Q52-4601	HANDLE ASSY	5.84
Q52-6401	BODY	8.17
Q52-6402	BODY	0.01
Q52-6501	MAIN SHAFT	8.51
Q52-6801	BODY COVER	3.06
Q52-6802	BODY COVER	0.50
Q52-6901	REAR CAP	3.40
Q52-7001	ROTOR	5.45
Q52-7002	ROTOR	0.50
Q52-7101	BAIL	11.23
Q52-7501	DRAG KNOB	7.15
Q52-7701	HANDLE	3.54
Q53-1301	BODY	0.01
Q53-1401	OSCILLATE GEAR	0.50
Q53-1601	SPOOL	0.01
Q53-1801	OSILLATING SLIDER	0.50
Q53-2001	SPOOL	0.10
Q53-2201	SPOOL	0.01
Q53-8301	BAIL ASSY	3.20
Q54-5301	MAIN SHAFT	5.79
Q55-9701	HANDLE ASSY	5.84
Q58-2701	PINION GEAR	8.85
Q58-2801	SPOOL ASSY	11.02
Q58-3001	SPOOL ASSY	11.02
Q58-3801	OSCILLATING POST	7.15
Q58-3802	OSCILLATING POST	8.51
Q58-3804	OSCILLATING POST	10.89
Q58-5701	PINION GEAR	11.91
Q58-5801	SPOOL ASSY	11.13
Q58-6001	SPOOL ASSY	11.24
Q58-6701	PINION GEAR	8.85
Q58-6901	SPOOL	5.84

Q58-7101	SPOOL	6.27
Q59-2301	SPOOL ASSY	0.50
Q59-2501	SPOOL ASSY	0.50
Q59-3301	HANDLE ASSY	0.50
Q59-3401	HANDLE ASSY	0.50
Q59-3701	SPOOL ASSY	0.50
Q59-3901	DRAG KNOB	0.50
Q59-4001	HANDLE ASSY	0.50
Q59-4401	SPOOL ASSY	0.50
Q59-4801	SPOOL ASSY	0.50
Q59-5001	DRAG KNOB	0.50
Q59-5101	HANDLE ASSY	0.50
Q59-5401	SPOOL ASSY	0.50
Q59-5801	DRAG KNOB	0.50
Q62-1901	DRAG DISK WASHER	2.38
VB02002-52	One-Way Bearing	3.44
VB070110030-2	Ball bearing	1.93
VB070140035-2	Ball bearing	1.93
VB080120035-2	Ball bearing	1.93
VB40070025-2	Ball bearing	1.93
VC315VDC500-1	Line Roller	1.29
VC318TF30-1F	Hexnut	0.64
VC702VDC500-1B	Pinion	3.01
VC718VDC500-1S	Main Shaft(front)	1.29
VD400MDA500-ZHP	Spool	6.30
VD500MDA500-ZHP	Handle Assy	6.35
VD700MDA500-1C	Main Gear	1.07
VD705VDC500-1	Oscillating Gear	1.29
VD708VDC500-1	Oscillating Slider	1.29
VD800AF10-1	Anti-reverse Lever	0.50
VI100MDA500-1	Main Body(front)	5.16
VI109MDA500-1	body side cover	1.29
VI200MDA500-1	Body Cover	3.44
VI300VDC500-1	Rotor	4.73
VI301VDC500-1	Bail Arm	1.72
VI304VDC500-1	Bail Arm Lever Cover	1.29
VI402TT50-1	Plastic line clip	0.50
VI406AA30-1	Line clip clicker	0.50
VI513MDA500-41	Handle Screw cap	1.29
VI515MQA50-1	Handle Cap Washer	0.50
VI600MDA500-ZHP	Front drag Assy	2.15
VI703VDC500-11	Bearing Holder	0.86
VI800CE30-1	Anti-reverse Swtich	0.86
VP105HT500-1	Bearing Plate	0.86
VP109MDA500-1	Body ring plate	0.50
VP319HT500-11S	Rotor Retainer Plate	0.50
VP610FV500-11	Drag Washer	0.64

VP611FV500-2	Winged Drag Washer	0.50
VP612HT500-1	Stainless Washer	0.50
VP719FA30-21	Clicker Gear	0.50
VP722FA30-11	Retaining Washer	0.50
VP902MQA50-1	Washer plate	0.50
VPW5-1-7-0-5-1S	Screw	0.50
VPW7-9-0-5-1F	Screw	0.50
VPW8-1-10-1-0-3-1S	Screw	0.50
VS302VDC500-1	Spring	0.50
VS305VDC500-1	Bail Lever	0.50
VS313VDC500-ZHP	Bail Assy	3.44
VS405HT500-1	Spring	0.50
VS801AF10-11	Torsion Spring	0.50
VS820TF10-12	Spring	0.50
VTMJ3-5-3-8-2-41N	Screw	0.50
VTPJ4-2-5-2-41	Line clip screw	0.50
VTPJ4-3-2-2-41	Line clip screw	0.50
VTPZ6-3-2-6-41	Screw	0.50
VTYJ4-5-1-6-41	Screw	0.50
VTYN3-6-4-5-2-2-41	Screw	0.50
VTYZA3-5-6-2-41	Screw	0.50
VTYZA3-5-7-7-2-41	Screw	0.50
VTYZN3-5-7-7-2-41	Screw	0.50
VTYZN6-2-5-5-2-1-41	Screw	0.50
W28-0100	Ball Bearing	4.28
W30-1501	Ball Bearing	6.30
W30-3301	Drive Gear	3.03
W30-3401	Drive Gear	3.03
W30-4101	Side Cover Bushing	1.01
W30-5101	Osc Slider Screw	0.50
W30-5401	Osc Gear	1.42
W30-5501	Osc Gear	1.42
W30-5601	Osc Gear Collar	0.72
W30-6101	Line Roller Washer	0.50
W30-6201	Line Roller Washer	1.07
W30-6401	Handle Lock Screw Washer	0.72
W30-9401	Rear Cover Screw	0.50
W31-1701	Bail Trip Lever Spring	0.50
W31-1801	Bail Trip Lever Washer	0.50
W31-5101	Side Cover Screw A	0.50
W31-5102	Screw	0.50
W31-5201	Side Cover Screw B	0.50
W31-5301	Side Cover Screw C	0.50
W31-5401	A/R Lever	0.50
W31-5701	A/R Cam	0.72
W31-5801	A/R Cam Spring	0.50
W31-6001	Bushing	0.54

W31-6011	Ball Bearing	2.84
W31-6201	A/R Pawl	0.50
W31-6501	A/R Pawl Spring	5.13
W31-6601	Drive Gear	1.17
W31-6611	Drive Gear	1.09
W31-7001	Handle Washer	0.50
W31-7101	Handle Screw	0.88
W31-7102	Handle Screw A	0.54
W31-7201	Handle Screw Cap	0.72
W31-7901	Ret	0.50
W31-8101	Main Shaft Spring	0.50
W31-8301	Main Shaft	2.24
W31-8402	Main Shaft	1.86
W31-8501	Main Shaft Washer	0.50
W31-8601	Spool Metal	2.74
W31-8701	Spool Metal	3.09
W31-8702	Spool Metal	2.84
W31-8901	Drag Spring Washer	0.50
W31-8902	Drag Spring Washer	0.50
W31-8903	Drag Spring Washer	0.50
W31-9002	Eared Washer	0.50
W31-9101	Drag Washer	0.50
W31-9102	Drag Washer	0.50
W31-9201	Spool	1.87
W31-9501	Key Washer	0.50
W31-9701	Click Spring	0.54
W31-9801	Rotor	2.09
W31-9901	Rotor	2.21
W32-0001	Rotor	2.34
W32-0011	Rotor	2.79
W32-0101	Line Stopper	0.54
W32-0201	Line Stopper	0.54
W32-0202	Line Stopper	0.54
W32-0301	Rotor Nut	0.88
W32-0701	Handle Metal	0.72
W32-0901	Handle Screw	0.50
W32-2001	A/R Cam Spring	0.69
W32-2511	Ball Bearing	2.52
W32-2701	Drive Gear	0.92
W32-2801	A/R Pawl Spring	0.50
W32-3101	Cap	0.72
W32-3301	Pinion Gear	1.21
W32-3401	Spool	1.64
W32-3601	Rotor	1.99
W32-3701	Line Stopper	0.54
W32-3901	Drag Washer	0.50
W32-4001	Eared Washer	0.54

W32-4101	Key Washer	0.54
W32-4201	Drag Washer Ret	0.50
W32-4301	Drag Adj Plt	0.50
W32-4401	Front Cover	4.00
W32-4501	Drag Knob	0.69
W32-4701	Handle Metal	0.50
W32-4801	Handle Stand	0.57
W32-4901	Handle	3.34
W32-5001	Handle Washer	0.50
W32-5101	Handle Screw	0.88
W32-5602	Body	4.45
W32-6001	Click Gear	0.50
W32-6101	Drag Knob Spring	0.50
W32-6201	Washer	0.50
W32-6301	Drive Shaft	0.57
W32-6401	Screw	0.50
W32-6502	Drag Knob	0.95
W32-6602	O Ring	0.50
W32-7001	Casting Trigger Spring	0.50
W32-7102	Casting Trigger	0.95
W32-7501	Drive Gear	1.11
W32-8002	Side Cover	1.70
W32-8102	Side Cover	1.70
W32-8201	Screw	0.50
W32-8301	Click Spring	0.50
W32-8801	Pinion Gear	1.68
W32-9931	Casting Trigger	1.20
W33-5802	Drag Knob	2.52
W33-6301	Screw	0.50
W33-7901	Bail	2.46
W33-8201	Line Roller Collar	0.72
W33-8202	Collar	0.50
W33-8301	Screw	0.50
W33-8702	Bail Spring Shaft	0.88
W33-8802	Bail Spring	0.54
W33-8901	Bail Spring Holder	0.50
W33-9001	Screw	0.50
W33-9302	Washer	0.50
W33-9402	Click Gear	1.07
W33-9501	Rotor Nut Holding Plt	0.50
W33-9601	Rotor Nut	0.50
W34-0501	Bail Trip Lever Spring	0.85
W34-0601	Bail Trip Lever	0.69
W34-0602	Bail Trip Lever	0.50
W34-1401	Roller Clutch	10.74
W34-1701	Ball Bearing	3.31
W34-1804	Pinion Gear	3.61

W34-1901	A/R Cam Spring	0.50
W34-3602	Ball Bearing	2.52
W34-3801	Drive Gear	1.64
W34-4101	Collar	0.50
W34-4701	Handle Collar	0.50
W34-4702	Collar	0.54
W36-0301	A/R Lever	0.57
W36-1201	Worm Shaft	17.89
W36-1202	Worm Shaft	17.89
W36-1701	Ball Bearing	0.50
W36-1801	Osc Slider	1.80
W36-1802	Osc Slider	1.80
W36-1951	Bushing	0.50
W36-2101	Osc Pawl	1.61
W36-2102	Osc Pawl	0.50
W36-2301	Osc Pawl Washer	0.54
W36-2401	Osc Slider Cover	1.42
W36-2501	Screw	0.54
W36-2701	Worm Shaft Gear	0.72
W36-3001	Drive Gear	2.79
W36-5101	Roller Clutch	11.81
W36-5301	Collar	0.72
W36-6802	Bail Trip Lever	0.88
W36-7101	Bail Spring	0.54
W36-7201	Bail Spring Shaft	1.07
W36-7401	Screw	0.50
W36-7501	Bail Arm Screw	0.50
W36-7601	Line Roller Screw	0.50
W36-8051	Line Roller Collar	0.57
W36-9001	Main Shaft	7.88
W36-9002	Main Shaft	7.06
W36-9102	Line Guard	2.68
W36-9201	Click Gear	1.20
W36-9301	Washer	0.50
W36-9501	Drag Knob	3.59
W36-9601	Drag Washer	1.07
W36-9701	Key Washer	0.50
W36-9801	Eared Washer	1.26
W36-9901	Drag Washer Ret	0.69
W38-2202	Bail Spring	0.50
W39-0002	Body	4.65
W39-0101	Handle Screw	3.06
W39-0202	Rear Cover	0.98
W39-0301	Screw	0.50
W39-0852	Side Cover	1.48
W39-1102	Handle	2.79
W39-1152	Handle	5.60

W39-1701	Pinion Gear	1.85
W39-2602	A/R Pawl Spring B	0.50
W39-2901	Bail Trip Lever	0.50
W39-2902	Bail Trip Lever	0.50
W39-3202	Bail Spring	0.54
W39-3302	Bail Spring Shaft	0.85
W39-3602	Bail	2.79
W39-3652	Bail	2.67
W39-3801	Main Shaft	3.75
W39-3901	Click Gear	0.54
W39-4054	Spool	5.82
W40-0001	Drag Knob	4.22
W40-0301	Drag Washer	0.85
W40-0401	Spool	12.81
W40-0901	Click Pawl Washer	0.50
W40-1001	Main Shaft	1.98
W40-1101	Bail	3.12
W40-1401	Screw	0.54
W40-1501	Washer	0.54
W40-1601	Line Roller	6.08
W40-1701	Line Roller Pin	1.07
W40-1801	Line Roller Collar	0.88
W40-1901	Line Roller Screw	0.50
W40-2001	Bail Spring Cover	0.98
W40-2101	Bail Trip Lever	1.20
W40-2201	Bail Trip Lever Spring	0.88
W40-2301	Rotor	2.46
W40-2401	Bearing Retainer Screw	0.54
W40-2601	Ball Bearing	4.10
W40-2901	Pinion Gear	1.99
W40-3001	Handle	5.25
W40-3101	A/R Lever Screw	0.50
W40-3201	A/R Lever	1.26
W40-3401	Body	8.26
W40-3701	A/R Pawl Spring	0.88
W40-3801	A/R Cam Spring	0.50
W40-4101	Drive Gear Washer	0.50
W40-4201	Drive Gear	3.14
W40-4301	Osc Slider	1.61
W40-4401	Osc Slider Pin	0.50
W42-9201	Ball Bearing	3.87
W42-9202	Ball Bearing	3.87
W42-9301	Ball Bearing	0.54
W42-9302	Ball Bearing	5.36
W42-9401	Ball Bearing	5.36
W44-5601	Click Gear	0.50
W44-7001	Bail Spring	0.50

W44-7101	Bail Spring Shaft	0.72
W45-6601	Line Roller Washer	0.50
W45-7101	Bail Spring Shaft	0.63
W45-7201	Bail Spring	0.50
W45-7401	Bearing Ret Screw	0.50
W45-7601	A/R Pawl Collar	0.50
W45-7701	A/R Pawl Spring	0.50
W45-7801	A/R Pawl	0.50
W45-7901	A/R Cam	0.50
W45-8301	Side Cover Screw	0.50
W45-8501	Osc Slider	0.50
W45-8601	Osc Gear	0.50
W45-8701	Osc Gear Collar	0.50
W45-8801	Drag Metal Washer	0.50
W45-8901	Drag Metal	0.88
W45-9001	Washer	0.50
W45-9101	Drag Coil Spring Washer	0.50
W45-9201	Drag Cover	0.54
W45-9501	Rear Cover B Screw	0.50
W46-4101	Line Roller Screw	0.50
W46-4201	Rotor Nut Hold Plt Screw	0.50
W46-4301	Rotor Nut Hold Plt	0.50
W46-4501	Bail Trip Lever Washer	0.50
W46-4601	Bearing Ret Screw	0.50
W46-4901	A/R Cam Spring	0.50
W46-5301	Handle Screw	3.06
W46-5401	Drag Cover	0.50
W46-5601	Side Cover Screw A	0.50
W46-5901	A/R Pawl Collar	0.50
W46-6201	Line Roller Screw	0.50
W46-8901	Pinion Gear	0.57
W47-0401	Collar	0.50
W47-0501	Collar	0.50
W47-0601	Pinion Gear	0.57
W47-3001	Rear Cover A	0.76
W47-3601	Rear Cover A	0.76
W47-4001	Drive Gear Bushing	0.50
W48-9601	Main Shaft	3.53
W48-9701	Bail Holder Cover	0.54
W48-9801	Bail Holder Nut	0.50
W48-9902	Rotor	1.15
W49-0002	Bail	1.37
W49-0101	Ball Bearing	2.46
W49-0202	Bail Arm	0.50
W49-0301	Bail Spring Cover	0.50
W49-0401	Ball Bearing	3.72
W49-0402	Ball Bearing	3.72

W49-0501	Bearing Ret	0.50
W49-0601	Pinion Collar	0.50
W49-0701	A/R Pawl	0.50
W49-0801	Anti Reverse Cam Retainer	0.50
W49-0901	A/R Cam	0.50
W49-1001	A/R Lever	0.50
W49-1101	A/R Pawl A	0.50
W49-1201	Anti Reverse Claw Spring	0.50
W49-1302	Body	1.37
W49-1401	Handle Screw	0.50
W49-1501	Screw	0.50
W49-1602	Clutch Lever	0.72
W49-1701	Clutch Lever Bridge	1.07
W49-1801	Ball Bearing	2.46
W49-1901	Drive Gear	0.70
W49-2102	Side Cover	0.92
W49-2302	Clutch Lever B	1.07
W49-2401	Clutch Cam	0.50
W49-2501	Clutch Cam Spring	0.50
W49-2601	Click Leaf Spring	0.50
W49-2701	Osc Slider Ret	0.50
W49-2801	Osc Slider	1.07
W49-2901	Osc Gear	1.42
W49-3001	Osc Plt	0.50
W49-3101	Osc Slider Screw	0.50
W49-3201	Click Leaf Spring	0.50
W49-3301	Clutch Plt A	0.50
W49-3401	Clutch Plate Screw	0.50
W49-3501	Clutch Plate	0.50
W49-3601	Clutch Trip Lever	0.50
W49-3701	Clutch Trip Lever Spring	0.50
W49-3801	Drag Metal	0.69
W49-3901	Drag Washer	0.50
W49-4001	Eared Washer	0.50
W49-4101	Key Washer	0.50
W49-4201	Drag Coil Spring	0.50
W49-4301	Drag Washer B	0.50
W49-4401	Drag Screw	0.50
W49-4501	Drag Metal B	0.69
W49-4601	Drag Metal Washer	0.50
W49-4701	Drag Metal Retainer	0.50
W49-4802	Rear Cover A	0.76
W49-4902	Rear Cover B	0.76
W49-5001	Rear Cover B Screw	0.50
W49-5102	Drag Knob	0.88
W49-5201	Drag Knob Screw	0.50
W49-5302	Drag Knob Screw Cap	0.50

W49-5601	Spool	1.60
W49-5701	Handle	3.14
W49-5901	Spool	1.60
W49-6501	Main Shaft	5.89
W49-6601	Bail Holder Cover Screw	0.50
W49-6701	Bail Holder Cover	0.54
W49-6802	Bail	1.37
W49-6901	Ball Bearing	4.28
W49-7002	Bail Arm	0.50
W49-7102	Rotor	1.37
W49-7201	A/R Claw Spring Holder	0.50
W49-7301	Bearing Ret	0.50
W49-7401	Ball Bearing	4.28
W49-7501	Collar	0.50
W49-7601	Roller Clutch	12.54
W49-7701	Pinion Gear	3.61
W49-7801	A/R Cam	0.50
W49-7901	A/R Lever Spring	0.50
W49-8001	A/R Lever	0.50
W49-8102	Body	2.07
W49-8201	A/R Lever Screw	0.50
W49-8302	Clutch Lever A	0.72
W49-8401	Clutch Lever Bridge	1.42
W49-8501	Ball Bearing Washer	0.50
W49-8601	Ball Bearing	4.44
W49-8701	Drive Gear Assembly	2.79
W49-8801	Drive Gear Washer	0.50
W49-8902	Side Cover	1.03
W49-9102	Clutch Lever B	0.72
W49-9201	Clutch Cam	0.50
W49-9301	Clutch Cam Spring	0.50
W49-9401	Click Leaf Spring Screw	0.50
W49-9501	Click Leaf Spring	0.54
W49-9601	Osc Plt	0.50
W49-9701	Click Leaf Spring Screw	0.50
W49-9801	Osc Slider Ret	0.50
W49-9901	Osc Slider	1.26
W50-0001	Clutch Plt A	0.50
W50-0101	Clutch Plt	0.50
W50-0201	Clutch Trip Lever	0.50
W50-0301	Clutch Trip Lever Spring	0.50
W50-0401	Drag Metal Washer	0.54
W50-0501	Drag Metal	6.43
W50-0601	Drag Washer	0.50
W50-0701	Eared Washer	0.50
W50-0801	Key Washer	0.50
W50-0901	Drag Coil Spring	0.50

W50-1001	Drag Coil Spring Washer	0.50
W50-1101	Drag Screw	0.50
W50-1201	Drag Metal	0.69
W50-1301	Drag Metal Washer	0.50
W50-1401	Drag Metal Ret	0.50
W50-1502	Rear Cover A	1.23
W50-1602	Rear Cover B	1.23
W50-1702	Drag Knob	1.58
W50-1802	Cap	0.88
W50-2201	Bushing	0.50
W50-2301	Handle	5.82
W50-2401	Spool	2.30
W50-2501	Drive Gear	2.79
W50-2701	Worm Shaft Gear	3.59
W50-5601	Bail Spring Shaft	0.63
W50-8701	Washer	0.50
W51-6801	Bail Spring Cover	0.54
W51-7001	Handle	1.72
W51-7301	Bail Spring Cover	0.54
W51-7501	Handle	4.02
W51-7801	Bail Spring Cover	0.54
W51-8501	Ball Bearing	2.46
W52-3402	Bail Arm	1.42
W52-6001	Bail Spring Cover	1.23
W52-9601	L/S Plt Screw	0.50
W52-9801	Click Button	0.50
W52-9901	Click Lever Spring	0.54
W53-0001	Pin	0.50
W53-0101	Screw	0.50
W53-0201	Spool Cover	0.50
W53-0301	Spool Cover Washer	0.50
W53-0401	Spool Cover Washer	0.50
W53-0501	Spool Cover Retainer	0.50
W53-0601	Click Pawl Screw	0.50
W53-0701	Click Pawl	0.72
W53-0801	Click Lever Plate	7.15
W53-0901	Click Retainer	0.50
W53-1001	Cog Wheel	1.07
W53-1101	Click Retainer	0.50
W53-1201	Worm Shaft Gear	0.72
W53-1301	Left Set Plt	1.89
W53-1401	Screw Stud	0.63
W53-1501	Frame Stand Screw	0.50
W53-1701	Frame Stand	3.06
W53-1801	Screw Stud	0.63
W53-1901	Line Guide	5.04
W53-2001	Line Guide Pawl	0.50

W53-2101	Line Guide Pawl Washer	0.50
W53-2201	Pawl Cap	0.54
W53-2301	Level Wind Guard	1.10
W53-2401	Worm Shaft Holder	0.57
W53-2501	Worm Shaft	5.36
W53-2601	Click Gear	1.07
W53-2701	Ball Bearing	5.36
W53-2901	Spool Ring	1.10
W53-3001	Brake Mounting	0.50
W53-3101	Brake Collar	0.50
W53-3201	Right Set Plt	6.17
W53-3301	Retainer	0.79
W53-3401	Washer	0.50
W53-3501	Screw	0.50
W53-3601	Spring	0.50
W53-3701	Push Bar	0.88
W53-3801	Pilot Lever	0.63
W53-3901	Latch Bar	1.26
W53-4001	Yoke	0.79
W53-4101	Yoke Spring	0.50
W53-4201	Pinion Gear	2.34
W53-4301	Drive Shaft Washer	0.50
W53-4401	Drive Shaft	3.43
W53-4501	A/R Pawl	0.50
W53-4601	A/R Ratchet	0.50
W53-4801	Drive Gear	5.13
W53-4901	Drag Washer A	0.50
W53-5001	Drag Washer B	0.50
W53-5101	Eared Washer	0.50
W53-5201	Key Washer	0.50
W53-5601	R/S Plt	4.59
W53-5801	R/S Plt Screw	0.50
W53-5901	O Ring	0.50
W53-6001	Spool Adj Spring	0.54
W53-6101	Cast Control Cap	2.14
W53-6201	Spacer	0.50
W53-6301	Drag Spring Washer	0.50
W53-6501	Friction Washer	0.50
W53-6601	Handle	3.49
W53-6801	Handle Nut	0.72
W53-6901	Handle Nut Plate	0.50
W53-7101	Reel Stand	5.36
W53-7201	Level Wind Guard	1.10
W53-7301	Worm Shaft	9.29
W53-7401	Spool	9.84
W53-7601	Click Button	0.50
W53-7701	Click Lever Spring	0.50

W53-7801	Click Pawl	0.54
W53-7901	Click Lever Plt	0.69
W53-8001	Right Set Plt	1.76
W53-8201	Spool	4.18
W53-8401	Ret B	0.54
W53-8501	Push Bar	0.88
W53-8601	Pilot Lever	0.54
W53-8701	Latch Bar	1.07
W53-8801	Yoke	0.50
W53-8901	Pinion Gear	1.87
W53-9001	Drive Shaft	2.46
W53-9101	Drive Gear	2.75
W53-9201	L/S Plt	5.82
W53-9202	L/S Plt	5.82
W53-9401	Handle Nut	0.54
W54-5401	Screw	0.50
W54-5501	Drag Lever	1.76
W54-5601	Line Guard Screw	0.50
W54-5801	Drag Cam Spring	0.50
W54-5901	Drag Cam	0.88
W54-6001	Line Guard	3.75
W54-6101	A/R Pawl Screw	0.50
W54-6301	A/R Pawl Spring	1.20
W54-6401	Click Pawl Spring	1.42
W54-6601	Screw	0.50
W54-6701	Stand	3.53
W54-6901	Drag Nut	2.52
W54-7001	Drag Spring	1.54
W54-7101	Drag Spring Washer	0.50
W54-7201	Click Spring	0.69
W54-7301	Drag Base	2.05
W54-7701	Drag Washer Ret	0.88
W54-7801	Key Washer B	0.50
W54-8001	Eared Washer	1.04
W54-8101	Key Washer A	0.50
W54-8301	A/R Pawl	0.69
W54-8501	Drive Shaft	5.36
W54-8601	Ratchet	1.80
W54-8701	Ratchet Washer	1.07
W54-8801	Click Gear	1.07
W54-8901	Click Gear Washer	1.04
W54-9001	O Ring	0.85
W54-9101	Handle Nut Washer	0.50
W54-9201	Handle Nut Retainer	0.88
W54-9301	Click Pawl Screw	0.50
W54-9401	Click Pawl	1.04
W54-9601	Drag Knob Screw	0.50

W54-9701	Handle Nut Washer	0.50
W55-9201	Side Cover	1.15
W55-9701	Rotor	1.15
W55-9801	Body	1.37
W55-9901	Side Cover	0.92
W56-0201	Rotor	1.15
W56-0401	Side Cover	0.92
W56-0701	Rotor	1.15
W56-0801	Body	1.74
W56-0901	Side Cover	1.15
W56-3101	O-Ring	0.88
W56-3501	Spring	0.50
W56-4201	Roller Clutch	8.95
W56-4701	Bearing Retainer	0.79
W56-9901	Anti-Reverse Pawl	0.63
W57-0001	A/R Cam Lever Spring	0.50
W57-0101	Anti-Reverse Pawl	0.63
W57-0301	Collar B	0.50
W57-5400	Ball Bearing	3.94
W57-9501	Bushing	0.72
W58-0801	Bail	5.60
W58-1401	Bail	9.66
W58-2401	Bail	10.25
W58-4501	R/S Plate (B)	5.82
W58-5001	R/S Plate (B)	5.82
W58-5801	Rotor	1.64
W58-5901	Rotor	1.99
W58-7301	Drag Knob	1.76
W58-7401	Click Plate	2.11
W58-7501	Drag Cam	1.42
W58-7601	Screw	0.50
W58-7701	Drag Spring	1.58
W58-7801	Click Pawl	0.88
W58-7901	Retainer	0.88
W58-8001	Retaining Spring	0.54
W58-8101	Washer	0.50
W58-8201	Retainer Washer	0.88
W58-8301	Retainer Screw	0.50
W58-8401	Spool	8.04
W58-8501	Frame	8.49
W58-8601	Drag Spring	1.95
W58-8701	Spool	8.96
W58-9801	Roller Clutch	10.27
W59-0401	Right Side Plate	5.82
W59-4501	Drag Knob	0.88
W59-4601	Front Cover	3.34
W59-4701	Spool	1.52

W59-4801	Cap	0.72
W59-4901	Side Ring	1.07
W59-5001	Handle Stand	0.54
W59-5101	Handle	2.44
W59-5201	SIDE RING	1.07
W59-5301	Cap	0.50
W59-5401	Side Ring	1.07
W59-5501	Handle Stand	0.72
W59-5601	Handle	3.49
W59-5701	Spool	1.74
W59-5801	Front Cover	6.99
W59-5901	Spool	1.50
W59-6001	Front Cover	4.60
W59-6101	Side Ring	2.30
W59-6201	Side Cover	1.52
W59-6301	Body	4.65
W59-6401	Cap	0.54
W59-6501	Push Button	1.23
W59-6601	Pinion Gear	1.74
W59-6701	Spool	1.74
W59-6801	Front Cover	4.22
W59-6901	Handle Stand	0.72
W59-7001	Handle	3.49
W59-7101	Side Cover	1.50
W59-7201	Body	3.79
W59-7301	Spool	1.87
W59-7401	Front Cover	6.99
W59-7501	Side Cover	1.50
W59-7601	Body	4.02
W59-7701	Spool	1.50
W59-7801	Front Cover	4.60
W59-7901	Side Ring	2.65
W59-8001	Side Cover	1.72
W59-8101	Body	4.24
W59-8201	Push Button	1.23
W59-8301	Spool	1.56
W59-8401	Front Cover	4.76
W59-8501	Handle Stand	0.72
W59-8601	Handle	3.49
W71-9701	Main Shaft	3.21
W72-0001	Body	3.26
W72-4501	Screw	0.50
W73-1601	Drag Knob	1.42
W73-1701	Spool	6.05
W73-1801	Bail Arm	1.07
W73-1901	Handle Screw	1.61
W73-2001	Anti-Reverse Lever	1.26

W73-2101	Rear Cover B	1.42
W73-2201	Drag Knob	3.21
W73-2301	Cap	0.88
W73-2401	Spool	6.52
W73-2601	Spool	7.34
W73-2701	Bail Arm	1.26
W73-2901	Handle Screw	1.95
W73-3001	Spool	7.81
W74-2001	Spool Washer	0.50
W74-2101	Screw	0.50
W74-2301	Line Roller Screw	0.54
W74-2401	Bearing Retainer A	1.07
W74-2501	Screw	0.50
W74-2601	Anti Reverse Claw Screw	0.50
W74-2701	Body	3.73
W74-2801	Clutch Lever A	0.88
W74-3001	Clutch Lever B	1.26
W74-3101	Clutch Cam	1.07
W74-3201	Clutch Cam Spring	0.72
W74-3301	Osc Slider Ret Screw	0.50
W74-3401	Clutch Plate A	0.88
W74-3501	Clutch Plate Screw	0.50
W74-3701	Rear Cover B	1.42
W74-3801	Rear Cover B Screw	0.50
W74-3901	Drag Knob	3.75
W74-5101	Side Ring	1.80
W74-5201	Side Ring Screw	0.50
W74-5601	A/R Reverse Spring Holder	0.88
W74-5701	Bearing Retainer	1.42
W74-6201	Clutch Lever A Screw	0.50
W74-6301	Clutch Lever A	1.07
W74-6501	Bushing	1.07
W74-6701	Clutch Lever B	1.42
W74-6801	Clutch Cam	1.26
W74-6901	Cluth Cam Spring	0.88
W74-7001	Click Leaf Spring Screw	0.50
W74-7101	Osc Slider Ret Screw	0.50
W74-7201	Clutch Plate	1.07
W74-7401	Rear Cover B	1.95
W74-7501	Drag Knob	4.13
W74-7601	Side Ring	2.14
W74-7701	Side Ring Screw	0.50
W74-7801	Washer	0.72
W74-8301	Pinion Gear Collar	1.07
W74-8401	Body	4.65
W75-1601	Roller Clutch Washer	0.50
W75-3301	Arm Lever Screw	0.50

W75-3701	Screw	0.72
W75-4201	Drive Gear Washer	0.50
W75-4501	Body Cover Screw	0.72
W75-4601	Body Cover Screw	0.72
W75-5801	Osc Gear Bushing Screw	0.50
W76-4201	Clutch Lever Screw	0.54
W77-0801	Arm Lever Screw	0.72
W77-1201	Bail Spring Holder	0.72
W77-1501	Rotor Nut	1.07
W78-0001	Ball Bearing	4.28
W79-6201	Main Shaft	2.87
W79-6302	Bail Arm	1.26
W79-6401	Collar	0.88
W79-6701	Bail Spring Cover	1.26
W79-6702	Rotor Cover	1.26
W79-6801	Bail Spring Holder	0.72
W79-7001	Pinion Gear Collar	0.88
W79-7101	Anti-Reverse Pawl Spring	0.54
W79-7201	A/R Spring Holder	0.54
W79-7301	Screw	0.50
W79-7401	Bearing Retainer	0.88
W79-7501	Ball Bearing	3.94
W79-7601	Pinion Gear	1.39
W79-7701	Anti-Reverse Pawl	0.88
W79-7801	Anti-Reverse Cam	0.88
W79-7901	Anti-Reverse Cam Spring	0.50
W79-8102	Handle Screw	1.95
W79-8201	Oscillation Slider	1.07
W79-8301	Drive Gear	1.74
W79-8901	Bail	3.49
W79-9101	Pinion Gear Collar	0.88
W79-9201	Anti Reverse Pawl Spring	0.54
W79-9301	Roller Clutch	8.22
W79-9401	Pinion Gear Collar	1.07
W79-9501	Bearing Retainer	1.07
W79-9601	Anti Reverse Lever	1.42
W90-2001	Roller Clutch	2.93
W90-8001	Ball Bearing	1.67
W90-8401	Ball Bearing	1.67
W91-0001	Body	2.87
W91-0201	Screw	0.50
W91-0501	Bearing Plt	0.72
W91-0801	Glow Plate	0.91
W91-0802	Rear Cover	1.10
W91-0901	Body Cover Ring	2.21
W91-1401	Shaft Key	0.91
W91-1601	Shaft Key Spring	0.50

W92-0001	Body Cover	1.44
W92-0201	Clicker Spring	0.50
W93-0001	Rotor	2.40
W93-0101	Bail Arm	1.10
W93-0401	Bail Arm Lever Cover	1.10
W93-0501	Bail Lever	0.50
W93-0701	Rotor	2.40
W93-0801	Sleeve	0.50
W93-0901	Bail Arm Osc Slider	0.50
W93-1001	Bail Spring	0.50
W93-1101	Bail Arm Shaft	0.50
W93-1501	Line Roller	1.10
W93-1601	Line Roller Bushing	0.50
W93-1801	Rotor Nut	0.72
W93-1901	Rotor Ret Plt	0.50
W93-2701	Rotor Nut Ret Plt	0.50
W93-8301	Screw	0.50
W94-0301	Spool	5.99
W94-0302	Spool *Extra*	5.99
W94-0501	Retainer	0.50
W94-2501	Screw	0.50
W94-5201	Screw	0.50
W94-5401	Screw	0.50
W94-5801	Screw	0.50
W95-1301	Handle Screw Cap	1.04
W95-1501	Handle Cap Washer	0.50
W95-3501	Screw	0.50
W95-4501	Screw	0.50
W95-5201	Screw	0.50
W95-8201	Screw	0.50
W95-9701	Screw	0.50
W95-9901	Screw	0.50
W96-0001	Drag Knob Assembly	3.31
W96-0201	Rear Drag Spring	0.50
W96-0301	Ret Plate	0.50
W96-0401	Rear Drag Ring	1.10
W96-0601	Click Spring	0.50
W96-0701	Clicker Seat	0.91
W96-0801	Rear Drag Washer B	0.50
W96-0901	Clutch Holder	0.91
W96-1001	Drag Washer	0.50
W96-1101	Eared Washer	0.50
W96-1201	Drag Washer	0.57
W96-1301	Clutch Ret Spring	0.50
W96-1901	Key Washer	0.91
W96-2401	Shim	0.50
W96-2901	Rear Drag Knob	1.10

W96-6001	Drag Washer (Rear)	0.50
W96-6201	Rear Drag Key Washer	0.50
W96-9901	Clutch Plate	0.50
W97-0001	Drive Gear	0.84
W97-0101	Ball Bearing	1.67
W97-0201	Pinion Gear	2.15
W97-0301	Bearing Holder	0.72
W97-0501	Osc Gear	1.48
W97-0801	Osc Slider	1.48
W97-0901	Cover Plate	0.50
W97-1001	Screw	0.50
W97-1801	Main Shaft	2.21
W97-1901	Click Gear	0.50
W97-2201	Washer Ret	0.50
W97-3101	Free Spool Lever Plt	0.57
W97-3701	Spacer Washer	0.50
W98-0001	A/R Lever	0.50
W98-0101	A/R Cam Spring	0.50
W98-0301	A/R Lever	0.72
W98-0401	Br Clutch Cam	0.72
W98-0801	A/R Switch	0.50
W98-1001	Roller Clutch Washer	0.50
W98-1101	Rotor Ball Bearing Washer	0.50
W98-1301	Bail Assembly	4.31
W98-1901	Drive Gear Washer	0.50
W98-2001	Roller Clutch Spring	0.50
W98-3301	Pinion Gear Washer	0.50
W98-6201	Screw	0.50
W98-8801	Grip Ring	0.79
W99-0101	Clicker Spring Ret	0.50
W99-1101	Bail Assembly	4.31
W99-1701	A/A Lever Spring	0.50
W99-3501	Free Spool Lever	0.72
W99-4501	Lever Plate	0.50
W99-5501	Br Clutch Cam Spring	0.50
W99-6501	Free Spool Lever	0.72
W99-7501	Free Spool Lever	0.72
W99-9901	Screw	0.50
WD0-0301	Drag Knob	2.52
WD0-0401	Spool	6.74
WD0-0501	Line Roller	2.68
WD0-0601	Rotor	1.64
WD0-0701	Body	2.09
WD0-0801	Side Cover	1.39
WD0-0901	Handle	3.73
WD0-1001	Spool	6.99
WD0-1101	Ball Bearing	2.52

WD0-1201	Drag Knob	3.06
WD0-1301	Spool	6.74
WD0-1401	Rotor	1.99
WD0-1501	Body	2.34
WD0-1601	Ball Bearing	2.52
WD0-1701	Side Cover	1.87
WD0-1801	Handle	4.18
WD0-1901	Spool	6.99
WD0-2101	Drag Knob	3.06
WD0-2201	Spool	10.25
WD0-2301	Rotor	1.99
WD0-2401	Body	2.56
WD0-2501	Ball Bearing	3.94
WD0-2601	Side Cover	1.87
WD0-2701	Handle	4.18
WD0-2801	Spool	10.48
WD0-5501	Drag Knob	3.06
WD0-5601	Spool	13.39
WD0-5602	Spool	6.87
WD0-5603	Spool	13.86
WD0-5701	Rotor	2.79
WD0-5702	Rotor	2.79
WD0-5703	Rotor	2.79
WD0-5801	Anti-Reverse Lever	1.07
WD0-5901	Side Cover	2.34
WD0-6001	Handle	8.96
WD0-6101	Rear Cover A	2.68
WD0-6201	Spool	15.03
WD0-6202	Spool	15.48
WD0-6203	Spool	15.48
WD0-6301	Ball Bearing	5.36
WD0-6401	Handle	11.30
WD0-6501	Drag Knob	2.52
WD0-6601	Spool	12.12
WD0-6602	Spool	13.28
WD0-6701	Rotor	2.09
WD0-6801	Bail Arm	1.07
WD0-6901	Side Cover	1.87
WD0-7001	Handle	8.04
WD0-7002	Handle	10.37
WD0-7101	Rear Cover A	2.33
WD0-7201	Ball Bearing	5.36
WD0-7301	Ball Bearing	5.36
WD0-7401	Drag Knob	2.52
WD0-7501	Spool	13.39
WD0-7502	Spool	13.98
WD0-7601	Spool Washer	0.50

WD0-7701	Click Gear	1.07
WD0-7801	Main Shaft	5.01
WD0-7901	Bail Screw	0.72
WD0-8001	Bail	5.00
WD0-8002	Bail	5.47
WD0-8201	Line Roller	7.15
WD0-8301	Bail Arm	1.07
WD0-8401	Rotor Cover A	2.14
WD0-8402	Rotor Cover A	2.33
WD0-8501	Bail Spring Shaft	0.88
WD0-8601	Bail Spring	0.54
WD0-8701	Bail Shaft	0.88
WD0-8702	Bail Shaft	1.26
WD0-8801	Rotor Nut	2.68
WD0-8901	Rotor	2.09
WD0-8902	Rotor	2.79
WD0-9001	Rotor Cover B	2.14
WD0-9002	Rotor Cover B	2.33
WD0-9101	Pinion Gear Collar A	0.88
WD0-9201	Bearing Ret Screw	0.50
WD0-9301	Bearing Retainer	1.07
WD0-9401	Ball Bearing	5.36
WD0-9501	Ball Bearing Collar	1.07
WD0-9601	Pinion Gear Collar A	0.72
WD0-9701	Roller Clutch	10.74
WD0-9801	Pinion Gear Collar	0.72
WD0-9901	Pinion Gear	3.61
WD1-0001	A/R Pawl Screw	0.50
WD1-0101	Anti-Reverse Pawl	0.72
WD1-0201	Anti Reverse Claw Spring	1.07
WD1-0301	Anti-Rev Cam Spring	2.52
WD1-0401	Anti Reverse Cam	0.72
WD1-0501	O-Ring	0.54
WD1-0601	Anti-Rev Lever	1.07
WD1-0701	Rear Cover Screw A	0.50
WD1-0801	Body	3.49
WD1-0802	Body	3.49
WD1-0901	Handle Screw	2.68
WD1-1001	Rear Cover	1.80
WD1-1101	Rear Cover Screw B	0.50
WD1-1201	Oscillating Gear	1.42
WD1-1301	Bushing	1.07
WD1-1401	Washer	0.50
WD1-1501	Oscillation Slider	1.07
WD1-1601	Stabilizer Bar	0.72
WD1-1701	Stabilizer Bar Screw	0.50
WD1-1801	Spring	0.54

WD1-1901	A/R Plunger Spring Screw	0.50
WD1-2001	Anti Reverse Pawl Plunger	1.26
WD1-2101	Anti Reverse Plunger Scre	0.50
WD1-2201	Anti Reverse Claw	0.72
WD1-2301	Spring	0.88
WD1-2401	Drive Gear	2.34
WD1-2501	Side Cover	1.87
WD1-2502	Side Cover	1.87
WD1-2601	Handle	13.16
WD1-2701	Anti Reverse Washer	0.50
WD1-2801	Pinion Gear Collar	1.26
WD1-2901	Drag Knob	3.06
WD1-3001	Spool	14.78
WD1-3002	Spool	14.78
WD1-3101	Main Shaft	5.73
WD1-3201	Bail	6.17
WD1-3301	Bail Arm	1.42
WD1-3401	Rotor Cover A	2.52
WD1-3501	Bail Shaft	1.07
WD1-3601	Rotor Nut Holding Plt Scr	0.54
WD1-3701	Rotor	3.26
WD1-3801	Rotor Cover B	2.52
WD1-3901	Pinion Ball Bearing Colla	1.42
WD1-4001	Pinion Gear Collar C	1.07
WD1-4101	Pinion Gear	4.18
WD1-4201	A/R Pawl Screw	0.50
WD1-4301	Anti-Reverse Cam	1.26
WD1-4401	Body	4.65
WD1-4501	Rear Cover	2.52
WD1-4601	Oscillating Gear	1.80
WD1-4701	Oscillation Slider	1.42
WD1-4801	Stabilizer Bar	1.07
WD1-4901	Stabilizer Bar Screw	0.54
WD1-5001	Anti-Reverse Pawl	1.61
WD1-5101	Screw	0.54
WD1-5201	A/R Pawl Collar	0.72
WD1-5301	Spring	1.07
WD1-5401	Drive Gear	3.03
WD1-5501	Side Cover	2.34
WD1-5601	Side Cover Screw	0.72
WD1-5701	Handle	11.30
WD1-5801	Osc Slider Screw	0.50
WD4-0001	Body	26.77
WD4-0101	Spool Assembly	22.12
WD4-0201	Handle Knob	2.14
WD4-0301	Handle Knob Screw	2.52
WD4-0401	Handle Knob Cap	0.50

WD4-0501	Drag Washer	4.28
WD4-0601	Drag Knob	4.47
WD4-0701	Spool Assembly	22.12
WD5-3601	Body	5.13
WD5-3602	Body	6.52
WD5-3701	A/R Lever	1.80
WD5-3702	A/R Lever	1.80
WD5-3801	Rear Cover	1.95
WD5-3802	Rear Cover	2.33
WD5-3901	Ball Bearing	3.21
WD5-4001	Side Cover	2.34
WD5-4002	Side Cover	2.56
WD5-4101	Handle Assembly	11.64
WD5-4102	Handle Assembly	11.64
WD5-4301	Ball Bearing	3.21
WD5-4401	Pinion Gear	3.49
WD5-4501	Bail Arm	1.80
WD5-4502	Bail Arm	1.80
WD5-4601	Bail Assembly	5.00
WD5-4602	Bail Assembly	5.70
WD5-4701	Rotor	3.14
WD5-4702	Rotor	4.08
WD5-4801	Washer	0.54
WD5-4901	Spool Assembly	13.16
WD5-4902	Spool Assembly	13.16
WD5-4903	Spool Assembly	14.33
WD5-4904	Spool Assembly	14.33
WD5-5001	Drag Knob	7.15
WD5-5101	Ball Bearing	3.21
WD5-5201	Ball Bearing	3.21
WD5-5301	Pinion Gear	3.96
WD5-5401	Screw	0.50
WD5-5501	Body	5.13
WD5-5502	Body	6.52
WD5-5601	A/R Lever	1.80
WD5-5602	A/R Lever	1.80
WD5-5701	Rear Cover	2.33
WD5-5702	Rear Cover	2.33
WD5-5801	Side Cover	2.34
WD5-5802	Side Cover	2.56
WD5-5901	Handle Assembly	11.64
WD5-5902	Handle Assembly	11.64
WD5-6001	Bail Arm	1.80
WD5-6002	Bail Arm	1.80
WD5-6101	Bail Assembly	5.00
WD5-6102	Bail Assembly	5.70
WD5-6201	Rotor	3.14

WD5-6202	Rotor	4.08
WD5-6301	Line Guard	3.06
WD5-6302	Spool Guide Support	3.75
WD5-6401	Spool Assembly	15.13
WD5-6402	Spool	15.13
WD5-6403	Spool Assembly	16.30
WD5-6404	Spool Assembly	16.30
WD5-6501	Drag Knob	7.15
WD5-6901	Drag Knob Assembly	3.06
WD5-7001	Spool Assembly	6.99
WD5-7101	Rotor	1.99
WD5-7201	Body	2.56
WD5-7301	Side Cover	1.87
WD5-7401	Handle Assembly	4.18
WD5-9801	Side Plate Screw	0.50
WD5-9901	Left Side Plate	5.58
WD6-0001	Frame	7.79
WD6-0101	Spool Assembly	10.70
WD6-0201	Right Set Plate	8.57
WD6-0301	Drag Washer A	4.10
WD6-0401	Drag Washer	4.10
WD6-0501	Right Side Plate	6.68
WD6-0601	Cast Control Cap	2.05
WD6-0701	Star Drag	3.43
WD6-0801	Handle Assembly	4.45
WD6-0901	Handle Nut Plate	0.50
WD6-1001	Frame	7.79
WD6-1101	Spool Assembly	11.15
WD6-1201	Right Side Plate	6.68
WD6-1301	Right Side Plate	5.58
WD6-1401	Frame	5.74
WD6-1501	Spool Assembly	11.15
WD6-1601	Left Set Plate	8.57
WD6-1701	Left Side Plate	6.68
WD6-1801	Star Drag	3.43
WD6-1901	Frame	7.79
WD6-2001	Spool Assembly	10.25
WD6-2101	Left Side Plate	6.68
WD6-6201	Spool Assembly	11.15
X09-0801	LINE THROUGH	2.21
X14-8901	Reel Guard Oil	14.36
X35-4301	FALL BRAKE DIAL SEAL	2.38
Z00-2611	Spool	14.88
Z00-2892	Spool	12.18
Z00-2984	Pick Up Pin	1.61
Z00-2985	Pick Up Pin	2.87
Z00-2986	Pick-Up Pin	2.87

Z01-2450	Handle	3.59
Z01-7536	Spool	41.06
Z01-7616	Spool	51.29
Z01-8583	Spool	40.65
Z01-8872	Spool	19.31
Z01-9584	Handle Screw	5.45
Z01-9590	Spool Assembly	82.35
Z01-9593	Pinion+Drive Gear Unit	46.99
Z01-9605	Osc Gear	14.05
Z01-9645	Spool Assembly	47.52
Z02-0297	Spool	78.74
Z02-0417	Pinion+Drive Gear Unit	20.27
Z02-0493	Pinion + Drive Gear	19.80
Z02-0653	Pinion + Drive Gear	8.63
Z02-0692	Pinion + Drive Gear	14.74
Z02-0737	Pinion + Drive Gear	10.46
Z02-0754	Pinion+Drive Gear	54.76
Z02-0865	Pinion+Drive Gear Unit	54.18
Z02-0976	SPOOL ASSY	19.31
Z02-1098	Spool	76.42
Z02-1103	Spool	80.71
Z02-1110	Spool	90.20
Z02-1171	Pinion+Drive Gear Unit	80.03
Z02-1272	Spool Assembly	30.83
Z02-1279	Pinion+Drive Gear Unit	68.51
Z02-1280	Pinion+Drive Gear Unit	69.76
Z02-1384	Pinion + Drive Gear	36.53
Z02-1472	Pinion + Drive Gear	36.53
Z02-1503	Pinion + Drive Gear	40.30
Z02-1510	Pinion+Drive Gear Unit	7.01
Z02-1543	Spool Assembly	35.51
Z02-1570	Pinion+Drive Gear Unit	8.75
Z02-1606	Pinion+Drive Gear Unit	9.74
Z02-1642	Pinion+Drive Gear Unit	99.45
Z02-1657	Pinion+Drive Gear Unit	82.64
Z02-1693	Pinion+Drive Gear Unit	138.42
Z02-1698	Pinion+Drive Gear Set	33.97
Z02-1716	Pinion+Drive Gear Unit	111.60
Z02-1720	MOTOR HOLDER	89.27
Z02-1722	MOTOR	73.99
Z02-1737	Pinion+Drive Gear Unit	49.34
Z02-1758	Pinion+Drive Gear Unit	56.76
Z02-1769	Pinion+Drive Gear Set	33.97
Z02-1801	Pinion+Drive Gear Unit	69.60
Z02-1819	Pinion+Drive Gear Set	33.97
Z02-1822	Pinion+Drive Gear Set	33.97
Z02-1825	Pinion+Drive Gear Set	33.97

Z02-1828	Pinion+Drive Gear Set	33.97
Z02-1831	Pinion+Drive Gear Set	28.06
Z02-1871	Pinion+Drive Gear Unit	44.75
Z02-1874	Pinion + Drive Gear Set	44.75
Z02-1881	PINION + DRIVE GEAR UNIT	38.35
Z02-1910	Spool Assembly	91.51
Z02-1953	Pinion+Drive Gear Unit	10.21
Z02-1954	Pinion+Drive Gear Unit	11.48
Z02-1955	Pinion+Drive Gear Unit	12.32
Z02-2042	Spool Assembly	42.39
Z02-2079	Pinion+Drive Gear Unit	59.16
Z02-2092	Pinion+Drive Gear Unit	68.88
Z02-2112	Pinion+Drive Gear Unit	55.33
Z02-2144	Pinion+Drive Gear Unit	176.38
Z02-2181	Pinion+Drive Gear Unit	166.60
Z02-2183	Pinion+Drive Gear Unit	157.11
Z02-2199	Power Cord	98.28
Z02-2423	Spool Assembly	42.39
Z02-2470	Pinion+Drive Gear Unit	123.96
Z02-2528	Spool Assembly	68.06
Z02-2586	Spool Assembly	29.40
Z02-2599	PINION+DRIVE GEAR UNIT	123.96
Z02-2625	Pinion+Drive Gear Unit	31.34
Z02-2636	Pinion+Drive Gear Unit	137.43
Z02-2651	Pinion+Drive Gear Unit	52.73
Z02-2654	Spool Assembly	122.22
Z02-2655	Spool Assembly	77.20
Z02-2659	Pinion+Drive Gear Unit	116.46
Z02-2672	Pinion+Drive Gear Unit	100.04
Z02-2675	Pinion+Drive Gear Unit	52.73
Z02-2724	Pinion+Drive Gear Unit	54.82
Z02-2728	Pinion+Drive Gear Unit	54.82
Z02-2784	Spool Assembly	33.01
Z02-2839	Spool Assembly	22.08
Z02-3041	Pinion+Drive Gear Unit	24.20
Z02-3097	Pinion+Drive Gear Unit	19.34
Z02-3102	Pinion+Drive Gear Unit	17.94
Z02-3105	Pinion + Drive Gear Unit	17.83
Z02-3132	Spool Assembly	59.53
Z02-3151	Spool Assembly	32.41
Z02-3232	Pinion + Drive Gear Unit	158.98
Z02-3235	Pinion + Drive Gear Unit	150.72
Z02-3243	Pinion+Drive Gear Unit	50.02
Z02-3246	Spool Assembly	100.70
Z02-3256	PINION GEAR + DRIVE GEAR UNIT	26.58
Z02-3302	Pinion+Drive Gear Unit	50.02
Z02-3312	Pinion+Drive Gear Unit	52.42

Z02-3334	Spool Assembly	42.62
Z02-3410	Pinion+Drive Gear Unit	50.02
Z02-3502	SPOOL	70.56
Z02-3510	Spool Assembly	53.87
Z02-3619	Pinion + Drive Gear Unit	36.53
Z02-3645	Pinion + Drive Gear Unit	135.34
Z02-3673	Pinion + Drive Gear Unit	133.76
Z02-3684	Pinion + Drive Gear Unit	36.53
Z02-3701	Pinion + Drive Gear Unit	36.53
Z02-3704	Pinion + Drive Gear Unit	148.54
Z02-3746	Pinion + Drive Gear Unit	36.53
Z02-3748	Pinion + Drive Gear Unit	131.79
Z02-3750	Pinion + Drive Gear Unit	132.88
Z02-3766	MOTOR HOLDER	41.95
Z02-3768	MOTOR	52.01
Z02-3802	Pinion + Drive Gear Unit	131.79
Z02-3806	Pinion + Drive Gear Unit	131.59
Z02-3848	PINION + DRIVE GEAR SET	31.68
Z02-3853	PINION + DRIVE GEAR UNT	44.52
Z02-3855	SPOOL UNIT(22-31)	106.33
Z02-3856	PINION + DRIVE GEAR SET	30.13
Z02-3907	PINION + DRIVE GEAR SET	31.90
Z02-3932	Spool Assembly	130.48
Z02-3998	Pinion+Drive Gear Unit	48.71
Z02-4005	Pinion + Drive Gear Unit	43.71
Z02-4006	Pinion+Drive Gear Set	43.71
Z02-4031	Pinion + Drive Gear	140.71
Z02-4106	Pinion + Drive Gear Unit	132.45
Z02-4117	Spool Assembly	29.68
Z02-4186	Pinion + Drive Gear Set	44.75
Z02-4206	PINION GEAR + DRIVE GEAR UNIT	23.83
Z02-4207	PINION GEAR + DRIVE GEAR UNIT	23.49
Z02-4208	PINION GEAR + DRIVE GEAR UNIT	25.19
Z02-4229	PINION GEAR + DRIVE GEAR UNIT	15.99
Z02-4544	PINION + DRIVE GEAR UNIT	78.75
Z02-4547	SPOOL UNT	97.24
Z02-4637	PINION GEAR + DRIVE GEAR UNIT	59.81
Z02-4658	PINION + DRIVE GEAR UNIT	77.29
Z02-4670	PINION + DRIVE GEAR UNIT	122.62
Z02-4673	PINION+DRIVE GEAR UNIT	126.42
Z02-4680	PINION GEAR + DRIVE GEAR UNIT	59.59
Z02-4814	PINION + DRIVE GEAR SET	32.12
Z02-4926	PINION + DRIVE GEAR SET	33.45
Z02-4927	PINION + DRIVE GEAR SET	25.03
Z02-4945	PINION+DRIVE GEAR UNIT	128.31
Z02-4947	PINION+DRIVE GEAR UNIT	125.09
Z02-4996	SPOOL ASSY	42.62

Z02-5093	SPOOL ASSY	42.62
Z02-5179	SPOOL ASSY	47.43
Z02-5181	PINION + DRIVE GEAR SET	63.75
Z02-5287	SPOOL ASSY (16-24)	31.23
Z02-5390	PINION + DRIVE GEAR SET	70.78
Z02-5394	PINION + DRIVE GEAR SET	64.29
Z02-5446	PINION + DRIVE GEAR SET	138.64
Z02-5447	PINION + DRIVE GEAR SET	157.11
Z02-5448	PINION + DRIVE GEAR SET	139.28
Z02-9640	Spool Assembly	52.75