


DAIWA

BAITCASTING REEL

CSTW200HL

*Please order by parts number, not key number.



Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW
2	E16-7101	BRAKE DIAL SPRING
3	M67-3702	BRAKE DIAL
4	B33-9801	BRAKE DIAL RETAINER(A)
5	F63-7701	BRAKE DIAL COLLAR
6	J88-6201	BRAKE DIAL LEAF SPRING
7	M83-5301	RS PLATE
8	J84-3301	BRAKE DIAL RETAINER(B)
9	G93-9301	BRAKE DIAL RETAINER(B) SCREW
10	M67-3801	MAG HOLDER
11	375-7404	RS BEARING WASHER(A)(0.3mm)
12	375-7411	RS BEARING WASHER(B)(1.0mm)
13	G18-5101	RS BEARING WASHER(C)
14	G51-1506	RS BALL BEARING
15	F03-2201	RS BEARING RING
16	M83-4301	SPOOL(17-20)
17	H77-0601	SPOOL O RING (A)
19	J33-9401	SPOOL PIN
20	M42-6701	SPOOL O RING (B)
21	M83-4801	FRAME(99-102)
22	M67-3403	FRONT COVER
23	M04-7801	FRONT COVER COLLAR
24	H53-1508	FRONT COVER SCREW
25	M67-1501	CLUTCH LEVER
26	H00-5701	CLUTCH LEVER SCREW
27	M67-1101	CLUTCH LEVER PLATE(L)
28	M67-1001	CLUTCH LEVER PLATE(R)
29	M67-4001	OSCILLATING POST
30	M46-8101	CLUTCH CAM COLLAR
31	M33-5101	KICK LEVER PLATE(A)
32	M83-9701	KICK LEVER SPRING
33	M38-7701	KICK LEVER
34	M71-8701	CLUTCH CAM PLATE
36	H15-9201	CLUTCH CAM PLATE WASHER(A)(0.25mm)
37	F54-2701	CLUTCH CAM PLATE WASHER(B)
38	B36-0406	CLUTCH CAM SCREW
39	M04-4101	KICK LEVER PLATE(B)
40	M70-7201	CLUTCH PLATE
41	B03-2904	KICK LEVER PLATE(B) SCREW
42	M67-2601	CLUTCH SPRING
43	Z02-8397	PINION DRIVE GEAR SET
44	M83-4701	LS PLATE
45	M46-8001	PINION COLLAR
46	E21-9701	PINION COLLAR RING
47	B05-5201	ZERO ADJUSTER O RING
48	J21-3101	ZERO ADJUSTER WASHER(A)
49	B17-5503	ZERO ADJUSTER WASHER(B)(0.5mm)
50	M57-1002	ZERO ADJUSTER
51	B55-7622	LS PLATE SCREW(B)
52	B55-7620	LS PLATE SCREW(B)

Key No	Part No	Description
53	320-5901	WORM SHAFT RETAINER
54	B41-1702	WORM SHAFT WASHER(0.3mm)
55	G72-0001	WORM SHAFT COLLAR
56	M68-1001	LEVELWIND
57	J74-0201	PAWL HOLDER PIN
58	M45-4101	PAWL
59	M16-1301	PAWL WASHER(0.1mm)
60	G25-2202	PAWL HOLDER O RING
61	M70-7401	WORM SHIELD
62	M01-6701	WORM SHAFT
63	G72-0001	WORM SHAFT COLLAR
64	M67-2901	WORM SHAFT GEAR
65	B33-9801	WORM SHAFT GEAR RETAINER
66	G09-9801	GEAR SHAFT WASHER(0.1mm)
67	320-8002	GEAR SHAFT RETAINER
68	F64-8301	GEAR SHAFT COLLAR
69	M45-4001	GEAR SHAFT PLATE
70	G29-7002	GEAR SHAFT PLATE SCREW
71	J28-1001	WORM GEAR
72	M83-3602	GEAR SHAFT
73	F65-7801	GEAR SHAFT O RING
74	M67-3101	RATCHET
75	J08-5101	DRIVE GEAR WASHES
76	Z02-8397	PINION DRIVE GEAR SET
77	H45-2602	DRAG WASHER
78	M83-4101	DRIVE COLLAR
79	M02-5201	DRIVE COLLAR SPRING
80	H45-2801	DRIVE COLLAR PIN
81	J56-6201	DRIVE COLLAR O RING
82	J32-7701	DRAG COLLAR
83	G81-9801	ONE WAY CLUTCH
84	B55-3804	HANDLE BEARING WASHER(A)(0.8mm)
85	G43-1008	HANDLE BALL BEARING
86	B55-3804	HANDLE BEARING WASHER(B)(0.8mm)
87	F02-8203	DRAG HOLDER
88	F03-2401	DRAG HOLDER LEAF SPRING
89	150-8901	DRAG SPRING WASHER
90	H92-9501	STAR DRAG WASHER
91	H91-2002	DRAG NUT
92	J01-1901	DRAG NUT SPRING
93	H91-1917	STAR DRAG
94	F57-6601	HANDLE WASHER
95	M83-4401	HANDLE ASSY
96	G79-3309	HANDLE NUT
97	J62-5401	HANDLE CAP
98	G83-5506	HANDLE CAP SCREW
99	M70-6704	FRAME
100	M87-8201	FRAM COVER
101	M04-7801	FRAME COVER SCREW COLLAR
102	H53-1509	FARME COVER SCREW