


# DAIWA BAITCASTING REEL

## LX-TW400-P\_P-P\_H-P\_XH-P

\*Please order by parts number, not key number.



| Key No | Part No  | Description                        |
|--------|----------|------------------------------------|
| 1      | J71-6301 | BRAKE DIAL SCREW                   |
| 2      | E16-7101 | BRAKE DIAL SPRING                  |
| 3      | J93-5801 | BRAKE DIAL                         |
| 4      | B33-9801 | BRAKE DIAL RETAINER(A)             |
| 5      | F63-7701 | BRAKE DIAL WASHER                  |
| 6      | J93-5901 | BRAKE CLICK SPRING                 |
| 7      | J97-5103 | LEFT SIDE PLATE                    |
| 8      | J94-6901 | BRAKE DIAL RETAINER(B)             |
| 9      | G93-9301 | BRAKE DIAL RETAINER(B) SCRERW      |
| 10     | J97-4501 | MAGNET HOLDER                      |
| 11     | 375-7404 | LS BEARING WASHER (A)              |
| 12     | 375-7411 | LS BEARING WASHER (B)              |
| 14     | G51-1501 | LS BALL BEARING                    |
| 15     | F03-2201 | LS BEARING RING                    |
| 16     | M16-7501 | SPOOL ASSY (16 TO 19)              |
| 20     | M16-7101 | FRAME                              |
| 21     | M04-9902 | FRONT COVER                        |
| 22     | H53-1511 | FRONT COVER SCREW                  |
| 23     | M04-9501 | CLUTCH LEVER                       |
| 24     | J93-2501 | CLUTCH LEVER PLATE ( R )           |
| 25     | J93-2601 | CLUTCH LEVER PLATE ( L )           |
| 26     | M05-0001 | OSCILLATING POST                   |
| 27     | H70-4101 | OSCILLATING POST RETAINER          |
| 28     | H91-0601 | CLUTCH CAM PLATE PIN SPRING COLLAR |
| 29     | H92-8801 | CLUTCH CAM PLATE PIN SPRING        |
| 30     | J05-5201 | CLUTCH CAM PLATE PIN               |
| 31     | G15-6803 | CLUTCH CAM BALL BEARING            |
| 32     | J94-6501 | CLUTCH CAM BEARING COLLAR          |
| 33     | J93-3001 | KICK LEVER PLATE ( A )             |
| 34     | H29-4101 | KICK LEVER PLATE ( A ) SCREW       |
| 35     | H45-0001 | KICK LEVER SPRING                  |
| 36     | J93-3201 | KICK LEVER                         |
| 37     | M05-1801 | CLUTCH CAM                         |
| 38     | J93-2901 | CLUTCH CAM PLATE                   |
| 39     | B03-2904 | CLUTCH CAM SCREW                   |
| 40     | M10-5701 | CLUTCH PLATE                       |
| 41     | J97-7701 | CLUTCH SPRING                      |
| 42     | M18-4102 | PINION GEAR                        |
| 43     | H16-0801 | BEARING RETAINER(B)                |
| 44     | G46-7101 | PINION BALL BEARING                |
| 45     | J95-3001 | PINION BEARING COLLAR              |
| 46     | M16-6806 | RIGHT SIDE PLATE                   |
| 47     | B05-5201 | ZERO ADJUST KNOB RING              |
| 48     | J69-2001 | ZERO ADJUST WASHER (A)             |
| 49     | B17-5503 | ZERO ADJUST WASHER (B)             |
| 50     | J93-2303 | ZERO ADJUST KNOB                   |
| 51     | G04-0830 | RIGHT SIDE PLATE SCREW(A)          |
| 52     | G94-5819 | RIGHT SIDE PLATE SCREW(B)          |
| 53     | G04-0832 | RIGHT SIDE PLATE SCREW(C)          |
| 54     | 320-5901 | WORM SHAFT RETAINER(A)             |
| 55     | B41-1702 | WORM SHAFT WASHER(0.1MM)           |
| 56     | J97-3801 | LEVEL WIND                         |
| 57     | 121-4212 | PAWL                               |
| 58     | 373-1303 | PAWL WASHER                        |
| 59     | F40-2801 | PAWL HOLDER NUT                    |
| 60     | M04-9801 | WORM SHIELD                        |

| Key No | Part No  | Description                |
|--------|----------|----------------------------|
| 61     | M04-9701 | WORM SHAFT                 |
| 62     | G46-9001 | WORM SHAFT BALL BEARING    |
| 63     | J93-4201 | WORM SHAFT GEAR            |
| 65     | G09-9801 | GEAR SHAFT WASHER(0.1MM)   |
| 66     | 320-8002 | GEAR SHAFT RETAINER        |
| 67     | J93-3401 | GEAR SHAFT COLLAR          |
| 68     | M04-0001 | GEAR SHAFT PLATE           |
| 69     | G80-3505 | GEAR SHAFT PLATE SCREW     |
| 70     | J93-3501 | DRIVE SHAFT GEAR           |
| 71     | J93-3301 | DRIVE SHAFT                |
| 72     | J93-4401 | RATCHET                    |
| 73     | H66-1101 | DRIVE GEAR WASHER(A)       |
| 74     | H35-9001 | DRIVE GEAR WASHER(B)       |
| 75     | M12-3602 | DRIVE GEAR                 |
| 76     | J93-4701 | DRAG WASHER                |
| 77     | J93-4801 | DRAG DISC WASHER           |
| 78     | J93-4901 | DRAG LIP WASHER            |
| 79     | J97-4301 | DRAG WASHER(B)             |
| 80     | J93-5001 | DRAG DISC WASHER(B)        |
| 81     | J37-7801 | CLUTCH RING                |
| 82     | G81-9801 | ONEWAY CLUTCH              |
| 83     | G43-1002 | HANDLE BALL BEARING        |
| 84     | B55-3801 | HANDLE BALL BEARING WASHER |
| 85     | E70-9201 | DRAG HOLDER                |
| 86     | E71-5601 | DRAG HOLDER LEAF SPRING    |
| 87     | 150-8901 | DRAG SPRING WASHER         |
| 88     | H92-9501 | STAR DRAG WASHER           |
| 89     | J93-5101 | DRAG NUT                   |
| 90     | J01-1901 | DRAG NUT SPRING            |
| 91     | J97-5002 | STAR DRAG                  |
| 92     | J10-1302 | HANDLE WAHSER              |
| 93     | M16-7801 | HANDLE ASSY                |
| 94     | J09-0311 | HANDLE NUT                 |
| 95     | M09-6501 | HANDLE LOCK PLATE          |
| 96     | H25-7004 | HANDLE LOCK PLATE SCREW    |
| 97     | J94-6701 | STOPPER PIN                |
| 98     | H27-0401 | STOPPER                    |
| 99     | B55-3802 | HANDLE BEARING WASHER      |

### LX-TW400P-P Special Parts

| Key No | Part No  | Description      |
|--------|----------|------------------|
| 42     | M21-9801 | PINION GEAR      |
| 46     | M16-6807 | RIGHT SIDE PLATE |
| 75     | M12-3802 | DRIVE GEAR       |

### LX-TW400H-P Special Parts

| Key No | Part No  | Description      |
|--------|----------|------------------|
| 42     | M18-4002 | PINION GEAR      |
| 46     | M16-6804 | RIGHT SIDE PLATE |
| 75     | M12-3202 | DRIVE GEAR       |

### LX-TW400XH-P Special Parts

| Key No | Part No  | Description      |
|--------|----------|------------------|
| 42     | M18-4202 | PINION GEAR      |
| 46     | M16-6805 | RIGHT SIDE PLATE |
| 75     | M12-3402 | DRIVE GEAR       |