


DAIWA

BAITCASTING REEL

LX300_H_H-P

*Please order by parts number, not key number.



Key No	Part No	Description
1	702-4450	Frame
2	410-4450	Spacer(A)
3	410-4460	Spacer (B)
4	090-0340	Clutch lever
5	490-1150	Line guide
6	400-2540	Line guide
7	540-3980	Washer
8	380-7160	Line pawl
9	270-0810	Level wind
10	470-1960	Worm shaft
11	240-2210	Worm shaft
12	200-0530	Gear
13	540-6060	Worm shaft
14	540-3930	Washer
15	200-0530	Worm shaft
16	460-4980	Long screw
17	558-1960	Frame plate
18	400-2570	Pin
19	540-7250	Washer
20	140-2030	Ball bearing
21	200-0580	Drive gear
22	410-4491	Plate
23	460-5370	Screw
24	460-5290	Screw
25	540-6600	Washer
26	240-2200	Oscillation
27	470-2511	Drive shaft
28	510-5310	Spring
29	400-2720	Pin
30	410-4470	Plate
31	460-5370	Screw
32	510-6610	Kick lever
33	330-3180	Kick lever
34	170-1510	Clutch cam
35	410-4480	Plate
36	460-1830	Screw
37	460-8180	Screw
38	410-4520	Plate
39	460-4870	Screw
40	080-0070	Yoke
41	510-6620	Yoke spring
42	260-2800	Pinion gear
43	530-0860	Anti-reverse
44	240-4040	Anti-reverse
45	540-9830	Spacer (C)
46	250-2260	Drive gear
47	540-6890	Drag
48	540-8010	Washer
49	540-8030	Key washer
50	540-8080	Drag
51	540-8020	Top washer
52	150-2190	Gear shaft
53	140-1810	Roller

Key No	Part No	Description
54	702-4460	Right side plate
55	460-0480	Screw
56	460-1131	Screw
57	430-1110	O-ring
58	150-3240	Bushing
59	430-1061	Bearing retainer
60	540-6850	Spacer(D)
61	540-4340	Spacer(E)
62	38A-3471	Cast control cap
63	140-2040	Ball bearing
64	540-1480	Spacing washer
65	510-5370	Plate
66	540-6391	Drag spring washer
67	540-9021	Washer
68	380-3211	Nut
69	510-6130	Spring
70	320-1480	Star drag
71	540-9271	Washer
72	702-4470	Handle assembly
73	380-1810	Handle nut
74	358-0310	Handle nut plate
75	460-1290	Screw
76.-79.	702-2730	Spool assembly
80	460-5610	Set plate screw
81	510-4450	Set plate spring
82	550-1980	Brake adjusting
83	510-5180	Brake click spring
84	200-0530	Brake dial
85	540-5380	Washer
86	702-4490	Left side plate
87	410-1911	Brake dial
88	701-4550	Set plate
89	460-5460	Screw
90	540-7190	Washer
91	140-3310	Ball bearing
92	430-0440	Bearing retainer
93	702-3700	Magnet holder
94	430-0971	Magnet holder ret.
95	540-6340	Washer

LX300H Special Parts

Key No	Part No	Description
42	260-2820	Pinion gear
46	250-2280	Drive gear
54	702-4500	Right side plate

LX300H-P Special Parts

Key No	Part No	Description
42	260-2820	Pinion gear
46	250-2280	Drive gear
54	702-4510	Right side plate
72	702-4520	Handle assembly