


TATU200PL

BAITCASTING REEL

TATU200PL

*Please order by parts number, not key number.



Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW
2	E16-7101	BRAKE DIAL SPRING
3	M67-3702	BRAKE DIAL
4	B33-9801	BRAKE DIAL RETAINER (A)
5	F63-7701	BRAKE DIAL COLLAR
6	J88-6201	BRAKE DIAL LEAF SPRING
7	M70-7601	RIGHT SIDE PLATE
8	J84-3301	BRAKE DIAL RETAINER (B)
9	G93-9301	BRAKE DIAL RETAINER SCREW
10	M67-3801	MAGNET HOLDER
11	375-7404	RS SPOOL ADJUST WASHER (A)
12	375-7411	RS SPOOL ADJUST WASHER (B)
13	G18-5101	RS SPOOL ADJUST WASHER (C)
14	G51-1503	SPOOL BALL BEARING
15	F03-2201	SPOOL BEARING RETAINER
16	M66-9301	SPOOL ASSEMBLY (17-20)
17	H77-0601	SPOOL O RING (A)
19	J33-9401	SPOOL PIN
20	M42-6701	SPOOL O RING (B)
21	M70-6601	FRAME ASSY(95-98)
22	M67-3401	FRONT COVER
23	H53-1508	FRONT COVER SCREW
24	M70-7001	CLUTCH LEVER
25	H00-5701	CLUTCH LEVER SCREW
26	M67-1001	CLUTCH LEVER PLATE (R)
27	M67-1101	CLUTCH LEVER PLATE (L)
28	M67-4001	STABILIZER BAR
29	B86-1705	PINION BALL BEARING (A)
30	M33-5101	CLUTCH CAM PLATE
31	M83-9701	CLUTCH TRIP LEVER SPRING
32	M33-5501	CLUTCH TRIP LEVER
33	M71-8701	CLUTCH CAM ASSY
35	H15-9201	CLUTCH BAR SCREW WASHER(A)
36	F54-2701	CLUTCH BAR SCREW WASHER(B)
37	B36-0406	CLUTCH BAR SCREW
38	M04-4101	CLUTCH CAM PLATE
39	M70-7201	CLUTCH PLATE
40	B03-2904	CLUTCH CAM PLATE SCREW
41	M67-2601	CLUTCH SPRING
42	Z02-8421	PINION DRIVE GEAR SET
43	M84-1001	LEFT SIDE PLATE
44	G43-1102	PINION BALL BEARING (B)
45	E21-9701	PINION BEARING RETAINER
46	B05-5201	MECHANICAL BRAKE O RING
47	J21-3101	MECHANICAL BRAKE WASHER (A)
48	B17-5503	MECHANICAL BRAKE WASHER (B)
49	J69-2502	ZERO ADJUSTER KNOB
50	B55-7622	LEFT SIDE PLATE SCREW (A)
51	B55-7620	LEFT SIDE PLATE SCREW (B)

Key No	Part No	Description
52	320-5901	WORM SHAFT RETAINER (A)
53	B41-1702	WORM SHAFT WASHER
54	G72-0001	WORM SHAFT BUSHING (A)
55	M68-1001	LEVELWIND
56	J74-0201	LEVELWIND PAWL PIN
57	M45-4101	LEVELWIND PAWL
58	M16-1301	LEVELWIND PAWL WASHER(0.1MM)
59	G25-2202	LEVELWIND PAWL O RING
60	M70-7401	WORM SHIELD
61	J24-3601	WORM SHAFT
62	G72-0001	WORM SHAFT BUSHING (A)
63	M67-2901	WORM SHAFT GEAR
64	B33-9801	BRAKE DIAL RETAINER (A)
65	G09-9801	DRIVE SHAFT WASHER(0.1MM)
66	320-8002	DRIVE SHAFT RETAINER
67	G46-6202	DRIVE BALL BEARING (A)
68	M45-4001	DRIVE SHAFT PLATE
69	G29-7002	DRIVE SHAFT PLATE SCREW
70	J28-1001	WORM GEAR
71	M67-1602	DRIVE SHAFT
72	M67-3101	RATCHET
73	J08-5101	DRIVE GEAR WASHER
74	Z02-8421	PINION DRIVE GEAR SET
75	H45-2602	DRAG WASHER
76	H91-3201	KEY WASHER
77	J90-9901	CLUTCH RING
78	G81-9801	ONEWAY CLUTCH
79	B55-3803	ONEWAY CLUTCH WASHER(A)
80	B55-3804	ONEWAY CLUTCH WASHER(B)
81	B86-1705	PINION BALL BEARING (A)
82	B55-3804	ONEWAY CLUTCH WASHER(B)
83	F02-8203	DRAG HOLDER
84	F03-2401	DRAG HOLDER LEAF SPRING
85	150-8901	DRAG SPRING WASHER
86	H92-9501	STAR DRAG WASHER
87	H91-2002	STAR DRAG NUT
88	J01-1901	STAR DRAG SPRING
89	H91-1901	STAR DRAG
90	F57-6601	HANDLE WASHER
91	M67-1901	HANDLE ASSEMBLY
92	H72-3702	HANDLE NUT
93	J21-3503	HANDLE LOCK PLATE
94	G04-0835	HANDLE LOCK PLATE SCREW
95	M70-6701	FRAME
96	M73-1601	FRONT COVER
97	M04-7801	FRONT COVER SCREW COLLAR
98	H53-1509	FRONT COVER SCREW
99	M04-7801	FRONT COVER COLLAR