


TATUSV100L_HL_XHL

BAITCASTING REEL

TATUSV100L_HL_XHL

*Please order by parts number, not key number.



Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW
2	E16-7101	BRAKE DIAL SPRING
3	J69-4910	BRAKE DIAL
4	B33-9801	BRAKE DIAL RETAINER (A)
5	F63-7701	BRAKE DIAL COLLAR
6	J88-6201	BRAKE DIAL LEAF SPRING
7	M63-8301	RIGHT SIDE PLATE
8	J84-3301	BRAKE DIAL RETAINER (B)
9	G93-9301	BRAKE DIAL RETAINER SCREW
10	J69-5001	MAGNET HOLDER
11	375-7404	RS SPOOL ADJUST WASHER (A)
12	375-7411	RS SPOOL ADJUST WASHER (B)
13	G18-5101	RS SPOOL ADJUST WASHER (C)
14	G51-1503	SPOOL BALL BEARING
15	F03-2201	SPOOL BEARING RETAINER
16	Z02-7784	SPOOL ASSEMBLY (17 26)
27	M46-7302	FRAME
28	M45-4403	FRONT COVER
29	H53-1508	FRONT COVER SCREW
30	M45-3801	CLUTCH LEVER
31	M45-3401	CLUTCH LEVER PLATE (L)
32	M45-3301	CLUTCH LEVER PLATE (R)
33	M04-1101	STABILIZER BAR
34	B86-1705	PINION BALL BEARING (A)
35	M46-7601	CLUTCH CAM PLATE (A)
36	M06-0601	CLUTCH TRIP LEVER SPRING
37	J63-8601	CLUTCH TRIP LEVER
38	M46-7401	CLUTCH CAM
39	M46-7501	CLUTCH BAR
40	M07-0001	CLUTCH BAR SCREW WASHER
41	B36-0406	CLUTCH BAR SCREW
42	H65-9101	CLUTCH CAM PLATE (B)
43	M15-7501	YOKE
44	B03-2904	CLUTCH CAM PLATE SCREW
45	J31-3901	YOKE SPRING
46	Z02-7414	PINION DRIVE GEAR SET
47	M63-8201	LEFT SIDE PLATE
48	G43-1102	PINION BALL BEARING (B)
49	E21-9701	PINION BEARING RETAINER
50	B05-5201	MECHANICAL BRAKE O RING
51	J21-3101	MECHANICAL BRAKE WASHER (A)
52	B17-5503	MECHANICAL BRAKE WASHER (B)
53	J69-2502	ZERO ADJUSTER KNOB
54	G04-0831	LEFT SIDE PLATE SCREW (A)
55	G04-0830	LEFT SIDE PLATE SCREW (B)
56	320-5901	WORM SHAFT RETAINER (A)
57	B41-1702	WORM SHAFT WASHER
58	G72-0001	WORM SHAFT BUSHING (A)
59	M05-4201	LEVELWIND
60	J74-0201	LINE GUIDE PAWL PIN

Key No	Part No	Description
61	M45-4101	LINE GUIDE PAWL
62	M16-1301	LINE GUIDE PAWL WASHER
63	G25-2202	LINE GUIDE PAWL O RING
64	M04-8901	WORM SHIELD
65	J24-3601	WORM SHAFT
66	G72-0001	WORM SHAFT BUSHING (B)
67	M04-8801	WORM SHAFT GEAR
68	B33-9801	WORM SHAFT GEAR RETAINER
69	G09-9801	DRIVE SHAFT WASHER
70	320-8002	DRIVE SHAFT RETAINER
71	G46-6202	DRIVE SHAFT BALL BEARING (A)
72	M45-4001	DRIVE SHAFT PLATE
73	G29-7002	DRIVE SHAFT PLATE SCREW
74	M04-8601	WORM GEAR
75	M45-3902	DRIVE SHAFT
76	H66-0901	RATCHET
77	J08-5101	DRIVE GEAR WASHER
78	Z02-7414	PINION DRIVE GEAR SET
79	H35-9002	DRAG WASHER
80	J69-4401	KEY WASHER
81	J37-7801	CLUTCH RING
82	B55-3805	ONEWAY CLUTCH WASHER
83	J54-0401	ONEWAY CLUTCH
84	B86-1705	DRIVE BALL BEARING (B)
85	B55-3801	DRIVE BEARING WASHER
86	F02-8203	CLICK SPRING HOLDER
87	F03-2401	CLICK LEAF SPRING
88	150-8901	DRAG SPRING WASHER
89	H92-9501	STAR DRAG WASHER
90	H91-2002	STAR DRAG METAL
91	J01-1901	STAR DRAG SPRING
92	H91-1901	STAR DRAG
93	F57-6601	HANDLE WASHER
94	J91-5901	HANDLE ASSEMBLY
95	G79-3310	HANDLE NUT
96	J62-5401	HANDLE LOCK PLATE
97	G83-5505	HANDLE LOCK PLATE SCREW
98	H77-0601	SPOOL HOLDER O RING
99	M04-7801	FRONT COVER COLLAR

TATUSV100HL Special Parts

Key No	Part No	Description
46	Z02-7412	PINION DRIVE GEAR SET
47	M63-8501	LEFT SIDE PLATE

TATUSV100XHL Special Parts

Key No	Part No	Description
46	Z02-7256	PINION DRIVE GEAR SET
47	M63-8201	LEFT SIDE PLATE