


BAMQLT2500_3000D-XH_4000D-CXH

SPINNING REEL

BAMQLT2500_3000D-XH_4000D-CXH

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q73-4901	DRAG KNOB
2	Q34-6101	DRAG RING
3	Q62-1901	DRAG DISC WASHER
4	J67-8801	DRAG WASHER(3pc)
5	Q73-2001	DRAG LIP WASHER
6	J54-9001	DISC WASHER
7	-----	
8	G21-2503	SPOOL BALL BEARING
9	Q34-5601	LINE STOPPER PLATE
10	Q34-5501	LINE STOPPER
11	Q34-5701	LINE STOPPER SPRING
12	R04-4401	SPOOL ASSY(2-12)
13	J54-6301	SPOOL WASHER(0.5mm)
14	J55-8201	SPOOL MEATAL SCREW
15	J54-9501	SPOOL MEATAL
16	E30-6801	SPOOL MEATAL BALL BEARING
17	J60-2201	SPOOL MEATAL WASHER(0.5mm)
18	Q79-8201	CLICK HOLDER
19	Q79-7701	CLICK LEAF SPRING
20	H98-6901	ROTOR NUT PACKING
21	Q73-5801	ROTOR NUT
22	Q85-8101	ROTOR NUT COLLAR
23	372-7601	ROTOR NUT WASHER(0.1mm)
24	H02-2701	ROTOR NUT SCREW
25	Q80-8218	ROTOR
26	Q81-0801	KICK LEVER SPRING
27	M19-4601	KICK LEVER WASHER
28	Q80-8301	KICK LEVER
29	Q95-7301	KICK LEVER SCREW
30	Q81-0901	ARM LEVER SHAFT
31	Q80-8501	ARM LEVER SHAFT COLLAR
32	Q81-1701	ARM LEVER SPRING
33	Q80-8601	ARM LEVER SHAFT HOLDER
34	Q81-2001	ARM LEVER SHAFT HOLDER SPRING
35	Q80-8701	ARM LEVER SHAFT HOLDER PIN
36	Q81-2201	ARM LEVER COVER SCREW
37	Q80-9201	ARM LEVER COVER
38	Q88-0604	ARM LEVER
39	Q80-9101	ARM LEVER COLLAR
40	B33-9801	ARM LEVER RETAINER
41	F88-9105	ROLLER WASHER(A)(0.5mm)
42	J73-6201	ROLLER PACKING
43	Q99-4101	ROLLER COLLAR(A)
44	J25-6702	ROLLER BALL BEARING
45	Q89-6901	ROLLER COLLAR(B)
46	Q88-1101	LINE ROLLER
47	Q99-4201	ROLLER COLLAR(C)
48	Q89-6601	ROLLER COLLAR(D)
49	375-4101	ROLLER WASHER(B)(0.1mm)
50	Q88-0701	BAIL ASSY
51	375-4105	ARM LEVER SCREW WASHER
52	M47-5401	ARM LEVER SCREW
53	Q41-6203	BAIL HOLDER SCREW WASHER(A)
54	F03-7400	BAIL HOLDER SCREW WASHER(B)
55	Q81-2301	BAIL HOLDER SCREW
56	H62-4901	MAG SEALED PLATE SCREW
57	375-4102	MAG SEALED PLATE SCREW WASHER(0.3mm)
58	J67-5201	MAG SEALED PLATE
59	J35-4801	MAG SEALED O RING
60	Q60-9601	MAG SEALED CAP
61	J63-9902	ONE WAY CLUTCH WASHER(0.1mm)
62	J38-8401	ONE WAY CLUTCH
63	J53-6102	CLUTCH RING
64	Q60-9001	CLUTCH RING COLLAR
65	Q19-5701	PINION BEARING PLATE SCREW
66	Q62-1201	PINION BEARING PLATE
67	G46-7302	PINION BALL BEARING(A)
68	375-8502	PINION BEARING WASHER(A)(0.1mm)
69	Z70-0629	PINION DRIVE GEAR SET
70	H93-1701	PINION BALL BEARING(B) WASHER

Key No	Part No	Description
71	G46-6202	PINION BALL BEARING(B)
72	G46-6103	PINION COLLAR WASHER(0.1mm)
73	J38-7701	PINION COLLAR
74	Q62-1301	REAR CAP SCREW(A)
75	R04-4301	BODY ASSY
76	Q60-9401	REAR CAP PACKING
77	Q98-5701	REAR CAP
78	Q62-1101	REAR CAP SCREW(B)
79	Q60-9201	OSCILLATING POST COLLAR
80	Q60-9301	OSCILLATING POST
81	Q94-9301	MAIN SHAFT
82	J64-4701	OSCILLATING GEAR WASHER
83	Q60-8101	OSCILLATING GEAR
84	H77-0601	OSCILLATING GEAR O RING
85	H12-9201	OSCILLATING GEAR BEARING WASHER(0.05mm)
86	G46-9005	OSCILLATING GEAR BALL BEARING
87	Q12-6101	OSCILLATING GEAR SCREW
88	G67-0501	DRIVE GEAR O RING
89	375-8511	DRIVE WASHER(0.02mm)
90	G52-2706	DRIVE BALL BEARING(A)
91	J55-3001	ENGINE PLATE O RING
92	Q60-9105	ENGINE PLATE
93	J13-0201	HANDLE PACKING
94	R04-4601	HANDLE ASSY
95	G46-7302	DRIVE BALL BEARING(B)
96	Q60-7901	SET PLATE
97	Q60-8001	SET PLATE O RING
98	G47-2401	DRIVE BEARING(B) RING
99	H61-7001	DRIVE BEARING(B) O RING
100	Q60-8903	DRIVE BEARING(B) COVER
101	G16-2401	HANDLE CAP O RING
102	Q34-5101	HANDLE CAP

BAMQLT3000D-XH Special Parts

Key No	Part No	Description
12	R04-4901	SPOOL ASSY(2-12)
25	Q81-6815	ROTOR
28	Q81-6901	KICK LEVER
37	Q81-7101	ARM LEVER COVER
50	R02-3301	BAIL ASSY
69	Z70-0727	PINION DRIVE GEAR SET
75	R04-4801	BODY ASSY
76	Q66-7101	REAR CAP PACKING
77	R00-6601	REAR CAP
80	Q12-6305	OSCILLATING POST
81	Q66-6201	MAIN SHAFT
83	Q66-6101	OSCILLATING GEAR
84	G46-6001	OSCILLATING GEAR O RING
91	J57-1501	ENGINE PLATE O RING
92	Q66-6909	ENGINE PLATE
94	R04-9101	HANDLE ASSY
96	Q66-5901	SET PLATE
97	Q66-6001	SET PLATE O RING

BAMQLT4000D-CXH Special Parts

Key No	Part No	Description
1	Q73-5701	DRAG KNOB
9	Q35-3501	LINE STOPPER PLATE
12	R04-6401	SPOOL ASSY(2-12)
25	Q83-2612	ROTOR
28	Q83-2801	KICK LEVER
30	Q83-3001	ARM LEVER SHAFT
32	Q83-3201	ARM LEVER SPRING
33	Q83-3301	ARM LEVER SHAFT HOLDER
37	Q83-3701	ARM LEVER COVER
38	R00-6702	ARM LEVER
50	R00-6801	BAIL ASSY
81	Q70-3801	MAIN SHAFT
83	Q70-3701	OSCILLATING GEAR