


EXELTA

SPINNING REEL

EXELT4000_5000D-C

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q35-2901	DRAG KNOB
2	Q34-6101	DRAG WASHER RETAINER
3	Q62-1901	KEY WASHER
4	Q91-7601	ATD DRAG WASHER (3PCS/PK)
5	Q34-6001	EARED WASHER
6	Q35-3501	LINE STOPPER PLATE
7	Q34-5501	LINE STOPPER
8	Q34-5701	LINE STOPPER SPRING
9	Q95-2001	SPOOL ASSY
10	E39-8003	SPOOL WASHER (A)
11	Q34-8502	SPOOL WASHER (B)
12	Q79-7701	CLICK LEAF SPRING
13	Q79-8201	CLICK SPRING HOLDER
14	Q34-4001	SPOOL WASHER (C)
15	H98-6901	ROTOR NUT PACKING
16	Q73-5801	ROTOR NUT
17	Q85-8101	ROTOR NUT COLLAR
18	372-7602	ROTOR NUT WASHER
19	H02-2701	ROTOR NUT SCREW
20	Q95-1901	ROTOR
21	Q81-0801	BAIL TRIP LEVER SPRING
22	M19-4601	BAIL TRIP LEVER WASHER
23	Q83-2801	BAIL TRIP LEVER
24	Q95-7301	BAIL TRIP LEVER SCREW
25	Q83-3001	BAIL SPRING SHAFT
26	Q80-8501	BAIL SPRING SHAFT COLLAR
27	Q83-3201	BAIL SPRING
28	Q83-3301	BAIL SPRING HOLDER
29	Q81-2001	BAIL CLICK SPRING
30	Q80-8701	BAIL CLICK PIN
31	Q81-2201	BAIL SPRING COVER SCREW
32	Q83-3701	BAIL SPRING COVER
33	Q83-3607	BAIL ARM
34	Q80-9101	BAIL ARM COLLAR
35	B33-9801	BAIL ARM RETAINER
36	Q81-0001	ROLLER COLLAR (A)
37	Q80-9901	ROLLER COLLAR (B)
38	Q80-9803	LINE ROLLER
39	Q80-9901	ROLLER COLLAR (C)
40	M39-8901	ROLLER WASHER
41	Q86-5701	BAIL
42	Q80-9701	ROLLER SCREW COLLAR
43	373-1306	ROLLER SCREW WASHER
44	Q81-0201	ROLLER SCREW
45	Q41-6203	BAIL HOLDER WASHER
46	Q81-2301	BAIL HOLDER SCREW

Key No	Part No	Description
48	G83-7101	SHIELD COVER SCREW
49	Q13-9401	SHIELD COVER
50	J38-8401	ONEWAY CLUTCH
51	J00-1403	CLUTCH RING
52	Q12-6201	PINION BEARING PLATE SCREW
53	Q19-5601	PINION BEARING PLATE
54	G46-7302	PINION BALL BEARING (A)
55	375-8502	PINION BEARING WASHER (A)
56	Z70-0923	PINION DRIVE GEAR SET
57	H93-1701	PINION SPRING WASHER
58	G46-6202	PINION BALL BEARING (B)
59	G46-6103	PINION BEARING WASHER (B)
60	J38-7701	PINION COLLAR
61	Q95-1401	BODY
62	Q86-4601	MAIN SHAFT
63	Q85-3002	OSCILLATING POST
64	Q84-5901	ANTI REVERSE CAM SPRING
65	Q85-2701	ANTI REVERSE CAM
66	Q85-2601	ANTI REVERSE LEVER
67	Q86-5101	REAR COVER
68	Q34-2901	REAR COVER SCREW
69	H59-5701	OSCILLATING GEAR WASHER
70	Q35-0901	OSCILLATING GEAR
71	G46-6001	OSCILLATING GEAR O RING
72	H12-9201	OSCILLATING GEAR BEARING WASHER
73	G46-9005	OSCILLATING GEAR BALL BEARING
74	Q12-6101	OSCILLATING GEAR SCREW
75	G67-0501	DRIVE GEAR O RING
76	375-8502	DRIVE WASHER
77	G46-7302	DRIVE BALL BEARING (A)
78	Q95-1501	SIDE COVER
79	Q34-2601	SIDE COVER SCREW (A)
80	Q34-2701	SIDE COVER SCREW (B)
81	Q85-2401	SIDE COVER SCREW (C)
82	Q69-1201	HANDLE ASSY
83	G52-2706	DRIVE BALL BEARING (B)
84	G47-2401	DRIVE BEARING RETAINER
85	G16-2401	HANDLE CAP O RING
86	Q34-5101	HANDLE CAP

EXELT5000D-C Special Parts

Key No	Part No	Description
8	Q34-5701	LINE STOPPER SPRING
39	Q80-9901	ROLLER COLLAR (C)
43	373-1306	ROLLER SCREW WASHER