


DAIWA

SPINNING REEL

PRXMQLT3000D-C_4000D-C

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q73-4901	DRAG KNOB
2	Q34-6101	DRAG RING
3	Q62-1901	DRAG DISC WASHER(A)
4	Q91-7601	ATD DRAG WASHER(3pc)
5	Q73-2001	DRAG LIP WASHER
6	J54-9001	DRAG DISC WASHER(B)
7	-----	-----
8	Q62-1001	SPOOL COLLAR
9	Q34-5601	LINE STOPPER PLATE
10	Q34-5501	LINE STOPPER
11	Q34-5701	LINE STOPPER SPRING
12	R06-9701	SPOOL ASSY(2to11)
13	J54-6301	SPOOL WASHER(0.5mm)
14	J55-8201	SPOOL METAL SCREW
15	J54-9501	SPOOL METAL
16	H62-4801	SPOOL METAL COLLAR
17	J60-2201	SPOOL METAL WASHER(0.5mm)
18	Q79-8201	CLICK HOLDER
19	Q79-7701	CLICK LEAF SPRING
20	H98-6901	ROTOR NUT PACKING
21	Q73-5801	ROTOR NUT
22	Q85-8101	ROTOR NUT COLLAR
23	372-7602	ROTOR NUT WASHER(0.2mm)
24	H02-2701	ROTOR NUT SCREW
25	Q81-6817	ROTOR
26	Q81-0801	KICK LEVER SPRING
27	M19-4601	KICK LEVER WASHER
28	Q81-6901	KICK LEVER
29	Q95-7301	KICK LEVER SCREW
30	Q81-0901	ARM LEVER SHAFT
31	Q80-8501	ARM LEVER SHAFT COLLAR
32	Q81-1701	ARM LEVER SPRING
33	Q80-8601	ARM LEVER SHAFT HOLDER
34	Q81-2001	ARM LEVER SHAFT HOLDER SPRING
35	Q80-8701	ARM LEVER SHAFT HOLDER PIN
36	Q81-2201	ARM LEVER COVER SCREW
37	Q81-7101	ARM LEVER COVER
38	Q88-0607	ARM LEVER
39	Q80-9101	ARM LEVER COLLAR
40	B33-9801	ARM LEVER RETAINER
41	F88-9105	ROLLER WASHER(A)(0.5mm)
42	J73-6201	ROLLER PACKING
43	Q99-4101	ROLLER COLLAR(A)
44	J25-6702	ROLLER BALL BEARING
45	Q89-6901	ROLLER COLLAR(B)
46	Q88-1101	LINE ROLLER
47	Q99-4201	ROLLER COLLAR(C)
48	Q89-6601	ROLLER COLLAR(D)
49	375-4101	ROLLER WASHER(B)(0.1mm)
50	R02-3301	BAIL ASSY
51	375-4105	ARM LEVER SCREW WASHER
52	M47-5401	ARM LEVER SCREW
53	Q41-6203	BAIL HOLDER SCREW WASHER(A)
54	F03-7404	BAIL HOLDER SCREW WASHER(B)(0.1mm)
55	Q81-2301	BAIL HOLDER SCREW
56	H62-4901	SHIELD CAP SCREW
57	J67-5301	SHIELD CAP PLATE
58	Q60-9601	SHIELD CAP
59	J63-9902	ONE WAY CLUTCH WASHER(0.1mm)
60	J38-8401	ONE WAY CLUTCH
61	J53-6102	CLUTCH RING
62	Q60-9001	CLUTCH RING COLLAR
63	Q19-5701	PINION BEARING PLATE SCREW
64	Q62-1201	PINION BEARING PLATE

Key No	Part No	Description
65	G46-7302	PINION BALL BEARING(A)
66	375-8502	PINION BALL BEARING(A) WASHER(0.1mm)
67	Z70-0712	PINION DRIVE GEAR SET
68	H93-1701	PINION BALL BEARING(B) WASHER
69	G46-6202	PINION BALL BEARING(B)
70	G46-6103	PINION COLLAR WASHER(0.1mm)
71	J38-7701	PINION COLLAR
72	Q62-1301	REAR CAP SCREW(A)
73	R06-9601	BODY
74	Q60-9401	REAR CAP PACKING
75	Q98-5701	REAR CAP
76	Q62-1101	REAR CAP SCREW(B)
77	Q60-9201	OSCILLATING POST COLLAR
78	Q60-9301	OSCILLATING POST
79	Q70-2601	MAIN SHAFT
80	J64-4701	OSCILLATING GEAR WASHER
81	Q70-2501	OSCILLATING GEAR
82	H77-0601	OSCILLATING GEAR O RING
83	H12-9201	OSCILLATING GEAR BEARING WASHER(0.05mm)
84	G46-9005	OSCILLATING GEAR BALL BEARING
85	Q12-6101	OSCILLATING GEAR SCREW
86	G67-0501	DRIVE GEAR O RING
87	375-8511	DRIVE WASHER(0.2mm)
88	G46-7302	DRIVE BALL BEARING(A)
89	J55-3001	ENGINE PLATE O RING
90	Q98-5603	ENGINE PLATE
91	R06-9901	HANDLE ASSY
92	G52-2706	DRIVE BALL BEARING(B)
93	Q60-8001	SET PLATE O RING
94	Q60-7901	SET PLATE
95	G47-2401	DRIVE BEARING(B) RING
96	H61-7001	DRIVE BEARING(B) O RING
97	Q98-5502	DRIVE BEARING(B) COVER
98	G16-2401	HANDLE CAP O RING
99	Q34-5101	HANDLE CAP

PRXMQLT4000D-C Special Parts

Key No	Part No	Description
1	Q73-5701	DRAG KNOB
9	Q35-3501	LINE STOPPER PLATE
12	R07-0601	SPOOL ASSY(2to11)
25	R07-2401	ROTOR
28	Q83-2801	KICK LEVER
30	Q83-3001	ARM LEVER SHAFT
32	Q83-3201	ARM LEVER SPRING
33	Q83-3301	ARM LEVER SHAFT HOLDER
37	Q83-3701	ARM LEVER COVER
38	R00-6704	ARM LEVER
50	R00-6801	BAIL ASSY
67	Z70-0685	PINION DRIVE GEAR SET
69	G46-6205	PINION BALL BEARING(B)
73	R07-0001	BODY
74	Q66-7101	REAR CAP PACKING
75	R00-6601	REAR CAP
78	Q12-6305	OSCILLATING POST
79	Q70-3801	MAIN SHAFT
81	Q70-3701	OSCILLATING GEAR
82	G46-6001	OSCILLATING GEAR O RING
89	J57-1501	ENGINE PLATE O RING
90	R00-6503	ENGINE PLATE
91	R07-0301	HANDLE ASSY
93	Q66-6001	SET PLATE O RING
94	Q66-5901	SET PLATE