


DAWA

SPINNING REEL

REVRLT6000

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q83-8801	DRAG KNOB
2	170-4101	DRAG WASHER RETAINER
3	Q73-1901	KEY WASHER
4	Q91-7701	DRAG WASHER
5	Q37-7601	EARED WASHER
26	Q83-8401	SPOOL ASSY
7	F05-0101	SPOOL WASHER (A)
8	Q36-3801	SPOOL WASHER (B)
9	Q79-7701	CLICK LEAF SPRING
10	Q79-8301	CLICK SPRING HOLDER
11	Q37-7501	SPOOL WASHER (C)
12	Q90-6501	ROTOR NUT
13	Q87-5501	ROTOR NUT COLLAR
14	G52-9509	ROTOR NUT WASHER
15	H02-2701	ROTOR NUT SCREW
16	Q83-7203	ROTOR
17	H41-3601	BAIL TRIP LEVER SPRING
18	---	---
19	Q99-4701	BAIL TRIP LEVER
20	H41-7701	BAIL TRIP LEVER SCREW
21	Q96-5001	BAIL SPRING SHAFT
22	Q81-8801	BAIL SPRING SHAFT PLATE
23	Q95-8001	BAIL SPRING
24	Q83-7801	BAIL SPRING HOLDER
25	Q81-2001	BAIL CLICK SPRING
26	Q80-8701	BAIL CLICK PIN
27	Q81-2201	BAIL SPRING COVER SCREW
28	Q83-8001	BAIL SPRING COVER
29	Q83-7901	BAIL ARM
30	Q80-9101	BAIL ARM COLLAR
31	B33-9801	BAIL ARM RETAINER
32	Q81-0001	ROLLER COLLAR (A)
33	Q80-9901	ROLLER COLLAR (B)
34	Q80-9803	LINE ROLLER
35	Q80-9901	ROLLER COLLAR (C)
36	Q81-0101	ROLLER WASHER
37	Q83-8101	BAIL ASSY
38	Q80-9701	ROLLER SCREW COLLAR
39	373-1306	ROLLER SCREW WASHER
40	M39-8901	ROLLER SCREW

Key No	Part No	Description
41	Q41-6203	BAIL HOLDER WASHER
42	Q81-2301	BAIL HOLDER SCREW
43	H64-0301	ROTOR COLLAR
44	G83-7101	SHIELD COVER SCREW
45	Q13-4301	SHIELD COVER
46	J30-9101	ONEWAY CLUTCH
47	J02-1304	CLUTCH RING
48	Q12-6201	PINION BEARING PLATE SCREW
49	J02-0801	PINION BEARING PLATE
50	635-4801	PINION BALL BEARING
51	Q90-6301	PINION GEAR
52	---	---
53	Q83-6801	BODY
54	Q36-2601	MAIN SHAFT
55	Q12-6303	OSCILLATING POST (A)
56	Q11-9103	OSCILLATING POST (B)
57	Q13-3401	ANTI REVERSE CAM
58	H69-7801	ANTI REVERSE CAM SPRING
59	Q11-8001	ANTI REVERSE LEVER
60	Q83-7101	REAR COVER
61	G27-0801	REAR COVER SCREW
62	G64-4201	OSCILLATING GEAR WASHER
63	Q13-3501	OSCILLATING GEAR
64	B85-3101	OSCILLATING GEAR O RING
65	G52-2102	OSCILLATING GEAR BEARING WASHER
66	G46-7108	OSCILLATING GEAR BALL BEARING
67	H46-3401	OSCILLATING GEAR SCREW
68	G64-5301	DRIVE GEAR RING
69	Q40-5103	DRIVE GEAR
70	373-7808	DRIVE WASHER
71	G52-3405	DRIVE BALL BEARING (A)
72	Q83-7001	SIDE COVER
73	G11-5001	SIDE COVER SCREW
74	Q48-2001	HANDLE ASSY
75	B86-1705	DRIVE BALL BEARING (B)
76	G52-5101	DRIVE BEARING RETAINER
77	F72-1202	HANDLE COLLAR
78	160-8401	HANDLE WASHER
79	Q13-6101	HANDLE SCREW
80	F03-7404	BAIL HOLDER SCREW WASHER