


# DAWA

## SPINNING REEL

## RGLT1000D\_2000D-XH-B

\*Please order by parts number, not key number.



| Key No | Part No  | Description              |
|--------|----------|--------------------------|
| 1      | Q37-6801 | DRAG KNOB                |
| 2      | Q34-6101 | DRAG WASHER RETAINER     |
| 3      | Q62-1901 | KEY WASHER               |
| 4      | Q91-7501 | ATD DRAG WASHER (1PC/PK) |
| 5      |          |                          |
| 6      | Q37-6701 | LINE STOPPER PLATE       |
| 7      | Q34-5501 | LINE STOPPER             |
| 8      | Q34-5701 | LINE STOPPER SPRING      |
| 9      | Q95-8301 | SPOOL ASSY               |
| 10     | Q38-2701 | SPOOL BEARING WASHER (A) |
| 11     | E33-2501 | SPOOL BALL BEARING       |
| 12     | B41-1706 | SPOOL BEARING WASHER (B) |
| 13     | Q34-8502 | SPOOL WASHER (A)         |
| 14     | E39-8003 | SPOOL WASHER (B)         |
| 15     | Q79-7701 | CLICK LEAF SPRING        |
| 16     | Q79-8201 | CLICK SPRING HOLDER      |
| 17     | Q34-4001 | SPOOL WASHER (C)         |
| 18     | H98-6901 | ROTOR NUT PACKING        |
| 19     | Q74-8401 | ROTOR NUT                |
| 20     | Q85-8101 | ROTOR NUT COLLAR         |
| 21     | 372-7602 | ROTOR NUT WASHER         |
| 22     | H02-2701 | ROTOR NUT SCREW          |
| 23     | Q82-5310 | ROTOR                    |
| 24     | Q82-5401 | BAIL TRIP LEVER SPRING   |
| 25     | M19-4601 | BAIL TRIP LEVER WASHER   |
| 26     | Q82-5501 | BAIL TRIP LEVER          |
| 27     | Q95-7301 | BAIL TRIP LEVER SCREW    |
| 28     | Q81-0901 | BAIL SPRING SHAFT        |
| 29     | Q80-8501 | BAIL SPRING SHAFT COLLAR |
| 30     | Q87-3901 | BAIL SPRING              |
| 31     | Q82-6001 | BAIL SPRING HOLDER       |
| 32     | Q81-2001 | BAIL CLICK SPRING        |
| 33     | Q80-8701 | BAIL CLICK PIN           |
| 34     | Q81-2201 | BAIL SPRING COVER SCREW  |
| 35     | Q82-6401 | BAIL SPRING COVER        |
| 36     | Q82-6308 | BAIL ARM                 |
| 37     | Q80-9101 | BAIL ARM COLLAR          |
| 38     | B33-9801 | BAIL ARM RETAINER        |
| 39     | Q81-0001 | ROLLER COLLAR (A)        |
| 40     | Q80-9901 | ROLLER COLLAR (B)        |
| 41     | Q80-9803 | LINE ROLLER              |
| 42     | Q80-9901 | ROLLER COLLAR (C)        |
| 43     | Q81-0101 | ROLLER WASHER            |
| 44     | Q82-6501 | BAIL                     |
| 45     | Q80-9701 | ROLLER SCREW COLLAR      |
| 46     | 373-1306 | ROLLER SCREW WASHER      |
| 47     | M39-8901 | ROLLER SCREW             |

| Key No | Part No  | Description                     |
|--------|----------|---------------------------------|
| 48     | Q41-6203 | BAIL HOLDER WASHER              |
| 49     | Q81-2301 | BAIL HOLDER SCREW               |
| 50     |          |                                 |
| 51     | G83-7101 | SHIELD COVER SCREW              |
| 52     | Q13-9401 | SHIELD COVER                    |
| 53     | Q30-8301 | ONEWAY CLUTCH                   |
| 54     | J00-1401 | CLUTCH RING                     |
| 55     | Q12-6201 | PINION BEARING PLATE SCREW      |
| 56     | Q19-5601 | PINION BEARING PLATE            |
| 57     | G46-7302 | PINION BALL BEARING (A)         |
| 58     | 375-8502 | PINION BEARING WASHER           |
| 59     | Z70-0980 | PINION DRIVE GEAR SET           |
| 60     | H93-1701 | PINION SPRING WASHER            |
| 61     | H95-9601 | PINION BALL BEARING (B)         |
| 62     |          |                                 |
| 63     | J38-7701 | PINION COLLAR                   |
| 64     | Q95-8101 | BODY                            |
| 65     | Q86-6301 | MAIN SHAFT                      |
| 66     | Q12-6306 | OSCILLATING POST                |
| 67     | Q84-5901 | ANTI REVERSE CAM SPRING         |
| 68     | Q85-2701 | ANTI REVERSE CAM                |
| 69     | Q85-2601 | ANTI REVERSE LEVER              |
| 70     | Q86-6901 | REAR COVER                      |
| 71     | Q34-2901 | REAR COVER SCREW                |
| 72     | H60-7902 | OSCILLATING GEAR WASHER         |
| 73     | Q37-5201 | OSCILLATING GEAR                |
| 74     | H77-0601 | OSCILLATING GEAR O RING         |
| 75     | H12-9201 | OSCILLATING GEAR BEARING WASHER |
| 76     | G46-9005 | OSCILLATING GEAR BALL BEARING   |
| 77     | Q12-6101 | OSCILLATING GEAR SCREW          |
| 78     | G67-0501 | DRIVE GEAR O RING               |
| 79     | 375-8502 | DRIVE WASHER                    |
| 80     | G46-7302 | DRIVE BALL BEARING (A)          |
| 81     | Q95-8201 | SIDE COVER                      |
| 82     | Q34-2601 | SIDE COVER SCREW (A)            |
| 83     | Q34-2701 | SIDE COVER SCREW (B)            |
| 84     | Q85-2401 | SIDE COVER SCREW (C)            |
| 85     | Q40-3301 | HANDLE ASSY                     |
| 86     | G52-2706 | DRIVE BALL BEARING (B)          |
| 87     | G47-2401 | DRIVE BEARING RETAINER          |
| 88     | F72-1001 | HANDLE SCREW COLLAR             |
| 89     | 160-8401 | HANDLE SCREW WASHER             |
| 90     | Q13-2401 | HANDLE SCREW                    |

| RGLT2000D-XH-B Special Parts |          |             |
|------------------------------|----------|-------------|
| Key No                       | Part No  | Description |
| 9                            | Q95-8601 | SPOOL ASSY  |