


SPINNING REEL

SAG4000-XH

*Please order by parts number, not key number.



Key No	Part No	Description
1	M37-9301	DRAG KNOB
2	J55-6701	DRAG WASHER RETAINER
3	J55-6601	KEY WASHER (A)
4	M51-2501	ATD DRAG WASHER (3PCS/PK)
5	J56-1202	EARED WASHER
6	M28-7101	KEY WASHER (B)
7	B35-8702	SPOOL BEARING RETAINER
8	G21-2503	SPOOL BALL BEARING (A)
2~9	M37-6301	SPOOL
10	J54-6304	SPOOL WASHER (A)
11	J54-9501	SPOOL METAL
12	J55-8201	SPOOL METAL SCREW
13	G52-2705	SPOOL BALL BEARING (B)
14	J60-2201	SPOOL BEARING WASHER
15	M29-2001	CLICK SPRING HOLDER
16	B74-7701	CLICK LEAF SPRING
17	G52-4801	ROTOR NUT PLATE
18	H62-1501	ROTOR NUT PACKING
19	G21-2503	ROTOR NUT BALLBEARING
20	H62-1401	ROTOR NUT
21	M35-4201	ROTOR NUT COLLAR
22	G16-2401	ROTOR NUT O RING
23	H45-5407	ROTOR NUT SCREW
24	M37-5301	ROTOR
25	H62-0401	ROTOR BRAKE SPRING
26	G68-5401	ROTOR BRAKE WASHER
27	H62-0301	ROTOR BRAKE SHAFT
28	M37-5601	BAIL SPRING HOLDER
29	G94-4501	BAIL SPRING
30	M19-5001	BAIL SPRING SHAFT PLATE
31	M37-7701	BAIL SPRING SHAFT
32	M19-5901	BAIL ARM PLATE
33	M37-5701	BAIL ARM
34	M47-9801	BAIL ARM COLLAR
35	B33-9801	BAIL ARM RETAINER
36	M19-5301	BAIL SPRING HOLDER SPRING
37	M19-5401	BAIL SPRING HOLDER PIN
38	M37-5801	BAIL SPRING COVER
39	G25-6401	BAIL SPRING COVER WASHER
40	M35-5601	BAIL SPRING COVER SCREW
41	M37-5901	BAIL
42	M19-6501	BAIL HOLDER PLATE
43	M47-9801	BAIL HOLDER COLLAR
44	B33-9801	BAIL HOLDER RETAINER
45	375-4101	ROLLER WASHER (A)
46	J53-7801	ROLLER MAG COLLAR (A)
47	J25-6701	ROLLER BALL BEARING
48	M19-6601	ROLLER COLLAR (A)
49	M19-6702	LINE ROLLER
50	J25-6301	ROLLER COLLAR (B)
51	J25-6601	ROLLER COLLAR (C)
52	J25-6701	ROLLER BALL BEARING
53	J53-8401	ROLLER MAG COLLAR (B)
54	J53-8001	ROLLER COLLAR (D)
55	M29-1901	ROLLER SCREW WASHER
56	M19-6802	ROLLER SCREW
57	M37-5101	MAGSEALED COVER
58	M37-5201	MAGSEALED COVER RING
59	M36-1501	MAGSEALED PLATE

Key No	Part No	Description
60	M36-1401	MAGSEALED PLATE O RING
61	M36-1301	ONEWAY CLUTCH COVER
62	H69-0201	ONEWAY CLUTCH PLATE (A)
63	J54-1901	ONEWAY CLUTCH PLATE (B)
64	G31-4501	ONEWAY CLUTCH
65	M36-2001	CLUTCH RING O RING
66	H78-2302	CLUTCH RING
67	371-2836	CLUTCH RING WASHER
68	M36-1101	PINION BEARING PLATE
69	E13-4508	PINION BEARING PLATE SCREW
70	G52-2802	PINION BALL BEARING (A)
71	371-2824	PINION WASHER (A)
72	Z02-6852	PINION DRIVE GEAR SET
73	G57-8502	PINION SPRING WASHER
74	E15-4803	PINION WASHER (B)
75	G52-2702	PINION BALL BEARING (B)
76	M36-0601	PINION BEARING COLLAR
77	M35-9307	BODY
78	M36-0302	OSCILLATING POST
79	M37-4801	MAIN SHAFT
80	B53-6102	REAR COVER WASHER
81	M36-0401	REAR COVER PACKING
82	M36-0501	REAR COVER
83	E27-2501	REAR COVER SCREW WASHER
84	J89-4901	REAR COVER SCREW (A)
85	M37-1101	REAR COVER SCREW (B)
86 87	J71-8601	REAR COVER SCREW O RING
88	G64-4203	REAR COVER SCREW WASHER
89	M37-4701	OSCILLATING GEAR
90	G46-6001	OSCILLATING GEAR O RING
91	G46-6103	OSCILLATING GEAR BEARING WASHER
92	G46-6202	OSCILLATING GEAR BALL BEARING
93	G94-0402	OSCILLATING GEAR SCREW
94	M44-3001	DRIVE GEAR O RING (A)
95	G80-0701	DRIVE GEAR O RING (B)
96	M44-3001	DRIVE GEAR O RING (C)
97	J18-5401	DRIVE GEAR O RING (D)
98	J04-0002	DRIVE BALL BEARING (A)
99	M35-9801	DRIVE BEARING WASHER (A)
100	B85-3101	SIDE COVER PIN O RING
101	J90-2801	SIDE COVER PIN
102	M35-9901	SIDE COVER (R)
103	G67-2401	SIDE COVER (R) O RING
104	M36-6402	HANDLE CAP
105	J04-0002	DRIVE BALL BEARING (B)
106	G64-5603	DRIVE BEARING WASHER (B)
107	J18-5401	SIDE COVER (L) O RING (A)
108	J80-1101	SIDE COVER (L) O RING (B)
109	M36-1203	SIDE COVER (L)
110	M46-0001	HANDLE
111	J93-2103	ROTOR NUT WASHER
112	B53-6101	BAIL ARM RETAINER WASHER
113	B53-6101	BAIL HOLDER RETAINER WASHER
114	M59-2501	MAGSEALED PLATE WASHER(A)
115	M59-2401	MAGSEALED PLATE WASHER(B)
200	M37-6901	HANDLE KNOB
201	M36-6301	HANDLE KNOB SCREW
202	H10-0001	HANDLE KNOB O RING