

How To Calibrate an MP3000

Wednesday, March 8, 2023

9:51 AM

1. Press and hold the RESET and INV.CNTR. buttons simultaneously for 10 seconds till you hear and audible beep
 - a. The reel should display 2 numbers. The number on the bottom indicates how much line the reel was calibrated for when line was initially installed, and the top number indicates the amount that the reel now “thinks” is left on the reel.
2. Press and hold the INV.CNTR. button for 5 seconds till it beeps.
 - a. The screen will display the top number for adjustment
 - b. If you wish to adjust the bottom number press INV.CNTR one more time
3. Once you have selected the number you wish to adjust, lift the power lever slowly to begin increasing the amount of line or depress the lever to decrease the amount of line.
 - a. It is optimal for the reel’s performance for both numbers to match unless you are certain of the amount of line that is left on the reel, the top number should reflect this known amount of line.
4. Once you adjusted the line amount to the desired settings press INV. CNTR 1 time then press RESET 1 time.
5. Press INV.CNTR repeatedly until the reel goes back to the “Home” Screen
6. DONE
 - * You can check to see if your calibration was successful by repeating steps 1 and 5.