


DAEWOO

ELECTRONIC REEL

SBG1800M-RJ

*Please order by parts number, not key number.



Key No	Part No	Description
9	M50-9001	MOTOR HOLDER (FRAME)
30	M49-4501	MOTOR
42	M50-9501	MOTIR CORD (RED)
45	M50-9502	MOTIR CORD (BLACK)
48	M51-9501	MOTOR SCREW
51	H62-1801	MOTOR SCREW O RING
54	E08-8005	MOTOR GEAR SHAFT BALL BEARING (A)
57	M50-9601	MOTOR GEAR (A)
66	M50-9602	MOTOR GEAR (B)
78	M51-0101	LEFT SIDE BASE PLATE
81	J92-0601	MOTOR HOLDER O RING (A)
84	G52-2702	MOTOR GEAR SHAFT BALL BEARING (A)
87	B35-8605	MOTOR GEAR SHAFT BALL BEARING (B)
93	J27-0001	MOTOR GEAR SHAFT
96	H07-8001	MOTOR GEAR SHAFT O RING
99	320-8002	MOTOR GEAR SHAFT RETAINER
102	H73-9703	MOTOR BALL BEARING
105	M50-9301	PALMING PLATE
114	M53-1901	LEFT SIDE BASE PLATE SCREW
120	M51-0001	RIGHT SIDE BASE PLATE
123	J92-0601	MOTOR HOLDER O RING (B)
126	M51-9401	CORD COVER (A)
129	M53-1901	RIGHT SIDE BASE PLATE SCREW
132	M49-2501	LEVELWIND
141	M49-2701	WORM SHIELD
147	M49-2801	WORM SHAFT
150	J27-1001	WORM SHAFT COLLAR
153	F23-7701	WORM SHAFT GEAR WASHER
156	M49-4401	WORM SHAFT GEAR
159	320-5901	WORM SHAFT GEAR RETAINER
162	F46-7201	WORM SHAFT BUSHING
165	B41-1706	WORM SHAFT WASHER
168	320-5901	WORM SHAFT RETAINER
171	J27-1201	LEVELWIND PAWL
174	G09-9801	LEVELWIND PAWL WASHER
177	J27-1301	LEVELWIND COLLAR
180	J26-7502	STABILIZER BAR
186	G50-1101	SPOOL BALL BEARING
192	M49-4901	SPOOL
207	G64-3501	SPOOL PIN
210	M49-4101	SPOOL GEAR (A)
211	B55-7607	SPOOL GEAR SCREW
213	J04-2402	SPOOL SHAFT BALL BEARING (A)
214	M59-2001	SPOOL SHAFT COLLAR
216	M49-5601	SPOOL SHAFT GEAR (A)
219	371-2824	SPOOL SHAFT GEAR WASHER
222	B01-3101	SPOOL SHAFT GEAR RETAINER (A)
225	M49-3601	SPOOL SHAFT
228	M48-9701	SPOOL SHAFT GEAR (B)
231	320-7601	SPOOL SHAFT GEAR RETAINER (B)
234	F81-1801	SPOOL SHAFT BALL BEARING (B)
237	M49-0001	SPOOL GEAR (B)
270	M49-3401	SPOOL PLATE
273	B55-7607	SPOOL PLATE SCREW
276	E15-4803	SPOOL SHAFT WASHER
285	M50-9801	SET PLATE
294	F57-3101	IDLE GEAR COLLAR (A)
297	M49-4301	IDLE GEAR (A)
300	G53-9401	IDLE GEAR WASHER (A)

Key No	Part No	Description
303	B55-7607	IDLE GEAR SCREW (A)
306	G07-6501	IDLE GEAR COLLAR (B)
309	M49-4201	IDLE GEAR (B)
312	G53-9401	IDLE GEAR WASHER (B)
315	B55-7607	IDLE GEAR SCREW (B)
318	E08-8005	IDLE GEAR BALL BEARING
321	E17-5802	SPOOL SHAFT BALL BEARING (C)
324	M49-5301	IDLE GEAR (C)
327	M49-5401	IDLE GEAR (D)
330	F88-9103	IDLE GEAR WASHER (C)
333	G07-6501	IDLE GEAR (E)
345	H67-4801	IDLE GEAR O RING
348	G07-7201	IDLE GEAR COLLAR (C)
351	B55-7607	SET PLATE SCREW
357	M39-1301	IC MODULE
363	J26-7502	FRAME PILLER
366	M51-9601	FRAME PILLER PLATE
369	B55-7607	FRAME PILLER PLATE SCREW
372	M53-1601	POWER LEVER COLLAR (A)
375	M51-2001	POWER LEVER
387	H71-4501	POWER LEVER O RING
390	F95-6701	POWER LEVER WASHER (A)
393	J29-1801	POWER LEVER HOLDER (R)
396	B55-3801	POWER LEVER HOLDER WASHER
399	M53-1401	POWER LEVER HOLDER (L)
402	B55-7607	POWER LEVER HOLDER SCREW
405	F59-0101	POWER LEVER COLLAR (B)
408	M53-9501	POWER LEVER WASHER (B)
411	G16-2201	POWER LEVER SCREW
414	B55-7607	SENSOR SCREW (A)
417	H15-8201	SENSOR SCREW (B)
418	M49-4601	CORD COVER (B)
420	M70-7801	FERRITE CORE
421	M70-8001	FERRITE CORE CORD (RED)
422	M70-8002	FERRITE CORE CORD (BLACK)
423	M51-9701	FINGER COVER
426	M51-9801	LINE GUARD
429	H58-5401	LINE GUARD SCREW
432	G16-2201	FINGER COVER SCREW
435	M51-9901	PUSH BUTTON
438	M52-0001	SHIFT SWITCH BUTTON
441	M52-0101	IC MODULE COVER
444	G16-2201	IC MODULE COVER SCREW
447	M52-0201	IC MODULE COVER PLATE
450	M54-8001	LEFT SIDE PLATE
477	F67-3802	MECHANICAL BRAKE WASHER (A)
480	J19-7401	MECHANICAL BRAKE WASHER (B)
483	J05-6901	MECHANICAL BRAKE WASHER (C)
486	G21-2403	MECHANICAL BRAKE WASHER (D)
492	M53-1902	LEFT SIDE PLATE SCREW
498	M49-0501	DRIVE SHAFT
501	G42-6301	DRIVE SHAFT BALL BEARING
504	372-7601	DRIVE SHAFT WASHER
507	B01-3101	DRIVE SHAFT RETAINER
510	H15-6901	DRIVE SHAFT O RING
513	M48-4201	DRIVE SHAFT RETAINING PLATE
516	E13-4509	DRIVE SHAFT RETAINING PLATE SCREW
519	M52-0601	RIGHT SIDE SET PLATE

Key No	Part No	Description
522	B55-7607	RIGHT SIDE SET PLATE SCREW
525	M49-4701	YOKE PLATE
540	M49-5101	ANTI REVERSE RATCHET
549	M49-7901	ANTI REVERSE CLAW PIN
552	G44-1301	ANTI REVERSE CLAW
555	M54-0701	ANTI REVERSE SPRING PIN
558	M48-2801	ANTI REVERSE SPRING
561	M48-4301	YOKE
564	M48-2101	PINION GEAR
567	M48-2401	YOKE SPRING
570	M08-5901	DRIVE GEAR WASHER
576	M49-3701	DRIVE GEAR
579	F21-4002	DRAG WASHER
582	M49-0401	KEY WASHER
585	H76-6701	EARED WASHER
588	H15-6901	DRAG COLLAR O RING (A)
591	M51-2401	DRAG COLLAR
594	F46-5901	DRAG COLLAR O RING (B)
597	G42-6301	DRIVE BALL BEARING
603	M51-1801	RIGHT SIDE PLATE (A)
606	G42-6301	PINION BALL BEARING
609	F44-0201	PINION BEARING RETAINING WASHER
612	B55-7607	PINION BEARING RETAINING SCREW
615	M52-0901	CLUTCH LEVER PLATE
618	M52-1001	CLUTCH LEVER
636	373-7808	CLUTCH LEVER WASHER (A)
639	J26-8201	CLUTCH LEVER WASHER (B)
642	M52-1101	CLUTCH CAM
651	J27-5301	CLUTCH CAM SPRING
654	160-8001	CLUTCH LEVER WASHER
657	353-8212	CLUTCH LEVER SCREW
660	G25-3301	RIGHT SIDE PLATE SCREW WASHER
663	G16-2201	RIGHT SIDE PLATE SCREW (A)
669	M52-0802	RIGHT SIDE PLATE (B)
672	M52-0701	RIGHT SIDE COVER PLATE
675	J51-0101	RIGHT SIDE COVER PLATE SCREW
678	E28-6001	LINE STOPPER
684	M53-1901	RIGHT SIDE PLATE SCREW (B)
687	M49-0301	DRIVE BEARING COLLAR
690	F67-3601	DRAG SPRING WASHER
696	H69-1901	CLICK SPRING HOLDER
705	H93-3201	CLICK LEAF SPRING
708	H92-9501	STAR DRAG WASHER
711	M35-0701	STAR DRAG
718	G02-7402	HANDLE WASHER
720	F86-3202	HANDLE COLLAR
723	M52-1201	HANDLE
777	G63-4603	HANDLE NUT
780	B88-4704	HANDLE LOCK PLATE
783	J31-6701	HANDLE LOCK PLATE SCREW
786	J18-4201	CONNECTOR CAP
913	K30-9201	ROD CLAMP
914	M52-1401	CLAMP SCREW
915	M62-6301	CLAMP COLLAR
916	M52-1501	CLAMP SCREW NUT
917	G44-5401	CLAMP NUT
941	J32-3802	CORD (WITHOUT FERRITE CORE)
942	M69-3001	FERRITE CORE