


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



SPINNING REEL **TOURNAMENT BASIA 45KYOGOI**



Key No.	Parts No.	Parts Name
1	G65-7301	Drag Knob
2,98-108	G65-7001	Spool Assembly
3	E39-9201	Washer (A)
4	F04-3401	Washer (B)
5	E26-7501	Washer (C)
6	G37-2901	Main Shaft
7	G18-0301	Rotor Nut Retainer
8	E46-8801	Screw (A)
9	G18-0201	Rotor Nut Shield
10	G31-4901	Ball Bearing (A)
11	G18-0101	Rotor Nut
12	G29-2401	Screw (B)
13	G17-8303	Rotor (A)
14	G17-9803	Rotor (B)
15	G29-2301	Screw (C)
16	G17-8403	Bail Arm
17	G18-8501	Screw (D)
18	G17-8603	Bail Assembly
19	G30-1101	Collar (A)
20	G30-1301	Ball Bearing (B)
21	G25-4201	Line Roller
22	G44-5501	Washer (D)
23	G17-9702	Collar (B)
24	F60-8901	Screw (E)
25	E32-6702	Bail Spring Shaft
26	E31-3901	Washer (E)
27	E26-5601	Bail Spring
28	G17-9201	Rotor Shaft
29	G17-9303	Cover (B)
30	F89-1503	Screw (F)
31	G17-8503	Cover (A)
32	G17-7701	Rotor Plate
33	371-2836	Washer (F)
34	G17-8201	Rotor Shield
35	G17-7001	Bearing Retainer
36	G17-5203	Screw (G)
37	F24-0001	Bell Bearing (C)
38	G08-8401	Clutch Cam Retainer
39	F64-1401	Clutch Cam
40	G08-8201	Spacing Sleeve
41	G31-4501	Roller Clutch
42	G17-5301	Roller Clutch Cover
43	G17-6901	Collar (C)
44	635-4801	Ball Bearing (D)
45	G17-6801	Collar (D)
46	G17-6701	Anti-Reverse Ratchet
47	E33-9701	Washer (G)
48	G17-6601	Pinion Gear
49	G17-5401	Collar (E)
50	G65-6801	Body
51	E32-7801	Anti-Reverse Cam Spring
52	G17-5803	Anti-Reverse Lever
53	F28-3101	Ball Bearing (E)

Key No.	Parts No.	Parts Name
54	320-5901	Worm Shaft Retainer (A)
55	G17-6201	Worm Shaft Retainer (A)
56	G17-6101	Worm Shaft
57	B41-1700	Washer (H)
58	G32-6201	Collar (F)
59	G25-4101	Collar (G)
60	G17-6501	Worm Shaft Retainer (B)
61	G25-3401	Collar (L)
62	G17-6401	Stabilizer Bar
63	G17-7101	Oscillating Slider
64	G17-7201	Oscillating Pawl
65	G17-7301	Collar (H)
66	375-0800	Washer (I)
67	E26-4302	Oscillating Slider Cover
68	352-1505	Screw (H)
69	G17-5501	Anti-Reverse Pawl Plate
70	G17-5601	Anti-Reverse Pawl
71	E26-2102	Collar (I)
72	E26-2201	Anti-Reverse Pawl Spring (A)
73	G27-8301	Screw (I)
74	G17-5701	Body Shield
75	635-4801	Ball Bearing (F)
76	E26-4502	Anti-Reverse Pawl Spring (B)
77	G59-7901	Drive Gear
78	371-2800	Washer (J)
79	635-4801	Ball Bearing (G)
80	G17-5701	Side Cover Shield
81	G17-7603	Side Cover
82	G17-7801	Screw (J)
83	F23-5407	Handle screw
84	G65-6901	Handle Assembly
85	G17-8001	Rear Cover Shield
86	G17-8109	Rear Cover
87	G18-0001	Screw (K)
89	G25-3201	Screw (L)
90	G25-3101	Collar (J)
91	G25-3601	Washer (K)
92	G25-3501	Washer (L)
94	G25-6801	Collar (M)
95	351-7707	Screw (M)
96	F70-4902	Spool Click Leaf Spring
97	F20-4001	Click Leaf Spring Holder
98	G15-9901	Screw (N)
99	G37-3701	Spool Retainer
100	G37-4601	Spool Shield
101	G37-3601	Drag Knob Click Plate
102	G37-3501	Key Washer
103	G37-3401	Drag Washer
104	G18-9001	Spool Ring
105	G31-8501	Screw (O)
106	G65-7201	Line Clip
107	B76-3201	Line Clip Spring
108	B33-9801	Line Clip Retainer