RIGHT SIDE FRAME ASSEMBLY FOR MODELS 805 AND 835



Key No.	Description	Part No.
1	Main Shaft Retaining Ring	195 800
2	Star Drag Spacer	009 800
3	Drag Control Knob	010 600
4	Insulating Washer (2 req.)	199P600
5	Tension Washer	008 600
6	Key Washer (2 req.)	086 600
7	Drag Washer (3 req.)	006P600
8	Ear Washer (2 req.)	007 836
9	Thermal Insulator	191 836
10	Spool	029 805
11	Counter Cup Gear	179 600
12	Counter Cup Shaft	188 800
13	Counter Cup Shaft Seal	247 800
14	Main Sleeve	098 800
15	Main Sleeve Pin	102 800
16	Idler Gear Retaining Ring (2 req.)	069B600
17	Idler Gear (2 req.)	178 600
18	Boom Screw	194 600

Key No.	Description	Part No.
19	Main Shaft Seal	245 800
20	Frame Vent Seal	247 805
21	Push Button Boot	504 805
22	Switch Boot	504 800
23	Frame Bearing	147A800
24	Fuse Boot	505 800
25	Boom Bottom	183 800
26	Boom Tip	218 800
27	Line Guide Screw	204R820
28	Line Guide	223 836
29	Boom Pulley Screw	182 800
30	Boom Tip Screw	204P600
31	Boom Pulley Nut	208 815
32	Boom Pulley	180 600
33	Line Guide Bracket	201 620
34	Line Guide Sleeve	202 600
35	Sleeve Retaining Ring	203 600
36	Cable Hardware (Complete)	213 600SPD
37	Boom Tip (Complete)	218C820SPD
38	Frame w/Bearing & Seals	132 805

LEFT SIDE FRAME ASSEMBLY FOR MODELS 805 AND 835



Key No.	Description	Part No.
38	Frame w/Bearing & Seals	132 805
39	Hold Down Knob	184 600
40	Hold Down Knob Washer	206 600
41	Hold Down Knob Spring	192 600
42	Fuse Circuit Breaker	506 800
43	Sensor Switch Asm	507A805
44	Sensor Switch Bracket	507C805
45	Switch (Up & Down)	503 825
46	Push Button	503 805
47	Hold Down Retaining Ring	195 600
48	Power Cable Clip	203 800
49	Lower Power Cable Cap	531 800
50	Power Cable (Lower)	532 800
51	Power Cable (Upper)	530 800
52	Motor	501 805
53	Motor Shaft Coupling	119 800
54	Gear Box Complete	156 805
55	Lock Washer (2)	220 805
56	Mounting Screw (2)	032 800
57	Gear Box Mounting Screw (4)	209 805
58	Wiring Harness (Breaker)	515A805

Key No.	Description	Part No.
59	Wiring Harness (Switch)	515 805
60	P.C. Driver Board	507 805
61	P.C Mounting Screw	046A704
62	Frame Gasket	264 800
63	Frame Cover	227 805
64	Indicator Bracket	181A800
65	Indicator Bracket Screw	063 349
66	Counter Cup Shaft Seal	247 800
67	Counter Cup Thrust Washer (2)	247 620
68	Counter Cup Washer	190P600
69	Counter Cup	181 600
70	Counter Cup Lock Nut	200 600
71	Rubber Washers (9)	220 800
72	Flat Washer (9)	205 800
73	Cover Mounting Screw (9)	063 800
74	Base Plate Mounting Screw (4)	209 600
75	Base Plate	133 600
76	Base Plate Washer (4)	220 600
77	Base Plate Nut (4)	211 600
78	Base Plate Large Nut	193 600
79	Sensor Bracket #4Screw (Click Spring)	063 330