



KEY NO.	PART NO.	DESCRIPTION
27	1271265	27-SS/V9500 Rotor
27	1271296	27-SS/V10500 Rotor
27A	1271266	27A-SS/V9500 Rotor Cover
28	1271267	28-SS/V9500 Ball Trip Lever
28D	1271268	28D-SS/V9500 Rotor Brake
28D	1271297	28D-SS/V10500 Rotor Brake
28E	1294661	28E-SS/V9500 Rotor Brake Cover
31	1271055	31-SS/V5500 Ball Arm Screw (2req)
32	1271270	32-SS/V9500 Ball Spring
34	1271163	34-SS/V7500 Ball Arm
34C	1271164	34C-SS/V7500 Pivot Arm
35	1271165	35-SS/V7500 Line Roller
35A	1271050	35A-SS/V5500 Line Roller Ball Bearing
36	1271166	36-SS/V7500 Line Roller Screw
38	1271167	38-SS/V7500 Rotor Nut
38A	1271063	38A-SS/V5500 Rotor Nut Lock Plate Screw(3req)
38D	1271168	38D-SS/V7500 Rotor Washer
39	1271271	39-SS/V9500 Main Shaft
39A	1288190	39A-SS/V9500 Spool Adjust Washer
39B	1288191	39B-SS/V9500 Main Shaft Washer
43	1271272	43-SS/V9500 Oscillation Slider
43A	1271273	43A-SS/V5500 Oscillation Slider Guide
43C	1271071	43C-SS/V5500 Oscillation Slider Bushing Screw
43D	1279457	43D-SS/V3500 Oscillation Slider Bushing
44	1271174	44-SS/V7500 Main Shaft Screw (2req)
45	1271274	45-SS/V9500 Body Cover
45	1271298	45-SS/V10500 Body Cover
46	1271275	46-SS/V9500 Body Cover Screw (4req)
47	1271276	47-SS/V9500 Spool Assembly
47B	1271299	47B-SS/V10500 Spool Assembly
47C	1271277	47C-SS/V9500 Spool
47D	1271279	47D-SS/V9500 Spool
47S	1271301	47S-SS/V5500 Drag Drive Plate Seal
48	1271281	48-SS/V9500 Drag Cover Seal
48S	1271282	48S-SS/V9500 Drag Cover Seal
51	1271065	51A-SS/V5500 Drag Washer Retainer
51A	1271163	51A-SS/V7500 Bearing Retainer Screw (3req)
52	1271783	52S-SS/V9500 Drag Knob Assembly
52	1271782	52-SS/V10500 Drag Knob Assembly
53	1293233	53S-SS/V5500 Drag Knob Seal
55	1271286	55S-SS/V9500 Drag Friction Washer (2req)
56	1271069	56T-SS/V5500 Drag Friction Washer
57	1271285	57T-SS/V7500 Keyed Drag Washer (2req)
57T	1271167	57T-SS/V7500 Keyed Drag Washer
63	1271266	63-SS/V9500 Spool Bushing
63S	1271287	63S-SS/V9500 Rear Bushing E-Clip
74H	1271169	74H-SS/V7500 Rotor Nut Locking Plate
98	1271190	98-SS/V7500 Clutch Sleeve Assembly
98	1271190	117-SS/V9500 Drag Drive Plate
117	1271288	117-SS/V9500 Drag Drive Plate
132	1271192	132-SS/V7500 Line Roller Collar
132A	1271097	132A-SS/V5500 Line Roller Washer
225	1271269	225-SS/V9500 Rear Bushing
231B	1271100	231B-SS/V9500 Oscillation Gear
231B	1271100	231B-SS/V5500 Oscillation Gear Screw
232	1271292	232-SS/V9500 Bearing Retainer (2req)
232	1271303	232-SS/V10500 Bearing Retainer (2req)
233A	1271196	233A-SS/V7500 Handle Cap
233C	1271197	233C-SS/V7500 Handle Cap Washer
27	1271265	27-SS/V9500 Rotor
27	1271296	27-SS/V10500 Rotor
27A	1271266	27A-SS/V9500 Rotor Cover
28	1271267	28-SS/V9500 Ball Trip Lever
28D	1271268	28D-SS/V9500 Rotor Brake
28D	1271297	28D-SS/V10500 Rotor Brake
28E	1294661	28E-SS/V9500 Rotor Brake Cover
31	1271055	31-SS/V5500 Ball Arm Screw (2req)
32	1271270	32-SS/V9500 Ball Spring
34	1271163	34-SS/V7500 Ball Arm
34C	1271164	34C-SS/V7500 Pivot Arm
35	1271165	35-SS/V7500 Line Roller
35A	1271050	35A-SS/V5500 Line Roller Ball Bearing
36	1271166	36-SS/V7500 Line Roller Screw
38	1271167	38-SS/V7500 Rotor Nut
38A	1271063	38A-SS/V5500 Rotor Nut Lock Plate Screw(3req)
38D	1271168	38D-SS/V7500 Rotor Washer
39	1271271	39-SS/V9500 Main Shaft
39A	1288190	39A-SS/V9500 Spool Adjust Washer
39B	1288191	39B-SS/V9500 Main Shaft Washer
43	1271272	43-SS/V9500 Oscillation Slider
43A	1271273	43A-SS/V5500 Oscillation Slider Guide
43C	1271071	43C-SS/V5500 Oscillation Slider Bushing Screw
43D	1279457	43D-SS/V3500 Oscillation Slider Bushing
44	1271174	44-SS/V7500 Main Shaft Screw (2req)
45	1271274	45-SS/V9500 Body Cover
45	1271298	45-SS/V10500 Body Cover
46	1271275	46-SS/V9500 Body Cover Screw (4req)
47	1271276	47-SS/V9500 Spool Assembly
47B	1271299	47B-SS/V10500 Spool Assembly
47C	1271277	47C-SS/V9500 Spool
47D	1271279	47D-SS/V9500 Spool
47S	1271301	47S-SS/V5500 Drag Drive Plate