


PARTS AND PRICE LIST FOR MODEL 101



ALL #101 PARTS ARE SUBJECT TO AVAILABILITY

Key No.	Part No.	Description	Price
1	1-101	Housing w/Bushing & Emblem	\$7.95
2	2-101	Housing Bushing	.70
2A	2-101	Cover Bushing	.70
3	3-101	Dog Mounting Screw	.35
4	4-101	Dog	.80
5	5-101	Dog Spring	.35
6A	6A-101	Eccentric	.80
6D	6D-101	Eccentric Spring	.40
6E	6E-101	Eccentric Lever	.45
6F	6F-101	Eccentric Lever Mounting Screw	.35
8	8-101	Main Gear Assembly	4.00
8A	8A-101	Main Gear Shim	.35
15	15-101	Handle (Complete)	4.10
15B	15B-101	Handle Shaft	.95
15C	15C-101	Handle Pivot Pin	.35
16	16-101	Handle Collar	.80
19	19-101	Pinion Gear	3.35
19A	—	Pinion Gear Spacer	—
20	20-101	Ball Bearing	6.05
21	—	Bearing Cover	—
23	3-101	Bearing Cover Screw	.35
24	24-101	Bail Wire (Complete)	3.60
27	27-101	Rotor Cup	6.40
27A	27A-101	Rotor End Cover	.45
28	28-101	Trip Lever	.80
28A	28A-101	Cam Lever	.80
28B	28B-101	Cam Lever Mounting Screw	.35
28C	28C-101	Trip Cam	.70
28D	28D-101	Cam Mounting Screw	.35

Key No.	Part No.	Description	Price
31	31-101	Bail Arm Screw	\$.45
31A	31-101	Bail Wire Mounting Screw	.45
32	32-101	Bail Spring	.50
34	34-101	Bail Arm	1.05
35	35-101	Line Roller	1.45
36	36-101	Roller Mounting Screw	.35
36A	36A-101	Roller Lock Washer	.35
38	38-101	Rotor Nut	.35
39	39-101	Crosswind Shaft	2.45
40B	40B-101	Click Ratchet	.45
43	43-101	Crosswind Arm	.95
44	44-101	Crosswind Arm Pin	.45
45	45-101	Housing Cover w/Bushing	2.70
46	46-101	Housing Cover Screw	.35
46A	28D-101	Rotor End Cover Screw	.35
47	47-101	Spool (Complete)	7.95
49	49-101	Click Spring	.45
49A	3-101	Click Spring Screw	.35
50	3-101	Bail Spring Cover Screw	.35
51	51-101	Retaining Ring	.35
52	52-101	Drag Knob (Complete)	1.35
56	56T-101	Drag Washer (Teflon*)	.35
57	57-101	Drag Washer (Keyed)	.40
58	58-101	Drag Washer (Ear)	.45
60	60-101	Thrust Washer (Teflon*)	.40
106	106-101	Cam Lever Spring	.35
132	132-101	Roller Washer	.70
227	227-101	Bail Spring Cover	.45
233	233-101	Housing Handle Cap	.70