


PARTS AND PRICE LIST FOR MODEL 103


Key No.	Part No.	Description	Price
1	1-103	Housing w/Bushing & Emblem	\$11.10
2	2-103	Housing Bushing	.75
2A	2-103	Cover Bushing	.75
3	3-103	Dog Mounting Screw	.45
4	4-103	Dog w/Finger Spring	1.90
6A	6A-103	Eccentric	1.60
6D	6D-103	Eccentric Spring	.40
6E	6E-103	Eccentric Lever	.50
6F	6F-101	Eccentric Lever Mounting Screw	.35
8	8-103	Main Gear Assembly	4.80
8A	8A-103	Main Gear Shim	.35
10	10-103	Anti-Reverse Ratchet	.70
15	15-103	Handle (Complete)	5.60
15B	15B-103	Handle Shaft	1.30
15C	15C-103	Handle Pivot Pin	.35
16	16-103	Handle Collar	.95
19	19-103	Pinion Gear	4.10
19A	19A-103	Pinion Gear Spacer	.75
20	20-103	Ball Bearing	8.00
21	21-103	Bearing Cover	.80
23	23-103	Bearing Cover Screw	.40
24	24-103	Bail Wire (Complete)	6.30
27	27-103	Rotor Cup	7.95
27A	27A-103	Rotor End Cover	.45
28	28-103	Trip Lever	.80
28A	28A-103	Cam Lever	.80
28B	28B-103	Cam Lever Mounting Screw	.35
28C	28C-103	Trip Cam	.80
28D	28D-103	Cam Mounting Screw	.40
31	31-103	Bail Arm Screw	.70

Key No.	Part No.	Description	Price
31A	31A-103	Bail Wire Mounting Screw	\$.70
32	32-103	Bail Spring	.70
34	34-103	Bail Arm	1.60
34A	34A-103	Bail Arm Spacer	.45
35	35-103	Line Roller	1.90
36	36-103	Roller Mounting Screw	.35
36A	36A-103	Roller Mounting Lock Washer	.35
38	38-103	Rotor Nut	.40
39	39-103	Crosswind Shaft	4.00
40B	40B-103	Click Ratchet	.45
43	43-103	Crosswind Arm	1.05
44	44-103	Crosswind Arm Pin	.40
45	45-103	Housing Cover w/Bushing	4.60
46	46-103	Housing Cover Screw	.35
46A	46A-103	Rotor End Cover Screw	.35
47	47-103	Spool (Complete)	14.40
49	49-103	Click Spring	.80
49A	3-101	Click Spring Screw	.35
50	23-103	Bail Spring Cover Screw	.40
51	51-103	Retaining Ring	.35
52	52-103	Drag Knob (Complete)	1.65
56	56T-103	Drag Washer (Teflon*)	.40
57	57-103	Drag Washer (Keyed)	.45
58	58-103	Drag Washer (Ear)	.45
60	60-103	Thrust Washer (Teflon*)	.40
106	106-103	Cam Lever Spring	.35
132	132-103	Roller Washer	.70
227	227-103	Bail Spring Cover	.45
233	233-103	Housing Handle	.80