




PARTS LIST FOR WAR15LWLCLH and WAR20LWLCLH  
REEL ASM. Nos. 1366189(WAR15LWLCLH)&1366194(WAR20LWLCLH)



| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION                   | KEY NO. | PART NO. | PENN STYLE NO.  | DESCRIPTION                  |
|---------|----------|----------------|-------------------------------|---------|----------|-----------------|------------------------------|
| 1       | 1383098  | 1-WAR15LWLCLH  | Right Side Plate Assembly(15) | 35      | 1383037  | 35-WAR15LW      | Click Tongue                 |
| 1       | 1383099  | 1-WAR20LWLCLH  | Right Side Plate Assembly(20) | 36      | 1383038  | 36-WAR15LW      | Click Button                 |
| 1A      | 1383100  | 1A-WAR15LWLCLH | Line Counter Cover            | 38      | 1383039  | 38-WAR15LW      | Screw (5 req)                |
| 1B      | 1383084  | 1B-WAR15LWLC   | Screw, L.C.Cover(3req)        | 38A     | 1383040  | 38A-WAR15LW     | Screw                        |
| 2       | 1406057  | 2-WAR15LWLCLH  | Right Side Ring               | 39A     | 1383041  | 39A-WAR15LW     | Screw(2req)                  |
| 3       | 1384179  | 3-WAR15LW      | Bridge                        | 40      | 1383042  | 40-WAR15LW      | Ball Bearing                 |
| 4       | 1382976  | 4-WAR15LW      | Drag Washer                   | 40A     | 1383043  | 40A-WAR15LW     | Washer                       |
| 5       | 1382977  | 5-WAR15LW      | Main Gear                     | 40B     | 1383044  | 40B-WAR15LW     | Felt Washer                  |
| 6       | 1382978  | 6-WAR15LW      | Tabbed Drag Washer(2 req)     | 40C     | 1383045  | 40C-WAR15LW     | Washer, Acetal Thrust        |
| 7       | 1382999  | 7-WAR15LW      | Keyed Metal Drag Washer       | 40D     | 1383046  | 40D-WAR15LW     | Washer, Rubber Thrust        |
| 7H      | 1383000  | 7H-WAR15LW     | Heavy Metal Drag Washer       | 40E     | 1383047  | 40E-WAR15LW     | Thrust Washer (2req)         |
| 8       | 1383001  | 8-WAR15LW      | Spring Washer (4 req)         | 41      | 1383048  | 41-WAR15LW      | Bushing                      |
| 9       | 1384180  | 9-WAR15LW      | Spacing Sleeve                | 41A     | 1384181  | 41A-WAR15LW     | Bushing                      |
| 10      | 1383002  | 10-WAR15LW     | Star Drag                     | 42      | 1385461  | 42-WAR15LWLC    | Worm Shaft Assembly(15)      |
| 10A     | 1383003  | 10A-WAR15LW    | Star Click Retainer           | 42      | 1385462  | 42-WAR20LWLC    | Worm Shaft Assembly(20)      |
| 10B     | 1383004  | 10B-WAR15LW    | Star Click Washer             | 42A     | 1384183  | 42A-WAR15LWLC   | Gear, L.C. Drive             |
| 10C     | 1383005  | 10C-WAR15LW    | Star Click Spring             | 43      | 1383051  | 43-WAR15LW      | Worm Shaft Bushing(2req)     |
| 11      | 1383006  | 11-WAR15LW     | Eccentric Jack                | 46      | 1383052  | 46-WAR15LW      | Line Guide Assembly          |
| 12      | 1383007  | 12-WAR15LW     | Pinion Yoke                   | 47      | 1383053  | 47-WAR15LW      | Line Guide Pawl              |
| 13      | 1383008  | 13-WAR15LW     | Pinion                        | 47A     | 1383054  | 47A-WAR15LW     | Pawl Shim                    |
| 15      | 1383276  | 15-WAR15LWLH   | Anti Reverse Dog(2 req)       | 48      | 1383055  | 48-WAR15LW      | Line Guide Nut               |
| 16      | 1383010  | 16-WAR15LW     | Screw (2 req)                 | 50      | 1383056  | 50-WAR15LW      | Worm Shield(15)              |
| 18      | 1383011  | 18-WAR15LW     | Pinion Yoke Spring (2 req)    | 50      | 1383057  | 50-WAR20LW      | Worm Shield(20)              |
| 19      | 1383012  | 19-WAR15LW     | Eccentric                     | 58      | 1383058  | 58-WAR15LW      | Line Guide Post(15)          |
| 20      | 1383013  | 20-WAR15LW     | Eccentric Spring              | 58      | 1383059  | 58-WAR20LW      | Line Guide Post(20)          |
| 21      | 1383014  | 21-WAR15LW     | Eccentric Lever               | 60      | 1383060  | 60-WAR15LW      | Worm Shaft Washer(2req)      |
| 22      | 1383015  | 22-WAR15LW     | Eccentric Screw               | 62      | 1383061  | 62-WAR15LW      | Spring                       |
| 23      | 1383016  | 23-WAR15LW     | Handle Assembly Screw         | 64      | 1383062  | 64-WAR15LW      | Idler Gear                   |
| 23A     | 1383017  | 23A-WAR15LW    | Handle Lock Screw             | 66      | 1383063  | 66-WAR15LW      | Click Ratchet                |
| 23B     | 1383018  | 23B-WAR15LW    | Handle Screw Washer           | 66A     | 1383064  | 66A-WAR15LW     | Spool Gear                   |
| 24      | 1383019  | 24-WAR15LW     | Handle Assembly               | 69      | 1383065  | 69-WAR15LW      | Retainer Ring                |
| 24A     | 1383020  | 24A-WAR15LW    | Handle Thrust Washer          | 69A     | 1383066  | 69A-WAR15LW     | Retainer Ring (2 req)        |
| 26      | 1383021  | 26-WAR15LW     | Spool Tension Control Cap     | 98      | 1383094  | 98-WAR15LWLH    | Main Gear Shaft              |
| 26A     | 1383022  | 26A-WAR15LW    | Bushing                       | 98A     | 1383068  | 98A-WAR15LW     | Clutch Housing               |
| 26B     | 1383023  | 26B-WAR15LW    | Clutch Retainer               | 98B     | 1384182  | 98B-WAR15LW     | Clutch                       |
| 26C     | 1383024  | 26C-WAR15LW    | Screw(2req)                   | 98R     | 1383069  | 98R-WAR15LW     | Anti Reverse Ratchet         |
| 27      | 1383281  | 27-WAR15LWLCLH | Left Side Plate(15)           | 98S     | 1383070  | 98S-WAR15LW     | Clutch Sleeve                |
| 27      | 1383282  | 27-WAR20LWLCLH | Left Side Plate(20)           | 120     | 1383071  | 120-WAR15LW     | O-Ring                       |
| 27A     | 1383027  | 27A-WAR15LW    | Bearing Housing               | 134A    | 1383095  | 134A-WAR15LWLH  | Clutch Recover Plate         |
| 27B     | 1383028  | 27B-WAR15LW    | Screw(2req)                   | 134B    | 1383096  | 134B-WAR15LWLH  | Clutch Recover Support Plate |
| 27C     | 1383029  | 27C-WAR15LW    | Screw                         | 134C    | 1383097  | 134C-WAR15LWLH  | Clutch Recover Spring        |
| 28      | 1383030  | 28-WAR15LW     | Left Side Ring                | 149     | 1184702  | 149-045         | Rod Clamp Nut (2 req)        |
| 29      | 1383031  | 29-WAR15LW     | Spool (15)                    | 149A    | 1184706  | 149-200         | Hex Nut (2 req)              |
| 29      | 1383032  | 29-WAR20LW     | Spool (20)                    | 154     | 1383077  | 154-WAR15LW     | Click Button Washer          |
| 29L     | 1383033  | 29L-WAR15LW    | Spool Assembly(15)            | 158     | 1383078  | 158-WAR15LW     | Dog Pin(2req)                |
| 29L     | 1383034  | 29L-WAR20LW    | Spool Assembly(20)            | 183     | 1383279  | 183-WAR15LWLH   | Frame Assembly(15)           |
| 33      | 1182754  | 33-113         | Rod Clamp                     | 183     | 1383280  | 183-WAR20LWLH   | Frame Assembly(20)           |
| 34      | 1182788  | 34-045         | Screw (2 req)                 | 303     | 1383283  | 303-WAR15LWLCLH | Counter Wheel Assembly       |