




(1SE664001U)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0071	Rotor Nut	RD 2541	Anti-Reverse Pawl Screw	RD 3873	Anti-Reverse Pawl Spring
RD 0080	Line Roller	RD 2852	Handle Screw Lock	RD 3874	Anti-Reverse Cam
RD 0345	Anti-Reverse Lever Screw	RD 2934	Flange Screw	RD 4264	Bail Spring Guide (B)
RD 0543	Side Cover Screw (small)	RD 3503	Spool Washer	RD 4267	Bail Trip Lever Washer
RD 0787	Nut Lock Screw	RD 3665	Slider Retainer Screw	RD 4318	Bail Trip Lever
RD 0792	Bearing Retainer Screw	RD 3676	Drag Knob	RD 4351	Anti-Reverse Lever
RD 0815	Line Roller Washer	RD 3677	Main Shaft	RD 4362	Side Cover Screw (large-silver)
RD 0940	Multi-Purpose Screw	RD 3681	Bail Spring Guide (A)	RD 4392	Bail Arm
RD 1008	Handle Lock Washer	RD 3682	Bail Spring	RD 4398	Bail Assembly
RD 1030	Handle Assembly	RD 3690	Pinion Gear	RD 5619	Bail Spring Cover
RD 1310	Line Roller Screw	RD 3694	Drive Gear	RD 5620	Rotor
RD 1442	Handle Screw Cap	RD 3695	Oscillating Gear	RD 5621	Side Cover Flange
RD 1506	Multi-Purpose Screw	RD 3696	Oscillating Slider	RD 6850	Spool Assembly
RD 1511	Lever Spring	RD 3868	Lock Out Spring Holder	RD 6873	Side Cover
RD 1520	Anti-Reverse Cam Spring	RD 3869	Anti-Reverse Lock Out Spring	RD 6874	Body
RD 1676	Side Cover Screw (large-black)	RD 3870	Anti-Reverse Lock Out	RD 8554	Ball Bearing
RD 2293	Drive Gear Bushing	RD 3871	Bushing Washer	RD11146	Washer
RD 2516	Spool Support	RD 3872	Anti-Reverse Pawl		