





EXPLODED PARTS VIEW

GRAPHITE CONSTRUCTION

BAITRUNNER

300



PARTS LIST

PART # DESCRIPTION

BR 0002	Drag Washers Retainer
BR 0003	Key Washer
BR 0004	Drag Washer 1
BR 0005	Eared Washer
BR 0006	Drag Washer 2
BR 0009	Spool Washer
BR 0010	Rotor Nut
BR 0014	Bail Trip Slide Cam
BR 0021	Line Roller
BR 0030	Anti-Reverse Pawl Spring
BR 0031	Anti-Reverse Spring Holder
BR 0033	Pinion Spacer
BR 0035	Bearing Retainer Screw
BR 0036	Bearing Retainer
BR 0037	Ball Bearing
BR 0040	Anti-Reverse Pawl
BR 0043	Anti-Reverse Cam
BR 0044	Anti-Reverse Cam Spring
BR 0045	Anti-Reverse Lever
BR 0046	Anti-Reverse Lever Screw
BR 0047	Ball Bearing
BR 0049	Drive Gear Washer
BR 0057	Clutch Plate Screw
BR 0058	Side Cover Screw A
BR 0065	Dial Click Screw
BR 0072	Oscillating Slider Retainer
BR 0080	Side Cover Screw B
BR 0092	Baitrunner Lever Screw
BR 0093	Lock Washer
BR 0240	Bail Trip Cover Screw
BR 0278	Nut Lock Screw

PART # DESCRIPTION

BR 0281	Lever Spring
BR 0284	Bail Trip Cam Screw
BR 0285	Line Roller Washer
BR 0286	Bail Spring Cover
BR 0287	Trigger Screw
BR 0288	Quick-Fire II Trigger
BR 0289	Bail Arm
BR 0290	Bail Spring Guide B
BR 0291	Bail Spring
BR 0292	Bail Spring Guide A
BR 0301	Bushing
BR 0303	"C" Lock
BR 0306	Clutch Spring
BR 0309	Clutch Pawl Spring
BR 0311	Lock Washer Retainer
BR 0312	Handle Lock Washer
BR 0313	Handle Screw Cap
BR 0314	Dial Click
BR 0316	Baitrunner Pawl Spring
BR 0318	Dial Retainer
BR 0323	Clutch Cam
BR 0325	Clutch Arm
BR 0326	Lever Shaft Retainer
BR 0328	Baitrunner Click Spring
BR 0332	Click Gear
BR 0333	Eared Washer "BFS"
BR 0334	Free Spool Tension Spring
BR 0335	Free Spool Tension Screw
BR 0336	Dial Spacer
BR 0337	Baitrunner Tension Dial

PART # DESCRIPTION

BR 0351	Oscillating Gear
BR 0354	Drag Knob
BR 0355	Spool Assembly
BR 0356	Main Shaft
BR 0357	Rotor
BR 0358	Bail Trip Lever
BR 0359	Bail Trip Cover
BR 0360	Bail Assembly
BR 0361	Anti-Reverse Ratchet
BR 0362	Pinion Gear
BR 0363	Anti-Reverse Pawl Screw
BR 0364	Body
BR 0365	Drive Gear
BR 0366	Baitrunner Ratchet
BR 0367	Ratchet Spacer
BR 0368	Baitrunner Pawl Guide
BR 0369	Side Cover
BR 0370	Baitrunner Pawl
BR 0371	Oscillating Slider
BR 0372	Clutch Cam Spacer
BR 0373	Clutch Plate Assembly
BR 0374	Baitrunner Lever Arm (L)
BR 0375	Free Spool Tension Shaft
BR 0376	Baitrunner Lever Arm (R)
BR 0377	Baitrunner Lever Bridge
BR 0378	Handle Assembly
BR 0652	Line Roller Screw
BR 0655	Free Spool Tension Washer (A)
BR 0656	Free Spool Tension Washer (B)
BR 0685	Slider Retainer Screw

Prices and specifications subject to change without notice.

OCTOBER, 1988