



SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

TO ORDER:

This reel belongs to the "Bantam" series.
Please order parts using the abbreviation
"BNT" and the part number.



EXPLODED PARTS VIEW

BANTAM® 100 EX & 100 EX SG

PARTS LIST

PART # DESCRIPTION

- 1. Handle Nut Lock Screw
- 2. Handle Nut
- 4. Drive Shaft Retainer Screw
- 6. Friction Washer
- 7A. Drag Tri-Star
- 8. Cast Control Cap
- 9. Cast Control Spacer
- 10. Cast Control Bushing
- 11. Side Plate Screw
- 13. Drive Shaft Bearing
- 14. Drag Spring Washer
- 15. "D" Washer
- 16. Drag Spacer
- 17. Pressure Plate
- 18. Drag Washer
- 19. Drive Gear
- 20. Base Drag Washer
- 21. Anti Reverse Ratchet

PART # DESCRIPTION

- 22. Drive Shaft
- 23. Pinion Gear
- 24. Pinion Yoke Spring
- 25. Pinion Yoke
- 26. Drive Shaft Shim
- 27. Retractor #1
- 28. Anti Reverse Dog
- 29. Retractor #2
- 31. Spool Shaft Bearing
- 32. Bearing Lock
- 34S. Centrifugal Brake Weights (Small)
- 34L. Centrifugal Brake Weights (Large)
- 35. Left Bearing Spacer
- 36. Stabilizer Bar Screw (Right)
- 39. Level Wind Bearing (Right)
- 41. Line Guide
- 42. Level Wind Pawl
- 43. Pawl Cap

PART # DESCRIPTION

- 45. Level Wind Bearing (Left)
- 46. Level Wind Retainer Screw (Left Hand Thread)
- 48. Left Side Plate Screw
- 49. Left Stabilizer Bar Screw
- 50. Handle Nut Lock Plate
- 51. Handle
- 52. Right Side Plate
- 53. Set Plate
- 54. Spool
- 55. Frame Assembly
- 56. Level Wind Gear
- 57. Level Wind Guard
- 58. Line Guide Stabilizer Bar
- 59. Left Side Plate
- *60. Line Guide Pawl Spacer*
- 156. Right Side Plate (SG)
- 157. Handle (SG)

Prices and specifications subject to change without notice.

*Optional—not shown in exploded view.

JUNE 1986

'87-111