


SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718



EXPLODED PARTS VIEW

TO ORDER:
This reel belongs to the "Bantam" series.
Please order parts using the abbreviation
"BNT" and the part number.

BANTAM® MAG 10 SG

PARTS LIST

PART# DESCRIPTION

1. Handle Nut Lock Screw
2. Handle Nut
4. Drive Shaft Retainer Screw
6. Friction Washer
9. Cast Control Spacer
11. Right Side Plate Screw
13. Drive Shaft Bearing
14. Drag Spring Washer
15. "O" Washer
16. Drag Spring
17. Pressure Plate
18. Drag Washer
19. Drive Gear
20. Base Drag Washer
21. Anti Reverse Ratchet
22. Drive Shaft
24. Pinion Yoke Spring
25. Pinion Yoke
26. Drive Shaft Shim

PART# DESCRIPTION

27. Retractor Spring #1
28. Anti Reverse Dog
29. Retractor Spring #2
32. Bearing Lock
35. Left Bearing Spacer
39. Level Wind Bearing Right
40. Level Wind Guard
42. Level Wind Pawl
45. Level Wind Bearing Left
60. Pawl Shim (Optional)
133. Level Wind Gear Lock
138. Handle Nut Lock Plate
140. Drag Tri-Star
141. Cast Control Cap
144. Set Plate
145. Spool Shaft Bushing
148. Level Wind Gear
149. Line Guide
150. Stabilizer Bar

PART# DESCRIPTION

151. Pawl Cap
154. Felt Oil Retainer
178. Handle
179. Cast Control Bushing
180. Right Side Plate
181. Pinion Gear
182. Spool Shaft Bushing
183. Spool (Old Style)
184. Magnet Retainer Lock
185. Magnet Retainer
186. Bearing Spacer
187. Frame
188. O Ring
189. Magnetic Control Dial
190. Left Side Plate
191. Left Side Plate Screw
192. Left Stabilizer Bar Screw
265. Thrust Washer
325. Spool (convertible)
326. V-Spool Converter*

Prices and specifications subject to change without notice

*Can only be used with 325 spool

JUNE 1986

27-119