


# SHIMANO

CHRONARCH S A-RB

CH-100D7



| Part No. | Description          | Part No. | Description                | Part No. | Description                      |
|----------|----------------------|----------|----------------------------|----------|----------------------------------|
| BNT0015  | Drag Spring Washer   | BNT3014  | Star Drag Nut              | BNT3908  | Star Drag                        |
| BNT0032  | Bearing Retainer     | BNT3041  | Clutch Plate Shaft Support | BNT3918  | Washer                           |
| BNT0060  | Spacer               | BNT3148  | Screw                      | BNT4004  | Handle Assembly                  |
| BNT0664  | Spacer B             | BNT3169  | Pawl Cap                   | BNT4005  | Right Side Plate                 |
| BNT0686  | E Lock               | BNT3226  | Quick-Fire II Clutch Bar   | BNT4006  | Cast Control Cap                 |
| BNT0817  | Screw                | BNT3483  | Anti-Reverse Ratchet       | BNT4007  | Drive Shaft                      |
| BNT1419  | Yoke Spring          | BNT3540  | Screw                      | BNT4008  | Line Guide                       |
| BNT1465  | Clutch Pawl Spring   | BNT3546  | Drag Washer                | BNT4009  | Idle Gear                        |
| BNT1671  | Washer               | BNT3547  | Drive Gear                 | BNT4010  | Worm Shaft                       |
| BNT1672  | E Lock               | BNT3548  | Drag Washer                | BNT4011  | Level Wind Guard                 |
| BNT1696  | Cast Control Spacer  | BNT3621  | Ball Bearing               | BNT4012  | Level Wind Guide                 |
| BNT1715  | Brake Collar (red)   | BNT3627  | Ball Bearing               | BNT4013  | Yoke                             |
| BNT2117  | Handle Nut           | BNT3630  | Roller Clutch Inner Tube   | BNT4014  | Screw                            |
| BNT2120  | Click Plate Retainer | BNT3689  | Screw                      | BNT4015  | Level Wind Protector             |
| BNT2121  | Star Drag Click      | BNT3813  | Damper Spring              | BNT4016  | Line Guard Retainer              |
| BNT2122  | Click Pin            | BNT3818  | Drive Shaft Retainer       | BNT4017  | One-Piece Frame                  |
| BNT2123  | Click Spring         | BNT3819  | Ball Bearing               | BNT4018  | Spool Assembly                   |
| BNT2125  | Star Drag Spring     | BNT3826  | Clutch Cam Retainer        | BNT4019  | Brake Case                       |
| BNT2127  | Star Drag Spacer     | BNT3827  | Clutch Cam                 | BNT4020  | Washer                           |
| BNT2144  | Washer               | BNT3828  | Clutch Pawl                | BNT4021  | O Ring                           |
| BNT2158  | Screw                | BNT3829  | Clutch Plate               | BNT4022  | Left Side Plate                  |
| BNT2224  | Spool Tension Spacer | BNT3832  | Clutch Bar Guide B         | BNT4036  | Line Guide Pawl                  |
| BNT2228  | Screw                | BNT3833  | Side Plate Cam Lever       |          |                                  |
| BNT2400  | Idle Gear            | BNT3834  | O Ring                     |          |                                  |
| BNT2404  | Anti-Reverse Pawl    | BNT3846  | Key Washer                 |          |                                  |
| BNT2429  | O Ring               | BNT3847  | Pinion Gear                | BNT1713  | Brake Collar (green) (accessory) |
| BNT2717  | E Lock               | BNT3906  | Handle Retainer            | BNT3237  | Wrench (accessory)               |