


SHIMANO

CURADO

CU-101D



(1RH394101U)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0011	Screw	BNT2127	Star Drag Spacer	BNT2414	Side Plate Spring
BNT0015	Drag Spring Washer	BNT2143	Ball Bearing	BNT2620	Worm Bushing A
BNT0032	Bearing Retainer	BNT2144	Washer	BNT2622	Clutch Cam
BNT0060	Spacer	BNT2150	Line Guide Pawl	BNT2623	Clutch Plate
BNT0194	Ball Bearing	BNT2151	Pawl Cap	BNT3155	Cast Control Cap
BNT0623	Screw	BNT2152	Level Wind Guide	BNT3196	Brake Case
BNT0664	Spacer B	BNT2154	Idle Gear C	BNT3208	Star Drag Click Plate
BNT0686	E Lock	BNT2161	Level Wind Guard	BNT3375	Drive Gear
BNT0987	Screw	BNT2162	Worm Bushing B	BNT3377	Pinion Gear
BNT1214	Drag Washer	BNT2192	Ball Bearing	BNT3379	Quick-Fire II Clutch Bar
BNT1328	Drive Shaft Retainer	BNT2201	Star Drag Spring	BNT3420	Handle Nut
BNT1344	C Lock	BNT2202	Star Drag Nut	BNT3551	Star Drag
BNT1419	Yoke Spring	BNT2212	Yoke	BNT3552	Screw
BNT1473	Screw	BNT2213	Clutch Cam Retainer	BNT3557	Spool Assembly
BNT1499	Screw	BNT2215	Clutch Pawl	BNT3559	Turnkey Dial
BNT1636	Screw	BNT2216	Clutch Pawl Spring	BNT3560	Handle Assembly
BNT1671	Washer	BNT2224	Spool Tension Spacer	BNT3561	Left Side Plate
BNT1672	E Lock	BNT2360	Drag Washer	BNT3562	Drive Shaft
BNT1696	Cast Control Spacer	BNT2394	Roller Clutch Inner Tube	BNT3563	One-Piece Frame
BNT1715	Brake Collar (red)	BNT2396	Roller Clutch Bearing	BNT3564	Thumb Rest
BNT1996	Spool Tension Spring	BNT2397	Key Washer	BNT3565	Right Side Plate
BNT2023	Spool Shaft Clip Holder	BNT2398	Anti-Reverse Ratchet	BNT3566	Line Guide
BNT2024	Spool Shaft Clip	BNT2400	Idle Gear A	BNT3903	Handle Retainer
BNT2119	Screw	BNT2401	Worm Shaft		
BNT2122	Click Pin	BNT2403	Line Guard		
BNT2123	Click Spring	BNT2404	Anti-Reverse Pawl	BNT3237	Wrench (accessory)

(200324)