





FX1000F 99

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3455	Spool Washer	4367	Line Roller Screw
0050	Anti-Reverse Lever Screw	3471	Anti-Reverse Cam Spring	4388	Bail Arm
0080	Line Roller	3645	Drag Knob	5166	Bail Assembly
0642	Side Cover Screw	3663	Oscillating Gear	5580	Spool Assembly
0779	Multi-Purpose Screw	3665	Slider Retainer Screw	5581	Main Shaft
0815	Line Roller Washer	3848	Bail Spring Guide (A)	5582	Rotor Assembly
1008	Handle Lock Washer	3856	Anti-Reverse Pawl	5583	Anti-Reverse Lock Out Spring
1025	Handle Assembly	3857	Anti-Reverse Pawl Spring	5584	Anti-Reverse Lock Out
1427	Spool Support	3858	Anti-Reverse Cam	5585	Rotor Lock
1442	Handle Screw Cap	4051	Bail Spring	5586	Pinion Bushing (back)
1514	Bushing Washer	4295	Bail Spring Guide (B)	5587	Drive Gear
1891	Multi-Purpose Screw	4296	Bail Spring Cover	5588	Side Cover
2283	Anti-Reverse Pawl Screw	4297	Bail Trip Lever	5589	Body
2293	Drive Gear Bushing	4298	Counterbalance Cover	5791	Bushing
2852	Handle Screw Lock	4351	Anti-Reverse Lever	5793	Oscillating Slider