


# SAHARA



## 2000FA 00

| RD No. | PARTS NAMES                   | RD No. | PARTS NAMES                   | RD No. | PARTS NAMES              |
|--------|-------------------------------|--------|-------------------------------|--------|--------------------------|
| 0026   | Ball Bearing                  | 4656   | Trip Lever Spacer             | 6628   | Oscillating Slider       |
| 0041   | Drive Gear Washer             | 4658   | Clutch Cover Screw            | 6679   | Nut Retainer             |
| 0050   | Anti-Reverse Lever Screw      | 4659   | Roller Clutch Assembly        | 6680   | Rotor Support Bushing    |
| 0071   | Rotor Nut                     | 4661   | Anti-Reverse Cam Ring         | 6686   | Click Spring             |
| 0642   | Side Cover Screw (long)       | 4749   | Bail Arm Screw                | 6687   | Bail Arm Click           |
| 0806   | Bail Hold Support Screw       | 4798   | Roller Clutch Screw           | 6692   | Bail Hold Support Shaft  |
| 0930   | Ball Bearing                  | 5180   | Drag Knob                     | 6694   | Bail Hold Support Spacer |
| 1008   | Handle Lock Washer            | 5189   | Anti-Reverse Cam              | 6696   | Pinion Gear              |
| 1083   | Slider Retainer Screw         | 5190   | Anti-Reverse Lever            | 6697   | Friction Ring Screw      |
| 1427   | Spool Support                 | 5547   | Handle Assembly               | 6698   | Friction Ring            |
| 1520   | Anti-Reverse Cam Spring       | 5625   | Line Roller Spacer            | 6699   | Drive Gear               |
| 2852   | Handle Screw Lock             | 5628   | Line Roller Collar            | 6702   | Spool Assembly           |
| 3309   | Line Roller Screw             | 5629   | Line Roller Bushing           | 6703   | Line Roller Washer       |
| 3402   | Rotor Protector Screw (small) | 5630   | Line Roller                   | 6704   | Bail Spring Guide (B)    |
| 3455   | Spool Washer                  | 6289   | Nut Retainer Screw            | 6705   | Bail Arm                 |
| 3673   | Oscillating Gear              | 6297   | Bail Spring Guide (A)         | 6706   | Bail Trip Lever          |
| 4640   | Bail Spring                   | 6482   | Rotor Protector Screw (large) | 6707   | Bail Assembly            |
| 4652   | Lever Spring Guide (B)        | 6596   | Side Cover Screw (short)      | 6708   | Body Assembly            |
| 4653   | Lever Spring                  | 6621   | Main Shaft                    | 6709   | Rotor Assembly           |
| 4654   | Lever Spring Guide (A)        | 6627   | Handle Screw Cap              |        |                          |

(120711)