


SEDONA

SE-4000FB



Part No.	Description	Part No.	Description	Part No.	Description
RD 0041	Drive Gear Washer	RD 4714	Roller Clutch Assembly	RD 8443	Anti-Reverse Lever
RD 0050	Anti-Reverse Lever Screw	RD 4749	Bail Arm Screw	RD 8633	Nut Lock Screw
RD 0071	Rotor Nut	RD 5209	Drive Gear	RD 8738	Ball Bearing
RD 0806	Bail Hold Support Screw	RD 5212	Oscillating Slider	RD 8740	Ball Bearing
RD 1008	Handle Lock Washer	RD 5213	Oscillating Gear	RD 8744	Ball Bearing
RD 1520	Anti-Reverse Cam Spring	RD 5625	Line Roller Spacer	RD 8935	Drag Knob
RD 2293	Drive Gear Bushing	RD 5909	Line Roller Bushing	RD 8936	Spool Assembly
RD 2516	Spool Support	RD 6482	Bail Spring Cover Screw (A)	RD 8937	Main Shaft
RD 2852	Handle Screw Lock	RD 6606	Side Cover Screw (B)	RD 8938	Bail Arm
RD 3309	Line Roller Screw	RD 6623	Bearing Spacer	RD 8939	Bail Assembly
RD 3402	Bail Spring Cover Screw (B)	RD 6686	Click Spring	RD 8940	Bail Trip Lever
RD 3503	Spool Washer	RD 6687	Bail Arm Click	RD 8941	Roller Clutch Screw
RD 3665	Slider Retainer Screw	RD 6692	Bail Hold Support Shaft	RD 8942	Pinion Gear
RD 4362	Side Cover Screw (A)	RD 6694	Bail Hold Support Spacer	RD 8943	Anti-Reverse Cam
RD 4649	Spacer	RD 6713	Bail Spring	RD 8944	Handle Assembly
RD 4652	Lever Spring Guide (B)	RD 6714	Bail Spring Guide (B)	RD 8945	Body Assembly
RD 4653	Lever Spring	RD 7175	Line Roller	RD 8946	Rotor Assembly
RD 4654	Lever Spring Guide (A)	RD 7176	Line Roller Washer	RD 9044	Bail Spring Guide (A)
RD 4656	Trip Lever Spacer	RD 7991	Handle Screw Cap		