


SEDONA

SE-6000FB



Part No.	Description	Part No.	Description	Part No.	Description
RD 0050	Anti-Reverse Lever Screw	RD 5041	Bushing	RD 6767	Lever Spring
RD 0521	Rotor Nut	RD 5455	Anti-Reverse Cam Spring	RD 6776	Oscillating Gear Bushing
RD 0690	Drive Gear Washer	RD 5625	Line Roller Spacer	RD 7176	Line Roller Washer
RD 0806	Bail Hold Support Screw	RD 5823	Lever Spring Guide (A)	RD 7577	Nut Lock Screw
RD 0998	Bail Spring Cover Screw (A)	RD 5825	Lever Spring Guide (B)	RD 8443	Anti-Reverse Lever
RD 1008	Handle Lock Washer	RD 5909	Line Roller Bushing	RD 8734	Handle Screw Cap
RD 1109	Slider Retainer Screw	RD 5910	Line Roller	RD 8743	Ball Bearing
RD 3182	Spool Support	RD 6379	Bail Arm Screw	RD 8744	Ball Bearing
RD 3309	Line Roller Screw	RD 6380	Bail Spring Guide (A)	RD 8958	Drag Knob
RD 3387	Handle Screw Lock	RD 6383	Bail Spring Guide (B)	RD 8959	Spool Assembly
RD 3503	Spool Washer	RD 6539	Bail Trip Lever	RD 8960	Main Shaft
RD 4004	Drive Gear Bushing	RD 6540	Bail Hold Support Spacer	RD 8961	Bail Arm
RD 4007	Oscillating Gear	RD 6623	Bearing Spacer	RD 8962	Pinion Gear
RD 4008	Oscillating Slider	RD 6664	Drive Gear	RD 8963	Anti-Reverse Cam
RD 4362	Side Cover Screw	RD 6686	Click Spring	RD 8964	Handle Assembly
RD 4416	Bail Spring Cover Screw (B)	RD 6687	Bail Arm Click	RD 8965	Body Assembly
RD 4649	Spacer	RD 6692	Bail Hold Support Shaft	RD 8966	Rotor Assembly
RD 4656	Trip Lever Spacer	RD 6760	Bail Spring Guide (A) Collar	RD 8973	Bail Assembly
RD 4763	Roller Clutch Assembly	RD 6761	Bail Spring		
RD 4829	Roller Clutch Screw	RD 6764	Spacer		