




4000RB 97

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2016	Drag Washer "H" (cloth)	4271	Anti-Reverse Cam
0041	Drive Gear Washer	2257	Drag Washer "H" (blue)	4274	Drag Shaft
0050	Anti-Reverse Lever Screw	2346	Drag Washer "C" (cloth)	4281	Pinion Gear
0071	Rotor Nut	2433	Pressure Screw	4282	Drive Gear
0080	Line Roller	2541	Anti-Reverse Pawl Screw	4290	Main Shaft
0111	Drag Coil Spring	2852	Handle Screw Lock	4310	Drag Click
0452	Drag Spring Washer	3681	Bail Spring Guide (A)	4362	Side Cover Screw
0540	Multi-Purpose Screw	3682	Bail Spring	4367	Line Roller Screw
0579	Eared Washer "B"	3687	Anti-Reverse Ratchet	4373	Quick-Fire II Trigger
0584	Hold Click Spring	3688	Anti-Reverse Lock Out	4421	Handle Screw Cap
0779	Multi-Purpose Screw	3692	Anti-Reverse Pawl Spring	4906	Anti-Reverse Lever
0786	Trigger Screw	3695	Oscillating Gear	4911	Spool Assembly
0787	Nut Lock Screw	3747	Slider Retainer Screw	4926	Drag Knob
0792	Bearing Retainer Screw	3766	Oscillating Slider	4945	Rotor
0815	Line Roller Washer	3767	Oscillating Slider Retainer	4946	Bail Assembly
0826	Key Washer "A"	3794	Drag Knob Screw	4947	Bail Arm
0930	Ball Bearing	3869	Anti-Reverse Lock Out Spring	4948	Bail Spring Cover
1008	Handle Lock Washer	4264	Bail Spring Guide (B)	4949	Side Cover
1511	Lever Spring	4266	Bail Trip Lever	4950	Body
1520	Anti-Reverse Cam Spring	4267	Bail Trip Lever Washer	5548	Handle Assembly
1596	Bushing Washer	4270	Anti-Reverse Pawl		