


SHIMANO®

1996 Repair Supplement



STRADIC

4000 96

ST4000FD

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 3307	Line Roller Bushing	RD 3520	Anti-Reverse Pawl Spring
RD 0041	Drive Gear Washer	RD 3308	Line Roller Washer	RD 3521	Anti-Reverse Pawl Spacer
RD 0071	Rotor Nut	RD 3309	Line Roller Screw	RD 3522	Worm Bearing
RD 0540	Bail Trip Lever Screw	RD 3366	Anti-Reverse Lever Screw	RD 3523	Idle Gear
RD 0779	Bail Arm Screw	RD 3402	Cover Screw	RD 3524	Worm Shaft
RD 0787	Nut Lock Screw	RD 3474	"O" Ring	RD 3525	Drive Gear
RD 0930	Ball Bearing	RD 3486	Oscillating Pawl	RD 3527	Oscillating Slide Bushing
RD 1008	Handle Lock Washer	RD 3501	Drag Knob	RD 3529	Oscillating Guide Holder
RD 1509	Bail Spring	RD 3503	Spool Washer	RD 3530	Oscillating Guide
RD 1511	Lever Spring	RD 3504	Rotor	RD 3531	Rear Protector
RD 1891	Multi Purpose Screw	RD 3506	Bail Spring Guide (A)	RD 3936	Oscillating Pawl Cover Screw
RD 2298	Spacer	RD 3507	Bail Spring Guide (B)	RD 4057	Main Shaft
RD 2309	Slide Retainer Screw	RD 3508	Bail Spring Cover	RD 4058	Oscillating Pawl Cover
RD 2362	Spool Support	RD 3509	Bail Trip Lever	RD 4059	Oscillating Slider
RD 2401	Ball Bearing	RD 3510	Counterbalance Cover	RD 4417	Line Roller (Power)
RD 2404	"E" Lock	RD 3511	Anti-Reverse Lock Out	RD 4421	Handle Screw Cap
RD 2409	Worm Shaft Spacer	RD 3512	Anti-Reverse Lock Out Spring	RD 4423	Anti-Reverse Lever
RD 2852	Handle Screw Lock	RD 3513	Lock Out Spring Holder	RD 4428	Bail Assembly
RD 2867	Bushing	RD 3514	Bearing Retainer	RD 4429	Bail Arm
RD 2904	Spool Assembly	RD 3515	Pinion Gear	RD 4430	Side Cover Flange
RD 3081	Side Cover Screw	RD 3516	Anti-Reverse Cam Spring	RD 4431	Side Cover
RD 3088	Bail Spring Cover Screw	RD 3517	Anti-Reverse Cam	RD 4432	Body
RD 3304	Bearing Spacer	RD 3518	Anti-Reverse Pawl Screw	RD 4433	Handle Assembly
RD 3306	Line Roller Bearing	RD 3519	Anti-Reverse Pawl		