


SHIMANO

TRAX

TRX151HGA



(51RL533A31X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0686	E Lock	BNT5329	Drive Shaft Retainer	BNT6921	Key Washer
BNT1672	E Lock	BNT5334	Bushing	BNT6922	Anti-Reverse Ratchet
BNT1696	Cast Control Spacer B	BNT5346	Bearing Spacer	BNT6924	O Ring
BNT2123	Click Spring	BNT5348	Screw	BNT6926	Worm Shaft
BNT2127	Star Drag Spacer	BNT5362	Clutch Pawl Spring	BNT6927	Level Wind Guard
BNT2224	Cast Control Spacer A	BNT5363	Clutch Plate	BNT6928	Screw
BNT2427	O Ring	BNT5376	Washer	BNT6931	Level Wind Guard Bushing
BNT2717	E Lock	BNT5383	Line Guide Pawl	BNT6932	O Ring
BNT4124	Star Drag Spring	BNT5503	O Ring	BNT6933	Washer
BNT4194	Ball Bearing	BNT5654	Idle Gear A	BNT6944	Clutch Guard Assembly
BNT4225	Roller Clutch Bearing	BNT5659	Idle Gear C	BNT6946	Brake Case
BNT4343	Ball Bearing	BNT5676	Brake Ring Gear	BNT6949	Star Drag Nut
BNT4588	Washer	BNT5680	Washer	BNT6953	Clutch Bar Guide B
BNT4625	Drag Washer C	BNT5681	Spring	BNT6954	Clutch Button
BNT4729	O Ring	BNT5714	Screw	BNT6955	Rught Side Plate Cam Lever
BNT4814	Screw	BNT5715	Washer	BNT6957	Yoke
BNT4817	Screw	BNT5756	Screw	BNT7095	Screw
BNT4819	Idle Gear	BNT5860	Star Drag Click Plate	BNT7096	Handle Nut Plate
BNT4867	Roller Clutch Inner Tube	BNT5938	Line Guide Assembly	BNT7099	Star Drag
BNT4874	Pawl Cap	BNT5942	Yoke Spring	BNT7100	Cast Control Cap
BNT4893	Washer	BNT5944	Screw	BNT7102	Screw
BNT4911	Clutch Pawl Assembly	BNT5945	Clutch Cam Retainer	BNT7105	Screw
BNT4925	Drive Gear	BNT5948	Screw	BNT7107	Spool Assembly
BNT4932	Click Spring	BNT5956	Stabilizer Bar	BNT7112	Frame Assembly
BNT5218	O Ring	BNT5971	O Ring	BNT7113	Right Side Plate Assembly
BNT5302	Pinion Gear	BNT5972	Brake Dial	BNT7114	Handle Nut
BNT5308	Washer	BNT6060	Roller Clutch Water Proof	BNT7115	Handle Assembly
BNT5310	Idle Gear Pin	BNT6070	Pinion Gear Bushing	BNT7116	Left Side Plate
BNT5314	Click Plate Retainer	BNT6074	Spool Clutch Pin	BNT7117	Drive Shaft
BNT5316	Click Pin	BNT6102	Clutch Cam	BNT7118	Level Wind Protector
BNT5319	Bearing Retainer	BNT6126	Handle Knob Seal	BNT7168	Drag Washer A
BNT5320	O Ring	BNT6655	Washer		
BNT5327	Idle Gear Spring	BNT6655	Washer		
BNT5328	Screw	BNT6701	Spacer		
				BNT4692	B-100 Oil (Accessory)

(211108)_001