




VM150





VM150

VM150 SPINNING REEL Part List

Key #	Description	Part No.	Key #	Description	Part No.
		VM150			VM150
1	Drag Knob Assembly	VBP332-01	40	Rotor Assembly	VBP309-01
2	Drag Seal	VBP171-01	41	Main Shaft Assembly	VBP315-01
3	Retaining Ring	SR3041	42	Rotor Seal	VBP262-01
4	Drag Washer "D"	VBP080-01	43	Screw	JX107-03
5	Drag Washer "B"	VBP033-02	44	Ball Bearing Holder	VBP190-01
6	Drag Washer "A"	VBP081-01	45	O-Ring	VBP164-01
7	Spool Bushing	VBP022-01	46	Washer	VBP065-01
8	Spool	VBP021-01	47	Pinion Ball Bearing	DP058-02
9	Spool Clicker	VBP103-01	48	One Way Clutch	VBP063-01
10	Spool Clicker Pin	VBP114-01	49	Clutch Sleeve	VBP139-01
11	Spool Click Spring	VBP069-01	50	Pinion	VBP011-01
12	Spool Click Spring Pin	ZP114-01	51	Bearing	VBP058-01
13	Spool Washer	VBP034-01	52	Trip Bumper Screw	JX125-01
14	Spool Metal	VBP213-01	53	Trip Bumper	VBP119-01
15	Rotor Nut Seal	VBP263-01	54	Body Assembly	VBP301-01
16	Rotor Nut	VBP006-01	55	O/S Gear Bushing	XP158-01
17	Screw	RQ100-02	56	O/S Gear Assembly	VBP353-01
18	Rotor Nut Retainer	VBP118-01	57	O/S Gear Ball Bearing	CH027-02
19	Washer	VBP110-01	58	O/S Gear Screw	VBP111-01
20	Bail Assembly	VBP347-01	59	O/S Slider	VBP025-01
21	Bushing	ZP106-01	60	O/S Slider Bushing "A"	VBP258-01
22	Pin	VBP042-02	61	O/S Slider Bushing "B"	VBP259-01
23	Line Roller Ball Bearing	SW017-02	62	O/S Slider Bushing "C"	VBP260-01
24	Line Roller	VBP004-01	63	Main Shaft Screw	RQ100-01
25	Line Roller Washer	VBP102-01	64	Dust Cap	VBP073-01
26	Arm Lever	VBP007-01	65	Seal Washer	VBP265-01
27	Washer	VBP167-01	66	Body Ball Bearing	CP058-03
28	Screw	MX107-02	67	O/S Pinion	VBP055-01
29	Pin	VBP042-01	68	Drive Gear Assembly	GT312-51
30	Kick Lever	VBP019-01	69	Drive Gear Adjust Washer	VBP045-01
31	Kick Lever Holder	VBP046-01	70	Side Cover Seal	VBP264-01
32	Bail Spring Shaft	VBP031-01	71	Side Cover	VBP024-01
33	Bail Spring	VBP096-01	72	Handle Cap	VBP074-01
34	Trip Pivot	VBP113-01	73	Handle Seal	VBP266-01
35	Arm Lever Cover	VBP087-01	74	Side Cover Screw Washer	VBP167-01
36	Screw	MX107-01	75	Side Cover Screw (Short)	VBP057-02
37	Rotor Bushing (B/Holder)	VBP106-02	76	Side Cover Screw	VBP057-01
38	Rotor Bushing (A/Lever)	VBP106-01	77	Handle Assembly	VBP318-01
39	E-Clip	BF092-01	78	Spool Assembly	VBP321-01