


# **VS VAN STAAL®**

## **VR125**



# VAN STAAL VR125 PART LIST

| Key # | Description                           | Part No.  | Qty | Key # | Description                           | Part No.  | Qty |
|-------|---------------------------------------|-----------|-----|-------|---------------------------------------|-----------|-----|
| 1     | Drag Knob Assembly include            | VR332-01  | 1   |       | 6N - Clutch Support Bearing           | BGRS5     | 1   |
|       | 1A - Drag Knob Cap                    | VR070-01  | 1   |       | 6P - One Way Clutch                   | VR063-01  | 1   |
|       | 1B - Drag Knob Cap O-Ring             | VR105-01  | 1   |       | 6Q - Pinion Gear Ball Bearing         | BGR02     | 1   |
|       | 1C - Drag Click Ratchet               | VR060-01  | 1   |       | 6R - Pinion Gear Assembly             | VR311-01  | 1   |
|       | 1D - Drag Nut                         | VR066-01  | 1   | 7     | Lock Ring O-Ring                      | VR101-01  | 1   |
|       | 1E - Drag Click Pawl                  | VR103-01  | 2   | 8     | Body Neck Screw                       | VR054-01  | 4   |
|       | 1F - Drag Click Spring                | VR049-01  | 2   | 9     | Body Neck Assembly                    | VR341-01  | 1   |
|       | 1G - Drag Spring                      | VR043-01  | 1   | 10    | Body Neck O-Ring                      | VR164-01  | 1   |
|       | 1H - Drag Knob                        | VR032-01  | 1   | 11    | Spool Shaft                           | VR015-01  | 1   |
| 2     | Spool Assembly (Kit) include          | VR321-10  | 1   | 12    | Body                                  | VR001-01  | 1   |
|       | 2A - Drag Cap                         | VR050-01  | 1   | 13    | Body Cover O-Ring                     | VS145-01  | 2   |
|       | 2B - Drag Cap O-Ring                  | VS098-01  | 1   | 14    | Service Cover                         | VR024-01  | 1   |
|       | 2C - Drag Cap Seal                    | VR171-01  | 1   | 15    | Drive Gear Assembly                   | VR312-01  | 1   |
|       | 2D - Spool Click Ratchet              | VR037-01  | 1   | 16    | Spool Shaft Spacer                    | VR026-01  | 1   |
|       | 2E - Spool Click Ratchet O-Ring       | VR145-01  | 1   | 17    | O/S Slider Assembly (Kit) include     | VR4025-01 | 1   |
|       | 2F - Spool Click Pawl                 | VR103-01  | 2   |       | 17A - E-Clip                          | NX092-01  | 2   |
|       | 2G - Spool Click Pawl Spring          | VR049-01  | 2   |       | 17B - O/S Slider Bearing Spacer       | VR029-01  | 4   |
|       | 2H - Drag Washer Keeper               | VR082-01  | 1   |       | 17C - O/S Slider Bearing Wear Ring    | VR106-01  | 2   |
|       | 2J - Spool Ball Bearing               | CH027-02  | 2   |       | 17D - O/S Slider Bearing              | XX117-01  | 2   |
|       | 2K - Spool Bearing Spacer             | VR161-01  | 1   |       | 17E - O/S Slider Bearing Shaft        | VR115-01  | 1   |
|       | 2L - Drag Washer Inner Lock           | VR080-01  | 3   |       | 17F - O/S Slider                      | VR025-01  | 1   |
|       | 2M - Drag Disc                        | VR030-01  | 5   | 18    | M5x0.8 Hex Nut                        | VR014-01  | 1   |
|       | 2N - Drag Washer Outer Lock           | VR081-01  | 3   | 19    | Locking Plate                         | VR078-01  | 1   |
|       | 2P - Spool                            | VR021-10  | 1   | 20    | Locking Plate Screw                   | VR051-01  | 1   |
|       | 2Q - Front Drag key Washer            | VS081-01  | 1   | 21    | Drive Gear Adjust Washer              | DF035-02  | 0   |
|       | 2R - Front Drag Disc                  | VS030-01  | 1   | 22    | Drive Gear Adjust Washer              | DF035-05  | 0   |
|       | 2S - Front Drag Washer                | VS080-01  | 1   | 23    | Gear Bearing                          | CF017-03  | 1   |
|       | 2T - Drag Knob Seal                   | VS171-01  | 1   | 24    | Body Cover                            | VR023-01  | 1   |
| 3     | Rotor Nut                             | VR006-01  | 1   | 25    | Body Cover Ball Bearing Adjust Washer | VR084-01  | 0   |
| 4     | Rotor Nut O-Ring                      | VR145-01  | 1   | 26    | Body Cover Ball Bearing Adjust Washer | VR084-02  | 0   |
| 5     | Rotor Assembly (Kit) include          | VR4009-10 | 1   | 27    | Body Cover Ball Bearing               | TW058-02  | 1   |
|       | 5A - Line Slider Screw                | VR108-01  | 1   | 28    | Handle Sleeve O-Ring                  | VR098-01  | 1   |
|       | 5B - Line Slider Screw O-Ring         | VS164-01  | 1   | 29    | Handle Sleeve                         | VS110-01  | 1   |
|       | 5C - Bail Arm Lever                   | VR007-01  | 1   | 30    | Gear Shaft Seal                       | VS109-01  | 1   |
|       | 5D - Arm Lever Bushing                | VR158-01  | 2   | 31    | Handle Assembly include               | VR318-01  | 1   |
|       | 5E - Arm Lever Cap                    | VR113-01  | 1   |       | 31A - Handle Stand Insert             | VS158-01  | 1   |
|       | 5F - Arm Lever O-Ring                 | VS101-01  | 1   |       | 31B - Handle Stand                    | VS058-01  | 1   |
|       | 5G - Line Roller Spacer "A"           | VR016-01  | 1   |       | 31C - Handle Arm                      | VR018-01  | 1   |
|       | 5H - Line Roller Seal                 | VR262-01  | 2   |       | 31D - Handle Cap                      | VS054-01  | 1   |
|       | 5J - Line Roller Ball Bearing         | CT157-02  | 1   |       | 31E - Handle Knob Screw               | VR077-01  | 2   |
|       | 5K - Line Roller                      | VR004-01  | 1   |       | 31F - Handle Knob Shaft               | VR005-01  | 1   |
|       | 5L - Line Roller Spacer "B"           | VR102-01  | 1   |       | 31G - Handle Knob Seal                | VR262-01  | 1   |
|       | 5M - Bail Assembly                    | VR347-10  | 1   |       | 31H - Handle Knob Ball Bearing        | VR028-01  | 2   |
|       | 5N - Bail Spring Cover Support        | VR046-01  | 2   |       | 31J - Handle Knob Nut                 | VS014-01  | 1   |
|       | 5P - Bail Spring Link                 | VS095-01  | 2   |       | 31K - Handle Knob                     | VR013-01  | 1   |
|       | 5Q - Bail Spring Spacer               | VR048-01  | 2   |       | 31L - Handle Knob Hub                 | VR003-01  | 1   |
|       | 5R - Bail Spring                      | VR022-01  | 2   |       | 31M - Handle Knob Cap O-Ring          | VS101-01  | 1   |
|       | 5S - Bail Spring Pivot                | VR095-01  | 2   |       | 31N - Handle Knob Cap                 | VR073-01  | 1   |
|       | 5T - Rotor                            | VR009-10  | 1   |       | 31A - Handle Stand Insert             | VS158-01  |     |
|       | 5U - Bail Spring Cover Screw          | VR057-01  | 2   |       | 31B - Handle Stand                    | VS058-01  |     |
|       | 5V - Counter Weight Screw             | VR057-02  | 1   |       | 31C - Handle Arm                      | VR018-01  |     |
|       | 5W - Bail Holder Screw                | VR051-01  | 1   |       | 31D - Handle Cap                      | VS054-01  |     |
|       | 5X - Bail Holder                      | VR017-01  | 1   |       | 31E - Handle Knob Screw               | VR077-01  |     |
|       | 5Y - Bail Holder Cap                  | VS113-01  | 1   |       | 31F - Handle Knob Shaft               | VR005-01  |     |
|       | 5Z - Counter Weight                   | VR148-01  | 1   |       | 31G - Handle Knob Seal                | VR262-01  |     |
| 6     | Clutch Housing Assembly (Kit) include | VR4038-01 | 1   |       | 31H - Handle Knob Ball Bearing        | VR028-01  |     |
|       | 6A - Spool Shaft Guide Seal           | VR171-01  | 1   |       | 31J - Handle Knob Nut                 | VS014-01  |     |
|       | 6B - Spool Shaft Bearing Bushing      | VR259-01  | 1   |       | 31K - Handle Knob                     | VR013-01  |     |
|       | 6C - Spool Shaft Bearing              | CH027-02  | 1   |       | 31L - Handle Knob Hub                 | VR003-01  |     |
|       | 6D - Spool Shaft Guide Assembly       | VR375-01  | 1   |       | 31M - Handle Knob Cap O-Ring          | VS101-01  |     |
|       | 6E - Spool Shaft Guide O-Ring         | VS101-01  | 1   |       | 31N - Handle Knob Cap                 | VR073-01  |     |
|       | 6F - Clutch Sleeve                    | VR139-01  | 1   |       |                                       |           |     |
|       | 6G - Clutch Sleeve Pin                | VR149-01  | 1   | 32    | Line Slider - Manual Pick up          | VS010-01  | 1   |
|       | 6H - Lock Ring                        | VR122-01  | 1   | 33    | Arm Lever Locking Pin                 | VR085-01  | 1   |
|       | 6J - Clutch Housing O-Ring "B"        | ORR8      | 1   | 34    | Arm Lever Spacer Washer               | VR109-01  | 1   |
|       | 6K - Clutch Housing O-Ring "A"        | VS1591    | 1   | 35    | Balancer                              | VS017-01  | 1   |
|       | 6L - Clutch Housing                   | VR038-01  | 1   | 5U    | Bail Spring Cover Screw               | VR057-01  | 2   |
|       | 6M - Main Seal                        | OSPR6     | 1   |       |                                       |           |     |