


VS100/150/150L Component Diagram



#	Part Name	Part No. (VS100/VS150/VS150L)	#	Part Name	Part No. (VS100/VS150/VS150L)	#	Part Name	Part No. (VS100/VS150/VS150L)
1	DRAG KNOB	SR1006	24	SCREW	SCBH1	47	HOUSING	SR1000/SR1000/SR1000L
2	PIN	PIDW1	25	WASHER SEAL	SR3025	48	HEX SCREW	SCFH3
3	SPRING GUIDE	SR1027	26	RETAINING RING	RR11	49	TRAVERS GUIDE	SR1017
4	SPRING	SR1054	27	RADIAL BEARING	BGRS1	50	LOCK WASHER	WSLCIT1
5	WASHER	SR1074	28	LINE ROLLER SPINDLE	SR3021P	51	HEX NUT	NTHX1
6	INNER SLEEVE	SR1026	29	LINE ROLLER	SR3020	52	SPINDLE	SR1023
7	SCREW, 0-80	SCFH15	30	SCREW	SCFH6	53	ROLLER	SR1022
8	RETAINING RING	SR1041	31	FLYER	SR1001/SR1501/SR1501L	54	MAIN GEAR	SR1009/SR1009/SR1009L
9	O-RING	ORR10	32	ROLL PIN	PIRL3	55	RADIAL BEARING	BGRS12
10	RETAINER	VS1024P	33	SCREW	SCFH1	56	CLUTCH BEARING	BGRC2
11	OIL SEAL	OSPR6	34	COUNTERWEIGHT	SR1059P/SR1559P/SR1559P	57	O-RING	ORR9
12	RADIAL BEARING	BGRS9	35	ROLL PIN	PIRL1	58	COVER	VS1102/VSB1102/SR1002L
13	BASE DRAG WASHER	SR1036	36	SHAFT	SR1010	59	BALL BEARING	BGRS90
14	DRAG WASHER	SR1038	37	LOCK RING	SR1055P	60	OIL SEAL	OSPR5
15	OCT. DRAG WASHER	SR1039	38	QUAD-SEAL	ORQ3	61	HANDLE HUB	SR1014/SR1014/SR1014L
16	SLOTTED DRAG WASHER	SR1037	39	SLEEVE GUIDE	SR1012/SR1012/SR1012L	62	HANDLE SCREW	SCSHC8
17	SPOOL	SR1003/SR1503/SR1503	40	SLEEVE	SR1021	63	HANDLE ARM	SR1005
18	CLICKER BASE	SR1057P	41	O-RING	ORR8	64	KNOB BOLT NUT	SR1060P
19	CLICKER	SR1058P	42	SEAL CARRIER	SR1072	65	HANDLE WASHER	SR1078
20	SCREW, 4-40	SCFH2	43	RADIAL BEARING	BGRS11	66	FLANGED BUSHING	SR1030
21	SPOOL HUB	VS1040P	44	PINION	SR1011/SR1011/SR1011L	67	CRANK KNOB	SR1008
22	SPINDLE NUT	SR3028P	45	BUSHING	SR1016	68	BUSHING	SR1029
23	LINE ROLLER BRACKET	SR1019/SR1519/SR1519L	46	FOOT	SR1004/SR1004/SR1004L	69	SHOULDER SCREW	SR1020P

