VAN STAAL®

VR175



VAN STAAL VR175 PART LIST

Key #	Description	Part No.	Qty	Key #	Description	Part No.	Qty
1	Drag Knob Assembly include	VS332-01	1		6N - Clutch Support Bearing	BGRS5	1
	1A - Drag Knob Cap	VR070-01	1		6P - One Way Clutch	VR063-01	1
	1B - Drag Knob Cap O-Ring	VR105-01	1		6Q - Pinion Gear Ball Bearing	BGR02	1
	1C - Drag Click Ratchet	VR060-01	1		6R - Pinion Gear Assembly	VR311-01	1
	1D - Drag Nut	VR066-01	1	7	Lock Ring O-Ring	VR101-01	1
	1E - Drag Click Pawl	VR103-01	2	8	Body Neck Screw	VR054-01	4
	1F - Drag Click Spring	VR049-01	2	9	Body Neck Assembly	VR341-01	1
	1G - Drag Spring	VR043-01	1	10	Body Neck O-Ring	VR164-01	1
	1H - Drag Knob	VS032-01	1	11	Spool Shaft	VR015-01	1
2	Spool Assembly (Kit) include	VR321-30	1	12	Body	VR001-01	1
	2A - Drag Cap	VR050-01	1	13	Body Cover O-Ring	VS145-01	2
	2B - Drag Cap O-Ring	VS098-01	1	14	Service Cover	VR024-01	1
	2C - Drag Cap Seal	VR171-01	1	15	Drive Gear Assembly	VR312-01	1
	2D - Spool Click Ratchet	VR037-01	1	16	Spool Shaft Spacer	VR026-01	1
	2E - Spool Click Ratchet O-Ring	VR145-01	1	17	O/S Slider Assembly (Kit) include	VR4025-01	1
	2F - Spool Click Pawl	VR103-01	2		17A - E-Clip	NX092-01	2
	2G - Spool Click Pawl Spring	VR049-01	2		17B - O/S Slider Bearing Spacer	VR029-01	4
	2H - Drag Washer Keeper	VR082-01	1		17C - O/S Slider Bearing Wear Ring	VR106-01	2
	2J - Spool Ball Bearing	CH027-02	2		17D - O/S Slider Bearing	XX117-01	2
	2K - Spool Bearing Spacer	VR161-01	1		17E - O/S Slider Bearing Shaft	VR115-01	1
	2L - Drag Washer Inner Lock	VR080-01	3		17F - O/S Slider	VR025-01	1
	2M - Drag Disc	VR030-01	5	18	M5x0.8 Hex Nut	VR014-01	1
	2N - Drag Washer Outer Lock	VR081-01	3	19	Locking Plate	VR078-01	1
	2P - Spool	VR021-30	1	20	Locking Plate Screw	VR051-01	1
	2Q - Front Drag key Washer	VS081-01	1	21	Drive Gear Adjust Washer	DF035-02	0
	2R - Front Drag Disc	VS030-01	1	22	Drive Gear Adjust Washer	DF035-05	0
	2S - Front Drag Washer	VS080-01	1	23	Gear Bearing	CF017-03	1
	2T - Drag Knob Seal	VS171-01	1	24	Body Cover	VR023-01	1
3	Rotor Nut	VR006-01	1	25	Body Cover Ball Bearing Adjust Washer	VR084-01	0
4	Rotor Nut O-Ring	VR145-01	1	26	Body Cover Ball Bearing Adjust Washer	VR084-02	0
5	Rotor Assembly (Kit) include	VR4009-30	1	27	Body Cover Ball Bearing	TW058-02	1
	5A - Line Slider Screw	VR108-01	1	28	Handle Sleeve O-Ring	VR098-01	1
	5B - Line Slider Screw O-Ring	VS164-01	1	29	Handle Sleeve	VS110-01	1
	5C - Bail Arm Lever	VR007-01	1	30	Gear Shaft Seal	VS109-01	1
	5D - Arm Lever Bushing	VR158-01	2	31	Handle Assembly include	VR318-01	1
	5E - Arm Lever Cap	VR113-01	1		31A - Handle Stand Insert	VS158-01	1
	5F - Arm Lever O-Ring	VS101-01	1		31B - Handle Stand	VS058-01	1
	5G - Line Roller Spacer "A"	VR016-01	1		31C - Handle Arm	VR018-01	1
	5H - Line Roller Seal	VR262-01	2		31D - Handle Cap	VS054-01	1
	5J - Line Roller Ball Bearing	CT157-02	1		31E - Handle Knob Screw	VR077-01	2
	5K - Line Roller	VR004-01	1		31F - Handle Knob Shaft	VR005-01	1
	5L - Line Roller Spacer "B"	VR102-01	1		31G - Handle Knob Seal	VR262-01	1
	5M - Bail Assembly	VR347-30	1		31H - Handle Knob Ball Bearing	VR028-01	2
	5N - Bail Spring Cover Support	VR046-01	2		31J - Handle Knob Nut	VS014-01	1
	5P - Bail Spring Link	VS095-01	2		31K - Handle Knob	VR013-01	1
	5Q - Bail Spring Spacer	VR048-01	2		31L - Handle Knob Hub	VR003-01	1
	5R - Bail Spring	VR022-01	2		31M - Handle Knob Cap O-Ring	VS101-01	1
	5S - Bail Spring Pivot	VR095-01	2		31N - Handle Knob Cap	VR073-01	1
	5T - Rotor	VR009-30	1		31A - Handle Stand Insert	VS158-01	
	5U - Bail Spring Cover Screw	VR057-01	2		31B - Handle Stand	VS058-01	
	5V - Counter Weight Screw	VR057-02	1		31C - Handle Arm	VR018-01	
	5W - Bail Holder Screw	VR051-01	1		31D - Handle Cap	VS054-01	
	5X - Bail Holder	VR017-01	1		31E - Handle Knob Screw	VR077-01	
	5Y - Bail Holder Cap	VS113-01	1		31F - Handle Knob Shaft	VR005-01	
	5Z - Counter Weight	VS148-01	1		31G - Handle Knob Seal	VR262-01	
6	Clutch Housing Assembly (Kit) include	VR4038-01	1		31H - Handle Knob Ball Bearing	VR028-01	
	6A - Spool Shaft Guide Seal	VR171-01	1		31J - Handle Knob Nut	VS014-01	
	6B - Spool Shaft Bearing Bushing	VR259-01	1		31K - Handle Knob	VR013-01	
	6C - Spool Shaft Bearing	CH027-02	1		31L - Handle Knob Hub	VR003-01	
	6D - Spool Shaft Guide Assembly	VR375-01	1		31M - Handle Knob Cap O-Ring	VS101-01	
	6E - Spool Shaft Guide O-Ring	VS101-01	1		31N - Handle Knob Cap	VR073-01	
	6F - Clutch Sleeve	VR139-01	1				
	6G - Clutch Sleeve Pin	VR149-01	1	32	Line Slider - Manual Pick up	VS010-01	1
	6H - Lock Ring	VR122-01	1	33	Arm Lever Locking Pin	VR085-01	1
	6J - Clutch Housing O-Ring "B"	ORR8	1	34	Arm Lever Spacer Washer	VR109-01	1
	6K - Clutch Housing O-Ring "A"	VSB1591	1	35	Balancer	VS017-01	1
	6L - Clutch Housing	VR038-01	1	5U	Bail Spring Cover Screw	VR057-01	2
	6M - Main Seal	OSPR6	1				